

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AOLION](#) /

› [AOLION Charging Grip for Switch 2 Joycon Instruction Manual](#)

AOLION AL-N52501B

AOLION Charging Grip for Switch 2 Joycon Instruction Manual

Model: AL-N52501B

PRODUCT OVERVIEW

This manual provides instructions for the AOLION Charging Grip designed for Switch 2 Joycon controllers. It details the product's features, setup, operation, maintenance, and specifications to ensure proper use and longevity.

WHAT'S IN THE BOX

- 1x Charging Grip
- 1x Type-C Charging Cable
- 1x Instruction Manual

KEY FEATURES

- **Stable Hold:** Provides a secure and stable connection for Switch 2 Joycon controllers during gameplay.
- **Charge While Playing:** Allows continuous charging of Joycon controllers via the included Type-C cable during use.
- **Ergonomic Design:** Shaped for comfortable extended gaming sessions, reducing hand fatigue.
- **LED Charging Indicator:** Features an intuitive LED system (Red for charging, Green for fully charged) to display charging status.
- **Portable Design:** Lightweight and compact for easy transport and quick attachment/detachment.

Perfectly matches the style and size of the console controller.



The blue and orange lights are image effects, not actual lights from the grip

Image: The charging grip connected to a console, allowing gameplay while charging. Includes a 23-inch Type-C cable.

Easy Installation, Firm Fit

Ours: Secure fixation prevents controller from falling or loosening during intense gaming



Installation



1 2



1 2

Image: Illustration of the grip's ergonomic design for improved handling and reduced fatigue during extended play.

SETUP AND INSTALLATION

- Attaching Joycon Controllers:** Align the Joycon controllers with the rails on the charging grip. Slide each Joycon down until it clicks securely into place. Ensure both controllers are firmly attached.
- Detaching Joycon Controllers:** Press the release button located on the back of the grip for each Joycon. Gently slide the Joycon upwards to detach it from the grip.

Play & Charge, Stays Cool

Enjoy uninterrupted gaming without worrying about battery depletion.
Prevents the controller from overheating.

Includes a 23-inch Type-C cable.
For longer reach, please consider using an additional cable.



Image: Visual guide for attaching and detaching Joycon controllers from the grip, demonstrating a firm and secure fit.

Your browser does not support the video tag.

Video: Demonstration of attaching and detaching Joycon controllers to the AOLION Charging Grip.

OPERATING INSTRUCTIONS

Charging the Joycon Controllers

1. Connect the included Type-C cable to the charging port on the grip and to a compatible USB power source (e.g., console dock, USB wall adapter).
2. Ensure Joycon controllers are securely attached to the grip.
3. The LED indicator will show the charging status.

LED Charging Indicator

- **Red Light:** Indicates that the Joycon controllers are currently charging.
- **Green Light:** Indicates that the Joycon controllers are fully charged.
- **No Light:** Indicates the grip is not working or not connected to power.

A full charge typically takes approximately 3.5 hours or less.

Fast Charging & LED Display

Charges in 3.5 hours or less.
LED shows status clearly.




Image: Explanation of the LED indicator lights for charging status (Red: Charging, Green: Fully Charged, No Light: Not Working).

MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the surface of the grip. Avoid using abrasive cleaners or solvents.
- Storage:** Store the grip in a cool, dry place away from direct sunlight and extreme temperatures.
- Handling:** Avoid dropping the grip or subjecting it to strong impacts.

TROUBLESHOOTING

Joycon controllers feel wobbly or loose:

Ensure the Joycon controllers are fully slid down until they click into place. Verify that the release buttons are not accidentally pressed during use. If the issue persists, ensure the Joycon rails are clean and free of debris.

Joycon controllers are not charging:

Check that the Type-C cable is securely connected to both the grip and the power source. Confirm the power source is active. Ensure the Joycon controllers are properly attached to the grip. If the LED indicator shows no light, try a different Type-C cable or power source.

LED indicator is not working:

Verify the grip is connected to a power source and Joycon controllers are attached. If the issue continues, contact customer support.

SPECIFICATIONS

Feature	Detail
Model	AL-N52501B
Dimensions	4.8 x 3.19 x 0.75 inches (12.2 x 8.1 x 1.9 cm)

Item Weight	2.89 ounces (81.9 grams)
Charging Interface	Type-C
Charging Time	Approximately 3.5 hours

Better Grip, Less Fatigue

Improves control and reduces hand strain during extended gameplay.



In some games, the enhanced grip may not be as effective.



Image: Detailed dimensions of the charging grip for reference.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact the manufacturer, AOLION, directly through their official website or the retailer where the product was purchased. Keep your purchase receipt for warranty claims.

© 2025 AOLION. All rights reserved.

This manual is subject to change without notice.