

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SVITOO](#) /

› [SVITOO Kids Tablet 10 Inch \(Model SVITOO Tab 10 GMS Certified 1027C\) User Manual](#)

SVITOO SVITOO Tab 10 GMS Certified 1027C

SVITOO Kids Tablet 10 Inch User Manual

Model: SVITOO Tab 10 GMS Certified 1027C

INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your SVITOO Kids Tablet 10 Inch. Designed for young users, this Android 15 tablet features parental controls, a durable shockproof case, and a vibrant 10-inch HD IPS display. Please read this guide thoroughly to ensure proper use and to maximize your tablet's functionality.

WHAT'S IN THE BOX

- SVITOO Kids Tablet 10 Inch
- Protective Cover (Pre-installed)
- USB-C Charging Cable
- User Manual
- Gift Box



Image: The SVITOO Kids Tablet 10 Inch, shown in its blue protective case, highlighting its robust design suitable for children.

PRODUCT OVERVIEW

Key Features

- Operating System:** Android 15 with GMS Certification for full Google Play access.
- Display:** 10-inch HD IPS (1280 x 800 pixels) touchscreen with eye protection mode.
- Processor:** Unisoc T7200 8-core CPU for smooth performance.
- Memory & Storage:** 20GB RAM (3GB physical + 17GB virtual) and 64GB internal storage, expandable up to 1TB via microSD card (sold separately).
- Cameras:** 8MP Rear Camera and 2MP Front Camera.
- Connectivity:** Dual-Band Wi-Fi (2.4/5 GHz) and Bluetooth 5.0.
- Battery:** 6000mAh high-capacity battery for extended usage.
- Audio:** Dual-box speakers and a 3.5mm headphone jack.

- **Durability:** Kid-friendly EVA shockproof case with a 360° rotating handle and 180° rotating stand.
- **Parental Controls:** Advanced settings for screen time limits, content filtering, and app management.

Tablet Components

Familiarize yourself with the physical components of your tablet:



Image: A detailed view of the tablet's side and rear, indicating the USB Type-C port, headphone jack, power ON/OFF button, volume controls, speakers, rear camera, and front camera.

- **USB Type-C Port:** For charging and data transfer.
- **Headphone Jack (3.5mm):** For connecting wired headphones.
- **Power ON/OFF Button:** To turn the tablet on/off or put it to sleep.
- **Volume Buttons:** To adjust the audio volume.
- **Speakers:** Dual-box speakers for audio output.
- **Front Camera:** For video calls and selfies.
- **Rear Camera:** For taking photos and videos.

- **MicroSD Card Slot:** Located under a protective flap, for storage expansion.



Image: The tablet's protective case featuring a versatile 360-degree rotating handle that also functions as a 180-degree rotating stand, allowing for various viewing angles.

SETUP GUIDE

1. **Charge the Tablet:** Before first use, fully charge the tablet using the provided USB-C cable and a compatible power adapter.
2. **Power On:** Press and hold the Power ON/OFF button until the screen lights up.
3. **Initial Setup:** Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
4. **Google Kids Space / Parental Controls:** During setup, you will have the option to configure Google Kids Space or other parental control settings. It is highly recommended to set these up immediately to ensure a safe environment for your child.

5. **Install Apps:** Once setup is complete, you can download age-appropriate apps and games from the Google Play Store.

OPERATING INSTRUCTIONS

Basic Navigation

- **Home Screen:** Swipe left or right to access different app pages.
- **App Drawer:** Swipe up from the bottom of the screen to view all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to access notifications and quick settings like Wi-Fi, Bluetooth, and screen brightness.
- **Back, Home, Recent Apps:** Use the navigation buttons at the bottom of the screen to go back, return to the home screen, or view recently opened applications.

Charging the Tablet

Connect the USB-C charging cable to the tablet's USB-C port and the other end to a power adapter. The battery icon on the screen will indicate charging status. A full charge provides approximately 12 hours of mixed use.

6000mAh

All-Day Battery Life

Endless Play Power Through The Entire Day.



Night Mode



Energy Saving



9H
Video



12H
Music



12H
Browsing



60Days
Standby

Image: The tablet connected to a charger, displaying a battery icon with 99% charge, illustrating the charging process and battery life features like Night Mode and Energy Saving.

Eye Protection Mode

To reduce eye strain, especially during prolonged use, activate the Eye Protection Mode (often called Night Mode or Reading Mode) from the quick settings panel or display settings. This mode adjusts screen colors to warmer tones.

PARENTAL CONTROLS

The SVITOO Kids Tablet features robust parental controls to help manage your child's digital experience. These controls are integrated with Android 15 and Google Family Link.

Smart Family Link Parental Controls



Set screen
time limits



Block harmful
apps and websites



Approve or deny
app downloads



Track your
child's location

Help kids build
healthy digital habits

Image: A family using the tablet, with an overlay showing various parental control options such as setting screen time limits, blocking harmful apps/websites, approving app downloads, and tracking child's location.

Configuring Parental Controls:

- Access Settings:** Go to **Settings > Digital Wellbeing & Parental Controls** or search for "Family Link" in your app drawer.
- Set Screen Time Limits:** Define daily limits for tablet usage to encourage balanced screen time.
- Content Filtering:** Block access to inappropriate websites and apps.
- App Approvals:** Require parental approval for new app downloads or in-app purchases.
- Location Tracking:** Monitor your child's device location (if enabled and configured).

For detailed instructions on Google Family Link, please refer to Google's official support documentation.

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and tablet body. Avoid abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the tablet frequently. Charge it regularly and avoid exposing it to extreme temperatures.
- **Software Updates:** Keep the tablet's operating system and apps updated to ensure optimal performance and security.
- **Storage:** Store the tablet in a cool, dry place away from direct sunlight when not in use.
- **Protective Case:** The included EVA shockproof case provides protection against drops and bumps. Ensure it is properly fitted at all times.

TROUBLESHOOTING

Problem	Solution
Tablet does not turn on.	Ensure the tablet is fully charged. Connect it to a charger for at least 30 minutes, then try powering it on again.
Screen is unresponsive.	Perform a force restart by holding the Power ON/OFF button for 10-15 seconds. If the issue persists, contact support.
Wi-Fi connection issues.	Check if other devices can connect to the Wi-Fi network. Restart your router and the tablet. Forget the network and reconnect.
Apps are crashing or slow.	Close background apps. Clear app cache (Settings > Apps > [App Name] > Storage > Clear Cache). Ensure sufficient storage space is available. Restart the tablet.
Battery drains quickly.	Reduce screen brightness. Close unused apps. Disable Wi-Fi/Bluetooth when not in use. Check battery usage in settings to identify power-hungry apps.

SPECIFICATIONS

Feature	Detail
Model Name	SVITOO Tab 10 GMS Certified 1027C
Operating System	Android 15
Screen Size	10 Inches
Screen Resolution	1280 x 800 Pixels (HD IPS)
Processor	1.8 GHz (Unisoc T7200 8-core CPU)
RAM	20 GB (3GB physical + 17GB virtual)
Internal Storage	64 GB
Expandable Storage	Up to 1TB via MicroSD (sold separately)
Graphics Coprocessor	Mali-G57 processor Imagination Tech
Wireless Type	802.11a/b/g/n/ac (Dual-Band 2.4/5 GHz)

Feature	Detail
Bluetooth	Bluetooth 5.0
Battery Capacity	6000mAh
Average Battery Life	12 Hours
Front Camera	2 Megapixel
Rear Camera	8 Megapixel
Item Weight	2.44 pounds
Product Dimensions	9.7 x 6.4 x 0.4 inches

WARRANTY AND SUPPORT

Your SVITOO Kids Tablet comes with a **1-Year Manufacturer Protection**. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, natural disasters, or unauthorized modifications.

For technical support, warranty claims, or any questions regarding your product, please contact SVITOO customer service through your Amazon order page. Look for the "Contact Us" option next to your order details.

Please retain your proof of purchase for warranty purposes.