

Jzones CT

Jzones Open Ear Earbuds User Manual

MODEL: CT

Introduction

Thank you for choosing Jzones Open Ear Earbuds. These true wireless clip-on earbuds are designed for lightweight comfort and allow you to stay aware of your surroundings while enjoying clear audio. Featuring Bluetooth 5.4 connectivity and a stable fit, they are ideal for various activities including outdoor sports.

What's in the Box

Your Jzones Open Ear Earbuds package includes the following components:

- User Manual
- Charging Case
- Earbuds (Left and Right)
- USB Type-C Charging Cable



Image: The Jzones Open Ear Earbuds, showing both earbuds and their compact charging case.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case provides an additional 19.5 hours of playtime, and can be fully charged in just 2 hours via the included fast charging Type-C cable.

- Place the earbuds into their respective slots in the charging case.
- Connect the USB Type-C cable to the charging port on the case and plug the other end into a USB power source.
- The LED display on the charging case will indicate the battery percentage.

WATER RESISTANCE WITH IPX4

Rainproof



Antiperspirant



Splash prevention



*Rain or Sweat, Music Never Stops

Image: The Jzones charging case displaying its battery level, indicating the remaining charge for both the case and the earbuds.

2. Bluetooth Pairing

The earbuds utilize advanced Bluetooth 5.4 for faster connections and enhanced stability.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.

3. Search for "CT" in the list of available Bluetooth devices.
4. Select "CT" to connect. Once connected, a voice prompt will confirm the successful pairing.
5. The smart auto-pairing feature activates instantly when you remove the earbuds from the case for subsequent uses.

Lightweight and Secure Fit

Each earbud weighs only 5g



*Better wearing experience than regular headphones

5g



Image: A visual representation of the earbuds connecting via Bluetooth 5.4 to a smartphone and laptop, highlighting the quick connect feature.

Operating Instructions

Wearing the Earbuds

The Jzones Open Ear Earbuds feature a unique clip-on design for secure and comfortable wear without entering the ear canal.

- Gently clip each earbud onto the outer part of your ear.
- Adjust for a snug yet comfortable fit. The lightweight design (5.7g per earbud) ensures a barely-there sensation.
- The open-ear design allows you to hear your surroundings while enjoying private sound, enhancing safety during outdoor activities.

Open-ear Clip-on Earbuds

Comfortable Fit, Zero Pain



Elastic

adaptable to your ears



Flexible

Soft&cozy



Image: A woman wearing the Jzones Open Ear Earbuds, demonstrating their comfortable and secure clip-on fit.


Touch Controls

Control your audio and calls with simple touch gestures on either earbud. The touch sensor is sensitive, so avoid direct contact with the body as much as possible.

Action	Left Earbud	Right Earbud
--------	-------------	--------------

Action	Left Earbud	Right Earbud
Play/Pause Music	Tap Once	Tap Once
Next Track	Double Tap (R)	Double Tap (R)
Previous Track	Double Tap (L)	Double Tap (L)
Answer/End Call	Double Tap	Double Tap
Reject Call	Long Press 2S	Long Press 2S
Activate Voice Assistant (Siri)	Triple Tap	Triple Tap

One-tap Control



Sensitive binaural touch for precise recognition

Image: A diagram illustrating the various touch control gestures for the Jzones earbuds, including single tap, double tap, long press, and triple tap functions.

Audio Quality

The bone conduction headphones feature a 14.2mm speaker and a built-in microphone, delivering vibrant, high-fidelity stereo sound and enhanced call quality. The completely open design allows you to hear your surroundings while enjoying private sound.

Clear Stereo Sound Quality



14.2mm speaker

sound transmission
enhancement technology



Image: A detailed diagram highlighting the 14.2mm speaker within the Jzones earbud, emphasizing its role in sound transmission enhancement technology.

Maintenance

Water Resistance (IPX4)

The earbuds feature a protective mesh and IPX4 water resistance, making them suitable for workouts and outdoor adventures. They stand up to an active lifestyle but are not suitable for swimming or full submersion in water.

- Wipe the earbuds clean with a soft, dry cloth after use, especially after workouts.
- Do not rinse under running water or submerge in any liquid.
- Ensure the charging contacts on both the earbuds and the case are dry before placing them back in the case to charge.

One-Step Pairing

Enhanced Connectivity with Bluetooth 5.4



5.4
Bluetooth



Quick Connect




Image: An illustration depicting the IPX4 water resistance of the Jzones earbuds, showing them resistant to rain, perspiration, and splashes.

Troubleshooting

If you encounter any issues with your Jzones Open Ear Earbuds, please try the following steps:

- **No Sound:** Ensure the earbuds are charged and properly connected to your device. Check the volume levels on both the earbuds and your device.
- **Pairing Issues:** Turn off Bluetooth on your device, then turn it back on. Try forgetting the device in your Bluetooth settings and re-pairing. Ensure the earbuds are fully charged.
- **Intermittent Connection:** Ensure there are no obstructions between the earbuds and your device. Keep your device within the Bluetooth range (up to 33 feet).
- **Charging Problems:** Verify that the charging cable is securely connected to both the case and the power source. Clean the charging contacts on the earbuds and inside the case with a dry cotton swab.

For persistent issues, refer to the full user manual or contact customer support.

Specifications

Feature	Detail
Brand	Jzones
Model Name	CT
Connectivity Technology	Wireless (Bluetooth 5.4)
Noise Control	Adaptive Noise Cancellation
Ear Placement	Open Ear
Form Factor	Open ear
Material	Plastic
Item Weight	3.84 ounces
Water Resistance Level	IPX4 (Waterproof)
Control Type	Touch Control
Bluetooth Range	33 Feet
Carrying Case Battery Average Life	19.5 Hours (additional playtime)
Carrying Case Battery Charging Time	2 Hours
UPC	850070711654

Warranty and Support

For detailed warranty information and customer support, please refer to the official Jzones website or the full User Manual PDF provided with your product. You can also access the PDF version of this manual [here](#).

If you require further assistance, please contact Jzones customer service with your product model number (CT) and purchase details.

© 2025 Jzones. All rights reserved.