

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GalnFu](#) /
- › [GalnFu Queen Size Lift Up Storage Bed with Charging Station Instruction Manual](#)

## GalnFu GalnFu821B3

# GalnFu Queen Size Lift Up Storage Bed with Charging Station Instruction Manual

Model: GalnFu821B3

## 1. INTRODUCTION

---

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your GalnFu Queen Size Lift Up Storage Bed with Charging Station. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The GalnFu lift-up storage bed combines functionality with modern design, offering a spacious under-bed storage compartment, a button-tufted headboard, and an integrated charging station for your convenience.



Image: GalnFu Queen Size Lift Up Storage Bed.

## 2. SAFETY INFORMATION

---

- Always follow assembly instructions carefully.
- Be cautious when using the hydraulic lift system to avoid injury.
- Keep fingers and other body parts away from moving parts during operation of the lift mechanism.
- Ensure all connections are secure before use.
- Do not exceed the maximum weight capacity of 1000 pounds.
- Keep children and pets away from the bed during assembly and when operating the lift mechanism.
- Only use the charging station for compatible devices and avoid overloading.

## 3. PACKAGE CONTENTS

---

Verify that all components listed below are present before beginning assembly. All parts are meticulously packed in one package.

- 1 x Lift Up Bed Frame (Queen Size)
- 1 x Upholstered Wingback Headboard with Charging Station (2 AC outlets, 2 USB ports)
- 1 x Installation Manual
- Installation Tools & Accessories (screws, bolts, Allen wrench, etc.)
- Wooden Slats and Support System
- Hydraulic Lift Mechanism components



Image: Overview of bed frame components highlighting sturdy structure, ease of assembly, and noise-free design.

## 4. SETUP AND ASSEMBLY

Assembly is designed to be straightforward. It is recommended to have two people for certain steps, especially when handling larger components or the hydraulic lift system. Follow the included installation manual for detailed, step-by-step instructions.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided parts list in the separate installation manual.

2. **Assemble Bed Frame:** Connect the side rails, footboard, and headboard according to the manual's diagrams. Ensure all bolts are finger-tightened initially.
3. **Install Wooden Slats:** Secure the wooden slats to the bed frame. The slats are designed for noise-free support and eliminate the need for a box spring.
4. **Attach Hydraulic Lift Mechanism:** Carefully attach the hydraulic lift system to the bed frame. This step may require assistance to ensure proper alignment and safety. Refer to the manual for specific instructions on engaging the hydraulic pistons.
5. **Secure Headboard:** Attach the upholstered headboard to the assembled bed frame.
6. **Final Tightening:** Once all components are in place, systematically tighten all bolts and screws using the provided tools. Do not overtighten.



Images: Details of slat attachment and sturdy frame construction.



Image: Noise-dampening foam detail.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Hydraulic Lift System

The bed features a hydraulic lift mechanism for easy access to the under-bed storage compartment. The maximum lifting capacity is 154 lbs.

- **To Lift:** Grasp the fabric pull handle located at the foot of the bed. With a firm and steady motion, lift the mattress platform upwards. The hydraulic pistons will assist in raising and holding the platform in the open position.
- **To Lower:** Gently pull the mattress platform downwards. Apply steady pressure until the platform fully descends and rests securely on the bed frame. Ensure no objects or body parts are in the path of the descending platform.
- **Protective Device:** The bed frame includes an anti-slip and stopping protective device to ensure the mattress remains securely in place when the bed is lifted or lowered.

## Hydraulic Mechanism

Maximum Lifting Capacity: 154lbs



## Lift up easily

Safety & Labor-Saving

## Protective Device

Anti-Slip & Stopping



Image: Operation of the hydraulic lift system and safety features.



Image: The bed with the mattress lifted, showcasing the under-bed storage.




Image: Anti-slip protective device detail.

## 5.2 Integrated Charging Station

The headboard features a built-in charging station for convenient power access.

- **Power Connection:** Connect the bed's power cord to a standard wall outlet.

- **AC Outlets:** Two 110V/12A AC outlets are provided for powering larger devices.
- **USB Ports:** Two 5V/2A USB ports (1 USB-A and 1 USB-C) are available for charging mobile devices.
- **Usage:** Plug your devices directly into the appropriate outlets or ports. Ensure devices are compatible with the provided power specifications.



Image: Detail of the headboard's charging station.

## 6. MAINTENANCE

- **Cleaning the Fabric:** For general cleaning, gently vacuum the upholstered parts using a soft brush attachment. For spills, blot immediately with a clean, dry cloth. For stubborn stains, consult a professional upholstery cleaner or use a mild fabric cleaner according to its instructions. Avoid harsh chemicals.
- **Frame Care:** Periodically check all bolts and screws to ensure they remain tight. Retighten if necessary. Wipe metal and wooden parts with a damp cloth and dry immediately.
- **Hydraulic System:** The hydraulic pistons are generally maintenance-free. If you notice any issues with lifting or lowering, ensure no obstructions are present. Do not attempt to disassemble the hydraulic components.

- **Charging Station:** Keep the charging ports free of dust and debris. Do not expose the charging station to liquids. If any electrical issues arise, discontinue use and contact customer support.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed squeaks or creaks.	Loose bolts or connections.	Check and tighten all assembly bolts and screws. Ensure slats are properly seated.
Hydraulic lift is difficult to operate.	Obstruction in the mechanism; new pistons may require initial force.	Ensure no items are blocking the lift path. New hydraulic pistons may be stiff initially; apply firm, steady pressure. If problem persists, contact support.
Charging station not working.	Power cord not plugged in; faulty device; power outage.	Verify the bed's power cord is securely plugged into a working wall outlet. Test with a different device. Check household circuit breaker.
Mattress slides on the frame.	Mattress not properly aligned; protective device not engaged.	Ensure the mattress is centered on the frame. Verify the anti-slip protective device is correctly installed at the foot of the bed.

## 8. SPECIFICATIONS

<b>Brand</b>	GalnFu
<b>Model Number</b>	GalnFu821B3
<b>Size</b>	Queen
<b>Color</b>	Beige
<b>Product Dimensions (L x W x H)</b>	85.5" x 63" x 46"
<b>Material</b>	Fabric, Wood, Steel
<b>Maximum Weight Capacity</b>	1000 Pounds
<b>Under-bed Storage Height</b>	10.8 inches
<b>Charging Station</b>	2 AC Outlets (110V/12A), 2 USB Ports (5V/2A - 1 USB-A, 1 USB-C)
<b>Box Spring Required</b>	No
<b>Assembly Required</b>	Yes

# QUEEN SIZE



Highest Storage Height  
(slats to floor)

L \* W \* H

Weight Capacity

10inch

85.5\*63\*46 in

1000lbs

Image: Queen size bed dimensions and specifications summary.



Image: Applicable mattress height range.

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official GalnFu website. Please have your model number (GalnFu821B3) and purchase date available when contacting support.

**GalnFu Store:** [Visit the GalnFu Store on Amazon](#)

© 2025 GalnFu. All rights reserved.

Documents - GalnFu – GalnFu821B3

no relevant documents