Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

InMotion 20W USB-C US Charger

InMotion 20W USB-C US Charger User Manual

Model: 20W USB-C US Charger

1. Introduction

Thank you for choosing the InMotion 20W USB-C US Charger. This manual provides essential information for the safe and efficient use of your charger. Please read it thoroughly before use and retain it for future reference.

Image 1.1: Front view of the InMotion 20W USB-C US Charger, showing the USB-C port and US plug.

2. Safety Information

To ensure safe operation, always follow these basic safety precautions:

- Do not expose the charger to liquids, moisture, or extreme temperatures.
- Do not attempt to disassemble, repair, or modify the charger. This will void the warranty and may cause electric shock or fire.
- Use only with compatible devices and cables.
- Ensure the charger is fully inserted into a wall outlet.
- Unplug the charger during lightning storms or when unused for long periods.
- Keep out of reach of children.

Image 2.1: This charger is designed for use in Canada and the USA, featuring a Type A - 2 pin power plug.

3. Package Contents

The package includes the following items:

- 1 x InMotion 20W USB-C US Charger
- 1 x User Manual (this document)

Note: A USB-C charging cable is required and sold separately.

4. Product Features

The InMotion 20W USB-C US Charger offers the following features:

- **20W Power Delivery:** Provides up to 20 watts of power for fast charging compatible devices.
- **3A Output:** Delivers 3 Amps of current for efficient charging.
- **USB-C Connectivity:** Features a single USB-C port for modern device compatibility.
- **Lightweight Design:** Compact and portable for travel and everyday use.
- **Universal Compatibility:** Compatible with various devices including smartphones, tablets, headphones, smartwatches, and cameras that support USB-C charging.

5. Setup

Follow these steps to set up your InMotion 20W USB-C US Charger:

1. **Unpack:** Carefully remove the charger from its packaging.
2. **Connect Cable:** Obtain a compatible USB-C charging cable (not included). Insert one end of the USB-C cable into the USB-C port on the charger.
3. **Plug into Outlet:** Insert the charger's US plug into a standard 100V AC wall outlet.
4. **Connect Device:** Connect the other end of the USB-C cable to your device (e.g., smartphone, tablet).



Image 5.1: The USB-C port on the InMotion charger, ready for cable connection.

6. Operating Instructions

Once connected, the charger will automatically begin charging your device. The charger is designed for fast charging compatible devices. Charging speed may vary depending on the device, cable, and battery level.

- Ensure your device supports USB-C charging for optimal performance.
- The charger is designed to deliver 20W of power. If your device requires less, it will draw only the necessary power.
- Disconnect your device once it is fully charged to conserve energy.



Image 6.1: Side view of the InMotion charger, illustrating its compact size when plugged into a wall outlet.

7. Maintenance

Proper maintenance ensures the longevity of your charger:

- **Cleaning:** Disconnect the charger from the power outlet before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping or subjecting the charger to strong impacts.

8. Troubleshooting

If you encounter issues with your charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not charging.	Charger not properly plugged in. Faulty USB-C cable. Device not compatible or port is damaged. Power outlet issue.	Ensure the charger is securely plugged into a working wall outlet. Try a different USB-C cable. Test the charger with another compatible device. Try a different power outlet.
Slow charging.	Cable not supporting fast charge. Device not supporting fast charge. High background app usage on device.	Use a high-quality USB-C cable rated for fast charging. Verify your device supports 20W fast charging. Close unnecessary applications on your device during charging.
Charger feels warm.	Normal operation during charging.	This is normal. If it becomes excessively hot or emits smoke/odor, unplug immediately and discontinue use.

9. Specifications

Feature	Detail
Brand	InMotion
Model	20W USB-C US Charger
Connector Type	USB Type C
Compatible Devices	Cameras, Headphones, Smartphones, Smartwatches, Tablets
Input Voltage	100 Volts (AC)
Amperage	3 Amps
Wattage	20 Watts

Feature	Detail
Output Current	3 Amps
Output Voltage	5 Volts
Power Source	Corded Electric
Power Plug	Type A - 2 pin (North American)
Special Feature	Lightweight Design

10. Warranty and Support

For warranty information and customer support, please refer to the official InMotion website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

InMotion Accessories Customer Service:

- Website: InMotion Store on Amazon
- Seller Information: InMotion Accessories Seller Profile

© 2026 InMotion. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F5WX6YXR

More documents and user manuals: **https://manuals.plus/**