

SVAN SL8203AIDV

SVAN SL8203AIDV 8 kg Front Load Washing Machine User Manual

Model: SL8203AIDV

1. INTRODUCTION AND SAFETY INFORMATION

Thank you for choosing the SVAN SL8203AIDV 8 kg Front Load Washing Machine. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your appliance. Please read this manual thoroughly before using the washing machine and keep it for future reference.

1.1 General Safety Warnings

- Ensure the washing machine is properly installed by a qualified technician before first use.
- Do not allow children to play with or operate the appliance.
- Keep packaging materials out of reach of children.
- Do not touch the power plug with wet hands.
- Unplug the appliance before cleaning or performing any maintenance.
- Do not wash items that have been cleaned in, washed in, soaked in, or spotted with combustible or explosive substances.
- Always close the water tap after use to prevent leaks.

2. PRODUCT OVERVIEW

The SVAN SL8203AIDV is an 8 kg front-load washing machine designed for efficient and quiet operation. It features an Inverter Motor, 1200 rpm spin speed, and an A-class energy efficiency rating. The appliance includes a transparent XXL door and a durable stainless steel diamond drum for optimal fabric care.



Figure 2.1: Front view of the SVAN SL8203AIDV washing machine. This image shows the appliance's white exterior, large black circular door, and the control panel located at the top.



Figure 2.2: Close-up of the SVAN SL8203AIDV control panel. The panel features a central program selection knob, a digital LED display, and touch buttons for Speed, Temperature, Rinse+, and Start/Pause. Program options include Spin, Rinse & Spin, Steam, Delicates, Synthetics, Drum Clean, Mixed, Eco 40-60, Cotton 20°C, Quick 30', and Quick 15'.




Figure 2.3: Energy efficiency label for the SVAN SL8203AIDV washing machine. This label indicates an 'A' energy class rating, 47 kWh per 100 cycles, 8.0 kg capacity, a 3:38 hour cycle duration, 40 liters of water consumption, and a noise level of 72 dB.

3. SETUP AND INSTALLATION

3.1 Unpacking

- Carefully remove all packaging materials.
- Inspect the appliance for any damage during transit. Contact your retailer immediately if damage is found.
- Remove the transport bolts located at the rear of the machine. These bolts secure the drum during transport and **must be removed** before operation to prevent damage. Keep the bolts for future transport.

3.2 Location Requirements

- Place the washing machine on a firm, level floor.

- Ensure there is adequate space around the machine for ventilation and maintenance.
- Avoid direct sunlight or extreme temperatures.

3.3 Water Connection

- Connect the inlet hose to a cold water tap with a 3/4-inch thread.
- Ensure all connections are tight to prevent leaks.

3.4 Drain Connection

- Position the drain hose into a standpipe or over the edge of a sink, ensuring it is securely fastened to prevent dislodging.
- The drain hose should be positioned at a height between 60 cm and 100 cm from the floor.

3.5 Electrical Connection

- Plug the power cord into a grounded electrical outlet.
- Ensure the voltage and frequency match the specifications on the rating plate of the appliance.

3.6 Leveling the Machine

- Adjust the leveling feet at the bottom of the machine until it is perfectly stable and level.
- Use a spirit level to verify. Proper leveling reduces vibration and noise during operation.

4. OPERATING INSTRUCTIONS

4.1 Before Each Wash

- Sort laundry by fabric type, color, and degree of soiling.
- Check pockets for small items like coins or keys.
- Close zippers and fasten hooks.

4.2 Loading Laundry

- Open the washing machine door.
- Load laundry loosely into the drum, ensuring not to overload. An 8 kg capacity means approximately 8 kg of dry laundry.
- Close the door firmly until it clicks.

4.3 Adding Detergent and Additives

- Pull out the detergent dispenser drawer.
- Add the appropriate amount of detergent to the main wash compartment.
- Add fabric softener or other additives to their respective compartments if desired.
- Push the dispenser drawer back in completely.

4.4 Selecting a Program

- Turn the central program selection knob (refer to Figure 2.2) to choose one of the 11 available programs:
 - **Spin:** For draining water and spinning clothes.

- **Rinse & Spin:** For an extra rinse cycle followed by spinning.
- **Steam:** For steam-assisted washing or refreshing.
- **Delicates:** Gentle wash for delicate fabrics.
- **Synthetics:** For synthetic and mixed fabrics.
- **Drum Clean:** Special program for cleaning the washing machine drum.
- **Mixed:** For mixed loads of cotton and synthetics.
- **Eco 40-60:** Energy-efficient program for cotton items normally washable at 40°C or 60°C.
- **Cotton 20°C:** Low-temperature wash for cotton.
- **Quick 30':** A fast 30-minute wash cycle.
- **Quick 15':** An even faster 15-minute wash cycle for lightly soiled items.

4.5 Adjusting Settings

- After selecting a program, use the touch buttons on the control panel to adjust settings such as:
 - **Speed:** Adjust spin speed (up to 1200 rpm).
 - **Temperature:** Modify wash temperature.
 - **Rinse+:** Add an extra rinse cycle.

4.6 Starting and Pausing a Cycle

- Press the **Start/Pause** button to begin the selected wash cycle.
- To pause a running cycle, press the **Start/Pause** button again. Press it once more to resume.
- The 'Stop&Go' function allows you to add forgotten items during the initial stages of a cycle.

4.7 Ending a Cycle

- The machine will signal the end of the cycle.
- Open the door and remove your laundry promptly to prevent wrinkles.
- Leave the door slightly ajar to allow the drum to air dry.

5. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

5.1 Cleaning the Detergent Dispenser

- Pull out the dispenser drawer completely.
- Remove any residue from the compartments using warm water and a brush.
- Rinse thoroughly and reinsert the drawer.

5.2 Cleaning the Drum

- Use the dedicated 'Drum Clean' program periodically to remove detergent residue and odors.
- For manual cleaning, wipe the inside of the drum with a damp cloth.

5.3 Cleaning the Filter

- Locate the drain pump filter, usually at the bottom front of the machine.
- Place a shallow container underneath to catch any residual water.

- Carefully unscrew and remove the filter.
- Clean any lint, debris, or foreign objects from the filter.
- Rinse the filter under running water and screw it back in securely.

5.4 Cleaning the Exterior

- Wipe the exterior surfaces with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.

6. TROUBLESHOOTING

Before contacting customer service, please refer to the following common issues and their solutions:

Problem	Possible Cause	Solution
Machine does not start	No power; Door not closed; Start/Pause not pressed	Check power supply; Ensure door is latched; Press Start/Pause button
Water not filling	Water tap closed; Inlet hose kinked; Water pressure too low	Open water tap; Straighten hose; Check water supply
Water not draining	Drain hose kinked or blocked; Drain pump filter clogged	Straighten hose; Clean drain pump filter (see Section 5.3)
Excessive vibration/noise	Transport bolts not removed; Machine not level; Overloaded drum	Remove transport bolts; Adjust leveling feet; Reduce laundry load
Detergent residue in dispenser	Insufficient water pressure; Clogged dispenser	Check water pressure; Clean detergent dispenser (see Section 5.1)

7. SPECIFICATIONS

Brand	SVAN
Model Number	SL8203AIDV
Type	Front Load Washing Machine
Capacity	8 kg
Maximum Spin Speed	1200 RPM
Motor Type	Inverter Motor
Energy Efficiency Class	A
Noise Level (Spin)	72 dB
Number of Programs	11

Dimensions (D x W x H)	45 x 59.8 x 84.5 cm
Product Weight	52 kg
Color	White
Included Components	Washing machine, Instruction Manual


8. WARRANTY AND SUPPORT

Your SVAN SL8203AIDV washing machine comes with a manufacturer's warranty. Please refer to the warranty card provided with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, spare parts, or to schedule a service appointment, please contact SVAN customer support. Ensure you have your model number (SL8203AIDV) and purchase date available when contacting support.

© 2025 SVAN. All rights reserved.

Related Documents - SL8203AIDV


	<p>Manual de Usuario Svan Lavadora Automática: Modelos SL6203AIDV, SL8203AIDV, SL10400AIDV</p> <p>Guía completa para la instalación, uso seguro y mantenimiento de las lavadoras automáticas Svan, incluyendo los modelos SL6203AIDV, SL8203AIDV y SL10400AIDV. Aprenda a operar su electrodoméstico de manera eficiente.</p>
	<p>Svan SLCS6201C Manual de Usuario: Guía Completa para tu Lavadora de Carga Superior</p> <p>Descubre el manual de usuario completo para la lavadora Svan SLCS6201C. Incluye instrucciones de instalación, operación, seguridad y mantenimiento para tu lavadora de carga superior.</p>
	<p>Svan SL9401AIDB Washing Machine User Manual</p> <p>Comprehensive user manual for the Svan SL9401AIDB washing machine, covering safety instructions, installation, operation, maintenance, and troubleshooting for optimal use.</p>

	<p>Svan SL6001DD Washing Machine User Manual</p> <p>Comprehensive user manual for the Svan SL6001DD washing machine, covering safety, installation, operation, maintenance, and troubleshooting.</p>
	<p>Svan SL8401AIDVBX Washing Machine User Manual</p> <p>Comprehensive user manual for the Svan SL8401AIDVBX washing machine, covering safety information, installation, operation, maintenance, and troubleshooting.</p>
	<p>Svan SF1675500ENF User Manual: Installation, Operation, and Safety Guide</p> <p>Comprehensive user manual for the Svan SF1675500ENF refrigerator. Includes installation instructions, operating guidelines, safety warnings, and troubleshooting tips.</p>

Documents - SVAN – SL8203AIDV

svan

Automatic Drum Washing Machine
OWNER'S MANUAL



Model: SL6203AIDV
SL8203AIDV
SL10400AIDV

Thank you for choosing our Washing Machine.
It is essential to read this manual carefully before it is installed and used for the first time.

[\[pdf\]](#) User Manual

Automatic Drum Washing Machine PIM SvanSL6203AIDV SL8203AIDV SL10400AIDV info@svanelectro 960600034 Page 6 3 Do not climb onto the washing machine or place items on it to avoid falling and Manual Usuario 2pim gruposvan 7005 multimedia Manual 2 |||

Automatic Drum Washing Machine Model: SL6203AIDV **SL8203AIDV** SL10400AIDV Safety notices 1 4 5 8 13 15 17 Parameters 19 28 . If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. 1 Repairs sh...

lang:en **score:34** filesize: 25.16 M page_count: 33 document date: 2025-04-16

svan

Lavatrice automatica a tamburo
MANUALE D'USO



Modello: SL6203AIDV
SL8203AIDV
SL10400AIDV

Guida per uso e manutenzione
È essenziale leggere attentamente questo manuale prima dell'installazione e del primo utilizzo.

[\[pdf\]](#) User Manual

DAGdvF5 L8k BAE3UM2GUiK 0 Lavatrice automatica a tamburo MANUALE D USO PIM Per le lavatrici dotate di prese d aria alla base non L illustrazione della lavatrice nel manuale è utilizzata esclusivamente scopo illustrativo Manual Usuario 5 pim gruposvan 7005 multimedia SL8203AIDV |||

Lavatrice automatica a tamburo MANUALE D USO Modello:: SL6203AIDV **SL8203AIDV** SL10400AIDV Grazie per aver scelto la nostra lavatrice. essenziale leggere attentamente questo manuale prima dell'installazione e del primo utilizzo. PREFAZIONE Questa lavatrice conforme ai requisiti di sicurezza attual...

lang:it **score:28** filesize: 1.93 M page_count: 36 document date: 2025-04-16

svan

Lavadora automática
MANUAL DE USUARIO



Modelo: SL6203AIDV
SL8203AIDV
SL10400AIDV

Le agradecemos por elegir nuestra lavadora.
Es fundamental que lea atentamente el presente manual antes de instalar y utilizar el equipo por primera vez.

[\[pdf\] User Manual](#)

manualLAVADORA SVAN SL6203AIDV 6KG 1200RPM A INVERTERv1comercialprieto WebRoot Store

Shops ComercialPrieto 6850 0E56 3D99 E809 1D58 0A6E 2802 01F7 DOCS manual |||

Lavadora autom tica MANUAL DE USUARIO Modelo: SL6203AIDV **SL8203AIDV**


SL10400AIDV Le agradecemos por elegir nuestra lavadora. Es fundamental que lea atentamente el presente manual antes de instalar y utilizar el equipo por primera vez.

PREFACIO Esta lavadora cumple con los requisitos vigentes en ma...

lang:es score:24 filesize: 151.86 M page_count: 33 document date: 2025-04-16

svan

Machine à laver automatique à tambour
MANUEL D'UTILISATION



Modèle: SL6203AIDV
SL8203AIDV
SL10400AIDV

Manuel d'utilisation pour machine à laver.

[\[pdf\] User Manual](#)

DAGdip3Ldul BAE3UM2GUILk 0 Machine à laver automatique tambour MANUEL D UTILISATION

PRÉFACE Cette machine est conforme aux exigences de sécurité actuelles Cependant une utilisation inappropriée peut entraîner Manual Usuario 4 pim gruposvan 7005 multimedia SL8203AIDV |||


Machine laver automatique tambour MANUEL D UTILISATION Modle : SL6203AIDV

SL8203AIDV SL10400AIDV Merci d avoir choisi notre machine laver. Il est essentiel de lire attentivement ce manuel avant l installation et la premire utilisation. PRFACE PRFACE Cette machine laver est conforme aux exigenc...

lang:fr score:23 filesize: 1.97 M page_count: 36 document date: 2025-04-16

svan

Lavadora automática
MANUAL DE USUARIO



Modelo: SL6203AIDV
SL8203AIDV
SL10400AIDV

Le agradecemos por elegir nuestra lavadora.
Es fundamental que lea atentamente el presente manual antes de instalar y utilizar el equipo por primera vez.

[Manual de Usuario Svan Lavadora Automática: Modelos SL6203AIDV, SL8203AIDV, SL10400AIDV](#)

Guía completa para la instalación, uso seguro y mantenimiento de las lavadoras automáticas Svan, incluyendo los modelos SL6203AIDV, SL8203AIDV y SL10400AIDV. Aprenda a operar su electrodoméstico de manera eficiente.

lang:es score:21 filesize: 2.08 M page_count: 33 document date: 2025-08-05