

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AIKE](#) /

› [AIKE Wall Mount Liquid Soap Dispenser AK1008 Instruction Manual](#)

## AIKE AK1008

# AIKE Wall Mount Liquid Soap Dispenser

MODEL: AK1008

## 1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your AIKE Wall Mount Liquid Soap Dispenser, Model AK1008. Please read this manual thoroughly before use to ensure proper function and longevity of the product.

The AIKE AK1008 is a durable, large-capacity liquid soap dispenser designed for commercial and home bathroom environments. It features a 27oz (800ml) refillable tank and offers dual installation options.

## 2. IMPORTANT SAFETY INFORMATION

- **Compatibility:** This dispenser is designed exclusively for standard liquid hand soap. It is **not suitable** for gel, foaming, granular, or exfoliating soaps. Using incompatible liquids may cause damage or malfunction.
- **Installation:** Ensure the dispenser is securely mounted according to the instructions to prevent it from falling and causing injury or damage.
- **Cleaning:** Do not use abrasive cleaners or solvents on the dispenser's surface. Clean with a soft, damp cloth.
- **Children:** Keep out of reach of small children to prevent misuse or accidental ingestion of soap.

## 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- AIKE Wall Mount Liquid Soap Dispenser (1 unit)
- Key (1 unit)
- User Manual (1 unit)
- Screws (4 units)
- Expansion Anchors (4 units)
- Nail-Free Sticker (1 unit)



## Packing List

Key X 1	Screw X 4
User Manual X 1	Nail-Free Sticker X 1
Soap Dispenser X 1	Expansion Anchor X 4

*Image 3.1: Package contents and product dimensions.*

**Text Description for Image 3.1:** This image displays the AIKE AK1008 soap dispenser along with its dimensions (9.06" H x 4.72" L x 3.15" W) and a list of included accessories: 1 Key, 1 User Manual, 1 Soap Dispenser, 4 Screws, 4 Expansion Anchors, and 1 Nail-Free Sticker.

## 4. SETUP AND INSTALLATION

The AIKE AK1008 dispenser offers two installation methods: drilled installation for maximum security and adhesive installation for convenience on suitable surfaces.

# SCREW INSTALLATION

Suitable for most wall types



# STICKER INSTALLATION

Only suit for smooth, dry and flat walls



Image 4.1: Illustration of screw and sticker installation methods.

**Text Description for Image 4.1:** This image shows two installation methods. The top section illustrates 'Screw Installation' with four screws and four yellow expansion anchors, indicating suitability for most wall types. The bottom section illustrates 'Sticker Installation' where a hand presses the dispenser onto a wall with a white adhesive pad, noting it's only suitable for smooth, dry, and flat walls.

## 4.1 Drilled Installation (Recommended for maximum stability)

- Select Location:** Choose a suitable wall location, ensuring it is clear of electrical wires or plumbing.
- Mark Holes:** Hold the dispenser against the wall at the desired height. Use a pencil to mark the positions for the four screw holes on the back plate.
- Drill Holes:** Using an appropriate drill bit for your wall type, drill holes at the marked positions. Insert the expansion anchors into the drilled holes.
- Mount Dispenser:** Align the dispenser's screw holes with the anchors. Insert and tighten the screws to secure the dispenser firmly to the wall.

## 4.2 Adhesive Installation (For flat, solid, and smooth wall surfaces)

- Prepare Surface:** Ensure the wall surface is clean, dry, flat, and free from dust, oil, or peeling paint. Avoid cleaning walls with water, alcohol, or other liquids before applying the sticker.
- Apply Sticker:** Peel the protective film from the back of the nail-free sticker. Carefully align and press

the sticker firmly onto the chosen wall location.

- 3. Attach Dispenser:** Align the dispenser with the sticker and press it firmly onto the adhesive. Apply pressure for several seconds to ensure a strong bond.
- 4. Wait:** Allow the adhesive to cure for at least 24-48 hours before filling the dispenser with soap to ensure maximum adhesion.

## 5. OPERATING INSTRUCTIONS

### 5.1 Filling the Dispenser



Image 5.1: Internal view showing refillable tank and double-lock system.

**Text Description for Image 5.1:** This image provides an internal view of the AIKE AK1008 dispenser. It highlights the 27oz / 800ml refillable tank, which is removable for easy refilling. It also points out the durable commercial ABS construction and the double-lock system, which allows unlocking with a key or by pressing.

- 1. Unlock:** Use the provided key to unlock the top cover, or press the designated button if the key is not used.
- 2. Open Cover:** Lift the top cover to access the internal soap reservoir.
- 3. Fill Reservoir:** Carefully pour liquid hand soap into the reservoir. Do not overfill.

4. **Close and Lock:** Close the top cover securely. If using the key, lock it to prevent tampering.

## 5.2 Dispensing Soap



*Image 5.2: Dispensing soap using the extended pump.*

**Text Description for Image 5.2:** This image shows a hand pressing the extended pump of the AIKE AK1008 soap dispenser, illustrating the 'Easy Push' mechanism. Liquid soap is being dispensed into the palm of the hand. The image also highlights the side profile of the dispenser, emphasizing the extended pump design.

Place your hand under the dispenser's nozzle. Press the extended pump lever firmly to dispense a measured amount of liquid soap. Release the lever to stop dispensing.

## 6. MAINTENANCE

### 6.1 Cleaning

- Wipe the exterior of the dispenser regularly with a soft, damp cloth and mild soap solution.
- Do not use harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the finish.
- Periodically clean the nozzle to prevent clogs.

### 6.2 Refilling

Refill the dispenser when the soap level is low, following the steps outlined in Section 5.1. The transparent window allows for easy monitoring of soap levels.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Soap not dispensing	Reservoir empty; Soap too thick/incompatible; Nozzle clogged; Pump not primed.	Refill reservoir; Use standard liquid soap; Clean nozzle; Press pump repeatedly until soap dispenses.
Dispenser falling off wall (adhesive install)	Surface not clean/smooth; Adhesive not cured; Overloaded.	Re-install on a clean, smooth surface; Allow 24-48 hours for adhesive to cure; Consider drilled installation for heavy use.
Leaking from nozzle	Soap too thin; Internal seal issue.	Ensure appropriate liquid soap consistency; Contact customer support if problem persists.

## 8. SPECIFICATIONS

- Model:** AK1008
- Color:** Silver
- Material:** Commercial-grade ABS Plastic
- Product Dimensions:** 4.72" L x 3.15" W x 9.06" H (12cm L x 8cm W x 23cm H)
- Liquid Volume Capacity:** 27 oz (800 Milliliters)
- Installation Type:** Wall Mount (Drilled or Adhesive)
- Item Weight:** 1.34 pounds


## 9. WARRANTY AND SUPPORT


The AIKE AK1008 Wall Mount Liquid Soap Dispenser comes with a one-year manufacturer warranty.

For support, warranty claims, or any questions regarding your product, please contact AIKE customer service via Amazon message or through our official support email. We value your experience and are ready to assist you.

© 2025 AIKE. All rights reserved.

## Related Documents - AK1008

	<a href="#"><u>AIKE AK1333 Automatic Soap Dispenser User Manual and Specifications</u></a> Detailed user manual and specifications for the AIKE AK1333 Automatic Sensor Soap Dispenser, including how to use, warnings, packing list, and liquid adjustment features.
--	--

	<p><a href="#"><b>AIKE AK1205 Automatic Soap Dispenser User Manual</b></a></p> <p>User manual for the AIKE AK1205 Automatic Soap Dispenser. Provides detailed instructions on installation, operation, liquid adjustment, battery management, troubleshooting, and specifications for the AIKE automatic soap dispenser.</p>
	<p><a href="#"><b>AIKE AK1335 Automatic Soap Dispenser User Manual</b></a></p> <p>User manual for the AIKE AK1335 automatic soap dispenser, detailing specifications, operation, charging, and maintenance. Learn how to use and care for your AIKE dispenser.</p>
	<p><a href="#"><b>AIKE AK1333 Automatic Soap Dispenser User Guide</b></a></p> <p>Official user guide for the AIKE AK1333 automatic soap dispenser. Learn how to use, charge, and maintain your dispenser for optimal performance. Includes instructions on operation, charging, and cleaning.</p>
	<p><a href="#"><b>AIKE AK1205 Automatic Soap Dispenser User Guide</b></a></p> <p>This document provides a user guide for the AIKE AK1205 Automatic Soap Dispenser, covering packing list, installation instructions, usage guidelines, and battery replacement reminders in multiple languages.</p>
	<p><a href="#"><b>AIKE AK2630 Air Hand Dryer User Manual</b></a></p> <p>User manual for the AIKE AK2630 Air Hand Dryer, covering installation, testing, daily use, maintenance, specifications, and safety precautions.</p>