

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [pTron](#) /

› [pTron Bassbuds Spark TWS Earbuds User Manual](#)

pTron Bassbuds

pTron Bassbuds Spark TWS Earbuds User Manual

Model: Bassbuds



PRODUCT OVERVIEW

The pTron Bassbuds Spark are in-ear True Wireless Stereo (TWS) earbuds designed for immersive audio experiences and clear communication. They feature a lightweight, ergonomic design and offer extended playtime, making them suitable for daily use, travel, and fitness activities.



Image: pTron Bassbuds Spark TWS Earbuds and their charging case, displayed in black.

Key Features:

- **Immersive Stereo Sound:** Equipped with 13mm Dynamic Drivers for rich audio.
- **Extended Playtime:** Up to 40 hours of non-stop playtime with the charging case.
- **Clear Call Quality:** Features a built-in HD microphone for clear stereo calls.
- **Bluetooth V5.3 Connectivity:** Ensures quick pairing and stable wireless connection.
- **Smart Touch Controls:** Manage music and calls directly from the earbuds.
- **Voice Assistant Support:** Instant access to your device's voice assistant.
- **IPX5 Water/Sweatproof:** Designed to withstand splashes and sweat.
- **Type-C Charging:** Convenient and fast charging for the case.
- **Stereo & Mono Bud Capability:** Use both earbuds for stereo sound or a single earbud for mono listening.

PACKAGE CONTENTS

Upon opening the package, ensure all the following items are present:

- pTron Bassbuds Spark TWS Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual
- S/M/L Soft Silicone Eartips

SETUP GUIDE

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case, ensuring they are correctly seated. Connect the Type-C charging cable to the charging port on the case and the other end to a USB power source.

- The charging time for a full charge is approximately 1.5 hours.
- The LED indicator on the case will show charging status.

Voice Assistant



Type-C Fast Charging



Image: The pTron Bassbuds Spark charging case with a Type-C charging cable connected, illustrating the fast charging capability.

2. Pairing with Your Device

The earbuds will automatically enter pairing mode when taken out of the charging case.

1. Open the charging case and remove both earbuds. They will automatically power on and attempt to connect to each other.
2. On your smartphone, tablet, or laptop, enable Bluetooth.
3. Search for new devices in your Bluetooth settings.
4. Select "pTron Bassbuds Spark" from the list of available devices.
5. Once connected, you will hear a confirmation tone, and the earbuds' LED indicators will change.

The earbuds support Bluetooth V5.3 for a stable and efficient connection up to 10 meters.

Bluetooth 5.3 Connectivity



Image: pTron Bassbuds Spark earbuds and their case positioned next to a laptop, highlighting Bluetooth 5.3 connectivity.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Remove earbuds from the charging case. They will power on automatically.
- **Power Off:** Place earbuds back into the charging case. They will power off automatically and begin charging.

Touch Controls

The pTron Bassbuds Spark feature intuitive touch controls on each earbud. The specific functions may vary slightly based on the number of taps or duration of touch.

Action	Function
--------	----------

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (Left/Right)	Reject Call

Making and Receiving Calls

The built-in HD microphone ensures clear call quality. Use the touch controls as described above to manage calls.



Image: A man wearing a pTron Bassbuds Spark earbud, demonstrating the clear call quality provided by the built-in HD microphone and in-ear design that blocks external noise.

Voice Assistant

Triple tap either earbud to activate your device's voice assistant (e.g., Google Assistant, Siri). This allows for hands-free control and information retrieval.

Stereo and Mono Mode

The Bassbuds Spark can be used in either stereo mode (both earbuds) or mono mode (single earbud). Simply remove one earbud from the case to use it independently. The other earbud can remain in the case or be used later to switch back to stereo mode.




Image: Two pTron Bassbuds Spark earbuds shown separately, highlighting their ability to function in both stereo and mono modes.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your pTron Bassbuds Spark earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.

- **Eartips:** Remove and clean the silicone eartips periodically with water and mild soap. Ensure they are completely dry before reattaching.
- **Water Resistance:** The earbuds are IPX5 water/sweatproof, meaning they can resist a sustained, low-pressure water jet spray. Do not submerge them in water or expose them to heavy rain. Dry them thoroughly if they get wet.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.



Image: A pTron Bassbuds Spark earbud with water splashing around it, demonstrating its IPX5 water/sweatproof rating.

TROUBLESHOOTING

If you encounter issues with your pTron Bassbuds Spark, refer to the following common solutions:

- **Earbuds not pairing with each other:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and remove them. They should automatically re-pair.
- **Earbuds not connecting to device:**

- a. Ensure Bluetooth is enabled on your device.
- b. Forget "pTron Bassbuds Spark" from your device's Bluetooth settings and try pairing again.
- c. Ensure earbuds are charged.

- **No sound or low volume:**

- a. Check the volume level on both your device and the earbuds.
- b. Ensure earbuds are properly seated in your ears.
- c. Clean any debris from the earbud speakers.

- **Charging issues:**

- a. Ensure the charging cable is securely connected to both the case and the power source.
- b. Try a different charging cable or power adapter.
- c. Ensure the charging contacts on the earbuds and inside the case are clean and free of obstruction.

SPECIFICATIONS

Detailed technical specifications for the pTron Bassbuds Spark TWS Earbuds:

Feature	Detail
Model Name	Bassbuds
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	10 Metres
Audio Driver Type	Dynamic Driver
Audio Driver Size	13 Millimetres
Battery Life	40 Hours (with charging case)
Charging Time	1.5 Hours
Control Method	Touch
Water Resistance Level	IPX5 (Water Resistant)
Item Weight	40 Grams
Material	Acrylonitrile Butadiene Styrene (ABS), Silicone
Product Dimensions	5 x 7 x 2.7 cm
Ear Placement	In Ear
Form Factor	In Ear
Impedance	32 Ohm
Noise Control	Sound Isolation

WARRANTY AND SUPPORT

Your pTron Bassbuds Spark earbuds come with a manufacturer's warranty and dedicated customer support.

- **Warranty:** 6 months manufacturer warranty from the date of purchase on manufacturing defects only.
- **Customer Support:** For any queries, assistance, or warranty claims, please contact pTron customer care.
- **Email:** support@ptron.in
- **Phone:** 040-67138888

© 2025 pTron. All rights reserved.