

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Outsunny](#) /

› [Outsunny 9FT Patio Umbrella User Manual - Model 84D-397V00CG](#)

Outsunny 84D-397V00CG

Outsunny 9FT Patio Umbrella User Manual

MODEL: 84D-397V00CG

1. Introduction and Safety Information

Thank you for choosing the Outsunny 9FT Patio Umbrella. This manual provides essential instructions for the safe assembly, operation, and maintenance of your umbrella. Please read it thoroughly before use and retain it for future reference.

Important Safety Warnings:

- **Base Not Included:** A suitable weighted umbrella base is required for stability and is not supplied with this product. Ensure the umbrella is securely anchored in a compatible base (e.g., Outsunny Base SKUs: 84D-068, 84D-167, 84D-213V00BK, 84D-248V00LG).
- **Weather Conditions:** Do not use the umbrella during extreme weather conditions such as strong winds, heavy rain, or snow. High winds can cause damage to the umbrella and pose a safety risk. Always close and secure the umbrella when not in use or during adverse weather.
- **Assembly:** Ensure all parts are correctly assembled and tightened before use. Improper assembly can lead to instability and potential injury.
- **Clearance:** Maintain adequate clearance around the umbrella to prevent obstruction or damage when opening and tilting.
- **Children and Pets:** Keep children and pets away from the umbrella during operation to prevent accidents.

2. Package Contents

Verify that all components listed below are present in your package. If any parts are missing or damaged, please contact customer support before proceeding with assembly.

- 1 x Umbrella Canopy with 8 Ribs
- 1 x Umbrella Pole (Upper Section)
- 1 x Umbrella Pole (Lower Section) with Hand Crank
- 1 x Push Button Tilt Mechanism (integrated)
- 1 x Wind Vent (integrated into canopy)

- 1 x User Manual



Image: The Outsunny 9FT Patio Umbrella in Charcoal Gray, fully assembled and providing shade over an outdoor seating area. This image illustrates the complete product and its components.

3. Setup and Assembly

Follow these steps to assemble your patio umbrella. It is recommended to have two people for easier assembly.

1. **Prepare the Base:** Place your compatible weighted umbrella base (not included) in the desired outdoor location. Ensure the base is stable and on a flat surface.
2. **Assemble the Pole:** Carefully insert the lower section of the umbrella pole (with the hand crank) into the upper section of the pole. Ensure the connection is secure and the locking pin (if present) engages.
3. **Insert into Base:** Insert the assembled umbrella pole into the center hole of your umbrella base. Tighten any securing knobs on the base to hold the pole firmly in place.
4. **Attach Canopy:** The canopy with its ribs is pre-attached to the upper pole section. Ensure all ribs are properly aligned.

5. **Open the Umbrella:** Slowly turn the hand crank clockwise to extend the canopy until it is fully open. Do not force the crank if resistance is met.



Image: An Outsunny 9FT Patio Umbrella providing shade for two individuals relaxing in an outdoor setting. This image demonstrates the umbrella in its intended use, highlighting its size and coverage.

4. Operating Instructions

Opening and Closing the Umbrella:

- **To Open:** Turn the hand crank clockwise until the canopy is fully extended and taut.
- **To Close:** Turn the hand crank counter-clockwise until the canopy is fully retracted. Secure the canopy with any attached ties to prevent it from unfurling in the wind.



Image: A detailed view of the manual crank mechanism located on the umbrella pole, used for opening and closing the canopy. This shows the ease of operation for adjusting the umbrella.

Tilting the Canopy:

The umbrella features a push-button tilt mechanism to adjust the canopy angle, providing optimal shade as the sun moves.

- **To Tilt:** Locate the push button on the umbrella pole, typically above the crank mechanism. Press and hold the button, then gently push the canopy in the desired direction to tilt it.
- **To Return to Upright:** Press and hold the push button again and gently push the canopy back to its vertical position. Release the button to lock it in place.



Image: An illustration demonstrating the push-button tilt feature of the umbrella, showing how to adjust the canopy angle for sun protection. This highlights the flexibility of the umbrella's design.

Wind Vent Feature:

The umbrella canopy includes a vented top designed to allow air to circulate, reducing wind pressure and enhancing stability in light breezes. This feature also helps dissipate heat, keeping the area underneath cooler.



Image: A top-down view of the umbrella canopy, clearly showing the integrated wind vent at the apex. Arrows indicate airflow, illustrating how the vent reduces wind stress and improves air circulation.

5. Maintenance

Proper maintenance will extend the life and appearance of your Outsunny patio umbrella.

- **Cleaning the Canopy:** Wipe the polyester canopy with a damp cloth to remove dirt and debris. For stubborn stains, use a mild soap solution and rinse thoroughly. Allow the canopy to air dry completely before closing or storing. Do not use harsh chemicals or abrasive cleaners.
- **Frame Care:** Periodically inspect the metal frame and ribs for any signs of rust or damage. Clean the metal components with a damp cloth and dry thoroughly. Apply a rust-inhibiting spray if necessary.
- **Storage:** When not in use for extended periods or during off-season, close the umbrella, secure it with ties, and store it in a dry, protected area. A protective cover (not included) is recommended to shield it from dust, dirt, and harsh weather.
- **Lubrication:** Occasionally apply a silicone-based lubricant to the crank mechanism and tilt joint to ensure smooth operation.

6. Troubleshooting

If you encounter issues with your umbrella, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Umbrella does not open or close smoothly.	Crank mechanism is stiff or obstructed.	Apply a silicone-based lubricant to the crank mechanism. Check for any debris or fabric caught in the mechanism.
Umbrella is unstable or wobbles.	Base is not heavy enough or pole is not secured.	Ensure the umbrella base is adequately weighted for the umbrella size. Tighten all securing knobs on the base. Verify the pole sections are fully engaged.
Canopy does not tilt.	Push button not fully depressed or mechanism is stiff.	Ensure the push button is fully pressed. Apply lubricant to the tilt joint if it feels stiff. Do not force the tilt.
Canopy appears faded or stained.	Exposure to sun and elements, dirt accumulation.	Clean the canopy regularly with a damp cloth and mild soap. Store the umbrella with a protective cover when not in use.

7. Specifications

Detailed specifications for your Outsunny 9FT Patio Umbrella, Model 84D-397V00CG.

- **Model Number:** 84D-397V00CG
- **Overall Dimensions:** Φ 8.8' x 7.8' H (105.9 inches diameter x 93.7 inches height)
- **Canopy Diameter:** 105.9 inches
- **Umbrella Pole Diameter:** 1.5 inches
- **Weight:** Approximately 14 Pounds
- **Canopy Material:** 100% Polyester with PU coating
- **Frame Material:** Metal (Steel)
- **Ribs:** 8 Steel Ribs
- **UV Protection:** UPF 30+ (Blocks 97% of harmful rays)
- **Opening Mechanism:** Manual Crank Lift
- **Tilt Mechanism:** Push Button Manual Tilt
- **Special Features:** Fade Resistant, Splash Resistant, UV Resistant, Vented Canopy
- **Color:** Charcoal Gray




Image: A diagram illustrating the key dimensions of the patio umbrella, including canopy diameter and overall height. This provides a visual reference for the product's size.



Image: A close-up view of the underside of the umbrella canopy, highlighting the eight robust ribs that provide strong support and stability to the structure.

8. Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact the manufacturer, Aosom LLC, or the seller directly. Please have your model number (84D-397V00CG) and purchase date available when contacting support.

Manufacturer: Aosom LLC

Brand: Outsunny