

**B0F62RKMHB**

# Generic 6-in-1 Selfie Stick with Fill Light (Model B0F62RKMHB) User Manual

Your comprehensive guide to setup, operation, and maintenance.

## INTRODUCTION

Thank you for choosing the Generic 6-in-1 Selfie Stick with Fill Light. This versatile device combines a selfie stick, tripod, and dual fill lights with a wireless Bluetooth remote, designed to enhance your photography and videography experience. Its compact and lightweight design makes it ideal for travel and on-the-go content creation. Please read this manual carefully to ensure proper use and optimal performance.

## “Product Hero” - What it is

### 6-in-1 Professional Selfie Stick

Integrated design with dual fill lights, tripod, and Bluetooth remote for all your creative needs.



The 6-in-1 Selfie Stick with Fill Light, showcasing its integrated design with dual fill lights, tripod, and Bluetooth remote.

# reinforce Tripod support



Key features of the selfie stick, including its tripod function, portability, remote control, lighting options, and shooting versatility.

## Compact & Travel Ready - Portability



Lightweight aluminum alloy design folds easily into your bag. Your perfect travel companion.

The selfie stick's compact design, making it travel-ready and easy to carry.

## WHAT'S IN THE BOX

Upon opening the package, please ensure all items are present and in good condition:

- 1PC\* Selfie Stick Set

## SETUP GUIDE

### 1. Unfolding the Selfie Stick/Tripod:

Gently pull the top section upwards to extend the selfie stick. To use as a tripod, spread the base legs outwards until they form a stable triangular support. Ensure the legs are fully extended for maximum stability.



Reinforced tripod support with anti-slip pads for stability.

### 2. Mounting Your Device:

Open the phone clamp at the top of the stick. Carefully insert your smartphone, camera, or GoPro into the clamp, ensuring it is securely held. The universal clamp is designed to fit various devices.

### 3. Pairing the Wireless Bluetooth Remote:

The remote control is typically embedded in the handle. Slide it out. Turn on the remote by pressing and holding the button until an indicator light flashes. On your phone, go to Bluetooth settings and search for available devices. Select the device named "SelfieCom" or similar to pair. The indicator light will stop flashing once paired. No app pairing is needed.



The embedded and detachable wireless remote control for portable storage.

#### 4. **Activating Fill Lights:**

The selfie stick features dual fill lights. Locate the light control buttons on the handle or remote. Press the button to turn on the lights. Subsequent presses will cycle through different brightness levels and color temperatures (cold/warm).

## **OPERATING INSTRUCTIONS**

### **1. Taking Photos/Videos with Remote:**

Once your phone is paired and mounted, open your camera application. Use the wireless remote control to trigger the shutter button for photos or start/stop video recording. This allows for stable, shake-free shots from a distance.



**Stable snapshot  
Do not shake the screen**

Using the wireless remote for one-click shooting.



Stable snapshot capability ensures clear photos and videos without screen shake.

## 2. **Adjusting Length and Angle:**

The retractable pole extends from 30.5cm to 180cm, allowing for a wide range of shooting distances. Adjust the phone holder's angle to switch between horizontal and vertical shooting modes as needed. The head can rotate to achieve various perspectives.



The selfie stick extended to 165cm for a wider shooting range.

### 3. Optimizing Lighting:

Utilize the dual fill lights to eliminate shadows and enhance clarity. Cycle through the 3 brightness levels and cold/warm color temperatures to match your environment or desired aesthetic. This is particularly useful for low-light conditions, vlogs, or live streams.

## “Dual Lighting” - Low-Light Performance



Dual lighting effectively reduces shadows for improved low-light performance.

#### 4. Using as a Tripod:

For group photos, stable video recording, or hands-free streaming, extend the tripod legs and place the unit on a flat, stable surface. Adjust the height and angle as desired. The anti-slip frosted grip and ABS plastic clamp ensure stability.

## Expandable & Multi-Angle - Use in a Group



The selfie stick in tripod mode, ideal for group photos and vlogs.

### Product Demonstration Video

Your browser does not support the video tag.

This video demonstrates the various features and functionalities of the 6-in-1 Selfie Stick with Fill Light, including its rotation, extension, and lighting adjustments.

## MAINTENANCE

- **Cleaning:** Wipe the selfie stick with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, fold the selfie stick to its compact size and store it in a dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The product features an IPX4 splash-proof design, meaning it can withstand splashes of water. However, it is not waterproof. Do not submerge it in water or expose it to heavy rain.
- **Battery Care:** Ensure the remote control's battery is replaced when necessary. If the fill lights are rechargeable, follow the manufacturer's guidelines for charging to prolong battery life.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not pairing.	Remote battery low or off; Bluetooth not enabled on phone; remote not in pairing mode.	Ensure remote is charged/has fresh batteries and turned on. Enable Bluetooth on your phone. Press and hold the remote button to enter pairing mode (indicator light flashes). Forget previous pairings on your phone and try again.
Fill lights not turning on.	Lights are off; battery low/depleted.	Press the light control button to turn them on. If rechargeable, ensure they are fully charged.
Selfie stick is unstable in tripod mode.	Legs not fully extended; uneven surface; device too heavy or off-center.	Ensure tripod legs are fully spread and locked. Place on a flat, stable surface. Verify your device is centered and securely clamped.
Phone not fitting in clamp.	Phone size exceeds clamp's maximum capacity.	Check product specifications for compatible phone sizes. Do not force the phone into the clamp as this may cause damage.

## SPECIFICATIONS

**Brand:** Generic

**Model Number:** B0F62RKMHB

**Material:** Aluminum alloy (pole), ABS plastic (clamp/grip)

**Color:** BK (Black)

**Maximum Height:** 180 Centimeters

**Minimum Height (Folded):** 30.5 Centimeters


**Folded Size:** 31.5 x 8.5 x 7.5 cm (12.4 x 3.3 x 2.9 inches)

**Special Feature:** Lightweight, Wireless Remote, Dual Fill Lights, Tripod Function

**Compatible Devices:** Cellphone, Camera, GoPro

**Tripod Head Type:** Standard Tripod Head

**Water Resistance Level:** IPX4 (Splash Resistant)



Detailed dimensions of the selfie stick in both extended and folded states.

## WARRANTY INFORMATION

This product comes with a **one-year warranty** from the date of purchase. The warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper maintenance. Please retain your proof of purchase for warranty claims.

## SUPPORT

If you encounter any issues or have questions regarding your Generic 6-in-1 Selfie Stick with Fill Light that are not addressed in this manual, please refer to the seller's support channels on the platform where you purchased the product. For further assistance, you may also consult the product listing for additional contact information or FAQs.