

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [COMHOMA](#) /
- › [COMHOMA DF-GB-BRC-02-BR Recliner Chair User Manual](#)

COMHOMA DF-GB-BRC-02-BR

COMHOMA DF-GB-BRC-02-BR Recliner Chair User Manual

Model: DF-GB-BRC-02-BR

INTRODUCTION

Thank you for choosing the COMHOMA DF-GB-BRC-02-BR Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read it thoroughly before use and retain it for future reference.



Image: The COMHOMA DF-GB-BRC-02-BR Recliner Chair, showcasing its design and brown fabric upholstery.

SAFETY INFORMATION

Caution:

- Ensure proper use of the reclining mechanism.
- This chair has a maximum weight capacity of 52.9 pounds. Exceeding this weight limit may cause instability or damage to the chair.
- Keep children and pets away from the moving parts of the recliner.
- Do not stand on the footrest or armrests.
- Avoid placing heavy objects on the recliner when it is in a reclined position.
- Always ensure the power cord for the massage and heat functions is not pinched or damaged.

PACKAGE CONTENTS

Before assembly, please ensure all components are present and undamaged. Refer to the packing list provided with your chair for a complete inventory. Typically, the package includes:

- Recliner backrest
- Recliner seat base with armrests
- Power adapter for heat and massage functions
- Remote control for heat and massage
- Assembly hardware (bolts, washers, etc.)
- Instruction manual

SETUP AND ASSEMBLY

The COMHOMA Recliner Chair is designed for effortless assembly. Follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Attach Backrest:** Slide the backrest onto the metal guides located on the seat base until it clicks securely into place.
3. **Connect Wiring:** Connect any electrical wires for the massage and heating functions, ensuring they are securely fastened.
4. **Attach Power Adapter:** Plug the power adapter into the chair's power input and then into a wall outlet.
5. **Final Check:** Ensure all connections are secure and the chair is stable before use.



Image: Product dimensions showing the chair's width, depth, and height in both upright and reclined positions.

OPERATING INSTRUCTIONS

Manual Reclining Function

To recline the chair, locate the lever on the side of the chair (typically on the right). Pull the lever to release the footrest and lean back to your desired position. To return to the upright position, push the footrest down with your legs and lean forward until the backrest locks into place.



Image: Diagram illustrating various adjustable recliner positions suitable for different activities like reading, using a phone, watching TV, and napping.

Vibration Massage and Heating Functions

Your recliner is equipped with vibration massage and heating elements. Use the remote control to activate and adjust these features:

- **Massage Zones:** Select from 4 optional massage parts (e.g., back, lumbar, thighs, calves).
- **Massage Modes:** Choose from 5 optional massage modes (e.g., pulse, press, wave, auto).
- **Massage Strength:** Adjust between 2 optional strength levels (low, high).
- **Heating Function:** Activate the local heating function for added comfort, typically in the lumbar area.



MASSAGE AND HEAT



4 optional parts



5 optional modes



2 optional strength



Local heating function

Image: Visual representation of the massage and heat functions, highlighting the 4 optional parts, 5 optional modes, 2 optional strengths, and local heating function.

Swivel Rocker Function

The chair features a 360-degree swivel and rocking motion. Simply rotate the chair to face any direction or gently rock for a soothing experience. Ensure there is adequate space around the chair for safe swiveling and rocking.

SWIVEL GLIDER RECLINER CHAIR

Smooth Gliding Motion and Recline Feature perfect for unwinding after a long day



Image: A person relaxing in the COMHOMA swivel glider recliner chair, illustrating its smooth gliding and reclining capabilities.

Integrated Features

Your recliner includes convenient features for enhanced comfort:

- **Cup Holders:** Use the integrated cup holders in the armrests to keep beverages secure.
- **Storage Bag:** Utilize the side storage bag for remote controls, magazines, or other small items.
- **Ergonomic Backrest:** The design provides optimal support for your back.

DETAILS SHOW THE QUALITY



Image: Detailed view of the recliner's features, including the ergonomic backrest, a built-in cup holder, and a convenient side storage bag.

MAINTENANCE

To ensure the longevity and appearance of your COMHOMA Recliner Chair, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Inspection:** Periodically check all bolts and connections to ensure they are tight. Retighten if necessary.
- **Placement:** Avoid direct sunlight and excessive heat to prevent fading or material damage.

TROUBLESHOOTING

If you encounter any issues with your recliner, refer to the following common solutions:

- **Reclining Mechanism Not Working:**
 - Ensure the lever is fully engaged.
 - Check for any obstructions preventing the footrest or backrest from moving.

- **Massage/Heat Not Functioning:**

- Verify the power adapter is securely plugged into both the chair and the wall outlet.
- Check if the wall outlet is functional.
- Ensure the remote control has working batteries (if applicable) and is properly connected.

- **Chair Feels Unstable:**

- Confirm all assembly bolts are tightened.
- Ensure the chair is placed on a flat, even surface.

If the problem persists, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	COMHOMA
Model Number	DF-GB-BRC-02-BR
Color	Brown
Material	Metal frame, Foam seating
Product Dimensions (D x W x H)	32.99"D x 29"W x 41"H (Upright)
Item Weight	89.8 Pounds
Max Weight Capacity	52.9 Pounds
Reclining Positions	Manual, Multiple angles
Massage Function	Vibration massage with 4 parts, 5 modes, 2 strengths
Heating Function	Local heating
Swivel Function	360-degree swivel
Additional Features	Cup Holders, Storage Bag
Required Assembly	Yes

Note: The listed maximum weight capacity of 52.9 pounds appears to be a potential data entry error in the source. Standard recliners typically support significantly higher weights. Please consult the manufacturer for accurate weight limits.

WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact COMHOMA customer service. Refer to the contact details provided on the product packaging or the official COMHOMA website.

Online Support: [Visit the COMHOMA Store on Amazon](#)

