Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vacusion VBS-01

Vacusion VBS-01 Cordless Vacuum Cleaner Instruction Manual

Model: VBS-01 | Brand: Vacusion

Introduction

The Vacusion VBS-01 Cordless Vacuum Cleaner is designed for thorough and convenient cleaning across various surfaces. This 8-in-1 cordless stick vacuum features three powerful suction modes, offering up to 45 minutes of runtime on a single charge. Its lightweight and versatile design allows for easy conversion into multiple configurations, making it ideal for cleaning floors, carpets, furniture, and even car interiors. Equipped with a 5-stage filtration system and LED headlights, it ensures a cleaner home environment by effectively capturing dust and debris.

Package Contents

Please ensure all components listed below are present in your package:

- 1 x Cordless Vacuum Cleaner Main Body
- 1 x Battery
- 1 x Detachable Extension Tube
- 1 x 180° Rotatable LED Floor Brush Head
- 1 x 2-in-1 Brush Tool
- 1 x Crevice Tool
- 1 x Multi-function Cleaning Tool
- 1 x Adapter
- 1 x Wall Hanger
- 2 x Screws & Wall Anchors
- 3 x Washable HEPA Filters (2 already assembled in the main body)
- 1 x Quick Start Guide
- 1 x User Manual

Image: All components included in the Vacusion VBS-01 package.

Setup

Assembly

1. Insert the detachable extension tube into the main body until it clicks securely into place.
2. Attach the 180° rotatable LED floor brush head to the other end of the extension tube, ensuring a firm connection.
3. For handheld use, detach the extension tube and connect desired accessories (2-in-1 brush tool, crevice tool, multi-function cleaning tool) directly to the main body.

Image: The cordless vacuum cleaner assembled in different configurations for versatile cleaning.

Charging the Battery

The Vacusion VBS-01 features a detachable 2200mAh Lithium-Ion battery. To charge:

1. Ensure the battery is securely attached to the main body or detached for separate charging.
2. Connect the adapter to the charging port on the battery or the wall-mounted charging station.
3. Plug the adapter into a power outlet. The battery charge time is approximately 4.5 hours.



Image: The detachable 2200mAh battery, ready for charging.

Operating Instructions

Power and Suction Modes

The vacuum cleaner offers three powerful suction modes to suit different cleaning needs. Use the control buttons on the main body to switch between modes and monitor battery life and cleaning status on the smart digital display.



Image: The smart digital display provides real-time updates on battery life, brush roll status, and current cleaning mode.

LED Headlights and Maneuverability

The floor brush head is equipped with bright LED headlights to illuminate dust and debris in dimly lit areas. Its 180° swivel and 90° tilt capabilities allow for easy maneuvering under furniture and into tight spaces.




Image: The vacuum's LED headlights illuminate dust under furniture for thorough cleaning.

Versatile Cleaning

The 7.8-inch brush head with a 2-in-1 roller is effective on various surfaces including hardwood floors, carpets, tiles, and marble. The vacuum's 8-in-1 convertible design makes it suitable for cleaning sofas, cars, curtains, narrow gaps, and stairs.



Image: The vacuum cleaner effectively cleans various floor types, from hardwood to carpet.

Maintenance

Emptying the Dustbin

The dustbin features a one-click emptying mechanism for quick and hygienic disposal of collected debris. Simply press the release button to open the bottom flap and empty contents directly into a trash receptacle.

Filter Cleaning and Replacement

The 5-stage filtration system includes washable HEPA and sponge filters. Regularly clean the filters to maintain optimal suction performance. An extra filter is included for convenience.

1. Twist and remove the filter assembly from the dustbin.
2. Separate the HEPA and sponge filters.
3. Rinse filters under running water until clean. Ensure they are completely dry before reassembling and placing back into the vacuum.
4. Replace filters as needed with the provided spares.



Image: Washable HEPA filters are easy to clean and maintain.

Troubleshooting

- **No Power:** Ensure the battery is fully charged. Check that the battery is correctly inserted into the main body.
- **Reduced Suction:** Empty the dustbin. Clean or replace the filters. Check the brush head and extension tube for blockages.
- **Brush Roll Not Spinning:** Check for hair or debris tangled around the brush roll. Ensure the brush head is properly attached.
- **Short Runtime:** Battery runtime may vary based on suction mode and surface type. Ensure the battery is fully charged before use.

Specifications

Feature	Detail
Brand	Vacusion
Model Name	VBS-01
Power Source	Battery Powered (Lithium-Ion)
Runtime	Up to 45 minutes
Battery Charge Time	4.5 Hours
Number of Speeds	3
Filter Type	HEPA Filter
Capacity	0.8 Liters
Noise Level	76 Decibels
Motor Horsepower	150 Watts
Item Weight	5.86 Pounds
Item Dimensions (L x W x H)	10.24"L x 11.81"W x 45.47"H

Warranty and Support

For warranty information or technical support, please refer to the contact details provided in the Quick Start Guide or User Manual included in your package. You may also visit the official Vacusion website for further assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F62WKVQC

More documents and user manuals: **https://manuals.plus/**