ULTIMEA U3721

ULTIMEA Poseidon M60 5.1CH Dolby Atmos Soundbar System User Manual

Model: U3721 | Brand: ULTIMEA

1. Introduction

The ULTIMEA Poseidon M60 is a 5.1-channel Dolby Atmos soundbar system designed to deliver immersive home theater audio. It features five built-in speakers, a wired subwoofer, and advanced technologies like BassMX and VoiceMX for enhanced sound clarity and deep bass. Control is available via remote or the dedicated Ultimea app.



Image: The ULTIMEA Poseidon M60 soundbar and its wired subwoofer.

2. What's in the Box

- 1x Soundbar
- 1x Wired Subwoofer
- 1x Power Adaptor
- 1x HDMI Cable
- 1x Remote Control (Batteries Not Included)
- 2x Wall Brackets
- 2x Mounting Screws
- 4x Wall Mounted Kit

3. Setup

3.1 Placement

Position the soundbar centrally below your television. The wired subwoofer can be placed on the floor near the soundbar, ideally in a corner for enhanced bass response.



Image: Recommended placement of the soundbar and subwoofer in a home theater setup.

3.2 Connections

The Poseidon M60 offers multiple connectivity options:

- **HDMI eARC:** For the best audio quality, connect the included HDMI cable from the soundbar's "HDMI to TV (eARC)" port to your TV's HDMI eARC/ARC port. This supports lossless Dolby Atmos audio.
- **Optical:** Connect an optical cable (not included) from the soundbar's "OPTICAL" port to your TV's optical output.
- **Bluetooth 5.4:** For wireless audio streaming from mobile devices.

- **USB:** For media playback from a USB drive.

Important Note for Subwoofer Setup:

If you experience issues with the subwoofer, ensure your TV's audio output setting is set to PCM (Pulse-Code Modulation). This is often required for the subwoofer to function correctly, especially with certain TV models. Consult your TV's user manual for specific audio output settings.



Image: Rear view of the soundbar showing various input ports.

3.3 Initial Power-On

After connecting the soundbar and subwoofer to power and your TV, press the power button on the soundbar or remote control to turn on the system. Select the desired input source using the remote or soundbar controls.

Your browser does not support the video tag.

Video: Official product overview demonstrating setup and features of the Poseidon M60. This video highlights the ease of setup and the immersive audio experience.

4. Operating the Soundbar

4.1 Basic Controls

Use the included remote control or the touch controls on top of the soundbar to manage power, volume, and input selection.

4.2 Ultimea App Control

Download the official Ultimea app for advanced control and customization. The app allows you to:

- Adjust a 10-band graphic equalizer.
- Select from 121 sound presets.
- Fine-tune 13 adjustable surround levels.
- Receive Over-The-Air (OTA) firmware updates.



Image: Screenshots of the Ultimea mobile application, demonstrating equalizer and sound customization options.

4.3 Audio Technologies

- **Dolby Atmos:** Experience immersive 4D sound with real Dolby Atmos. The soundbar's five built-in speakers, including two side-firing drivers, create a wide surround soundstage.
- **VoiceMX Technology:** Enhances vocal clarity by isolating and boosting dialogue frequencies, ensuring clear speech even during intense scenes or at low volumes.
- **BassMX Technology:** Powers the wired subwoofer's 18mm high-excursion driver and tuned cabinet for deeper, tighter

bass.



Image: A visual representation of Dolby Atmos sound projection filling a room.



Image: An internal diagram illustrating the five built-in speakers within the soundbar, including left, center, and right surround channels.



Image: The wired subwoofer, highlighting its BassMX technology for enhanced low-frequency performance.

4.4 Bluetooth Pairing

To pair a Bluetooth device:

1. Press the Bluetooth button on the remote or soundbar. The indicator light will flash.
2. Enable Bluetooth on your device and select "Poseidon M60" from the list of available devices.
3. Once connected, the indicator light will turn solid.



Image: A user interacting with the soundbar via a smartphone, demonstrating Bluetooth 5.4 connectivity.

5. Maintenance

To ensure the longevity and optimal performance of your ULTIMEA Poseidon M60 soundbar system:

- Keep the soundbar and subwoofer clean by wiping them with a soft, dry cloth.
- Avoid exposing the system to excessive moisture, heat, or direct sunlight.

- Do not block the speaker grilles or vents.
- Disconnect from power during lightning storms or when unused for long periods.

6. Troubleshooting

Problem	Possible Cause	Solution
No Sound	Incorrect input selected; cables loose; TV audio settings incorrect.	Check input source; ensure all cables are securely connected; set TV audio output to PCM or Bitstream.
Subwoofer not working	TV audio output not set to PCM.	Access your TV's audio settings and change the digital audio output format to PCM.
Bluetooth connection issues	Device too far; interference; soundbar not in pairing mode.	Move device closer; clear obstacles; re-enter pairing mode on soundbar.
Remote control not working	Batteries dead; line of sight blocked.	Replace batteries; ensure no obstructions between remote and soundbar.

7. Specifications

Feature	Detail
Model Name	Poseidon M60
Speaker Type	5.1ch Soundbar with Dolby Atmos
Speaker Maximum Output Power	300 Watts
Frequency Response	45 Hz
Subwoofer Diameter	5.25 Inches
Connectivity Technology	HDMI eARC, Optical, Bluetooth 5.4
Wireless Communication Technology	Bluetooth 5.4
Control Method	App, Remote
Product Dimensions	31.5"D x 3.54"W x 2.76"H
Item Weight	8.82 Pounds
Mounting Type	Tabletop or Wall Mount
Audio Encoding	Dolby Atmos

8. Warranty and Support

The ULTIMEA Poseidon M60 comes with a Limited Warranty. For detailed warranty information, product support, or technical assistance, please visit the official ULTIMEA website or contact their customer service.

You can also refer to the official User Guide PDF available at:https://m.media-amazon.com/images/I/D18dCdvRiCL.pdf

© 2025 ULTIMEA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question