

Mosonnytee Q16

Mosonnytee Q16 Open Ear Wireless Earbuds User Manual

Model: **Q16** | Brand: **Mosonnytee**

1. PRODUCT OVERVIEW

The Mosonnytee Q16 Open Ear Wireless Earbuds are designed for comfort and high-quality audio, allowing users to stay aware of their surroundings while enjoying sound. These earbuds feature an ergonomic open-ear design, intuitive touch controls, and immersive surround sound with CVC noise cancellation.

Key features include:

- **Open-Ear Design:** Ergonomic shape for all-day comfort without pressure, allowing awareness of ambient sounds.
- **Intuitive Touch Controls:** Easy management of calls, volume, and track selection with simple taps.
- **Studio-Quality Surround Sound:** Enhanced decoding algorithm with CVC noise cancellation for a lifelike 3D soundstage.
- **Effortless Auto-Connect:** Automatic pairing upon opening the case, compatible with Android, iOS, and Windows Bluetooth devices.
- **Extended Battery Life:** Up to 86 hours of playtime with the charging case, featuring a real-time power indicator.



Image: Mosonnytee Q16 Open Ear Wireless Earbuds in their charging case, highlighting the digital battery display.

Your browser does not support the video tag.

Video: An official demonstration of the Mosonnytee open ear earbuds, showcasing their design, fit, and features like the LED digital display and HiFi sound quality.

2. SETUP GUIDE

2.1. Package Contents

Before you begin, please ensure all items are present in your package:

- Mosonnytee Q16 Open Ear Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual (this document)

2.2. Charging the Earbuds and Case

For optimal performance, fully charge the earbuds and charging case before first use.

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and plug the other end into a USB power adapter (not included) or a computer's USB port.
3. The LED digital display on the charging case will indicate the battery level. A full charge is indicated by "100%".
4. Charging typically takes approximately 1-2 hours for the earbuds and 2-3 hours for the case.



Image: The Mosonnytee Q16 charging case being charged, showing the power input and internal charging indicators.

2.3. Bluetooth Pairing

The earbuds are designed for effortless auto-connection.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, computer), enable Bluetooth.
3. Search for "Q16" or "Mosonnytee Q16" in the list of available Bluetooth devices.

4. Select "Q16" to connect. Once connected, you will hear an audio prompt, and the earbuds' indicator lights will turn off or flash slowly.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.



Image: The Mosonnytee Q16 earbuds and their case positioned near a smartphone, illustrating a successful Bluetooth connection.

3. OPERATING INSTRUCTIONS

3.1. Wearing the Earbuds

The Q16 earbuds feature an open-ear design for comfortable and secure fit.

1. Identify the Left (L) and Right (R) earbuds.
2. Gently hook the earbud over your ear, ensuring the speaker portion is positioned comfortably near your ear canal without entering it.
3. Adjust for a snug and stable fit.



Image: A user wearing the Mosonnytee Q16 earbud, highlighting its ergonomic design for comfortable and secure placement.

3.2. Touch Controls

The Q16 earbuds feature intuitive touch controls on each earbud. The functions can vary slightly between the left and right earbud for certain actions.

Action	Left Earbud	Right Earbud
Play/Pause Music	Single Tap	Single Tap
Next Track	Long Press (1s)	Long Press (1s)
Volume Up	Double Tap	N/A
Volume Down	N/A	Double Tap

Action	Left Earbud	Right Earbud
Answer/End Call	Single Tap	Single Tap
Reject Call	Long Press (2s)	Long Press (2s)
Activate Voice Assistant	Triple Tap	Triple Tap

Note: Specific touch control sensitivity and response times may vary slightly based on individual usage.



Image: The Mosonnytee Q16 earbuds and their charging case, ready for use with a smartphone, demonstrating their multimedia capabilities.

4. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your Mosonnytee Q16 earbuds.

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe the earbuds and charging case. Do not use abrasive cleaners,

alcohol, or chemical solvents.

- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.
- **Charging:** Avoid overcharging. Disconnect the charging cable once the case and earbuds are fully charged.
- **Water Exposure:** While designed for daily use, avoid prolonged exposure to water or high humidity. Do not submerge the earbuds or case in water.

5. TROUBLESHOOTING

If you encounter issues with your Mosonnytee Q16 earbuds, try the following solutions:

5.1. Earbuds Not Pairing/Connecting

- Ensure the earbuds are fully charged.
- Make sure Bluetooth is enabled on your device and the earbuds are within range (typically 10 meters/33 feet).
- Turn off Bluetooth on your device, then turn it back on.
- Forget or remove "Q16" from your device's Bluetooth list and attempt to pair again.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid to re-initiate pairing mode.

5.2. No Sound or Low Volume

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.
- Try playing audio from a different application or source.
- Restart your connected device.

5.3. Charging Issues

- Verify the charging cable is securely connected to both the case and the power source.
- Ensure the charging port on the case is clean and free of debris.
- Try using a different USB charging cable or power adapter.
- Confirm the earbuds are correctly seated in the charging case.

6. SPECIFICATIONS

Feature	Detail
Model Name	Q16
Brand	Mosonnytee
Connectivity Technology	Wireless (Bluetooth)
Form Factor	In Ear (Open Ear Design)
Material	Plastic
Color	Black
Playtime (with case)	Up to 86 hours

Feature	Detail
Noise Cancellation	CVC Noise Cancelling
Compatibility	Android, iOS, Windows Bluetooth devices

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included in your product packaging or visit the official Mosonnytee website. You may also contact customer service via the platform where you purchased the product.

Online Support: [Visit the Mosonnytee Store on Amazon](#)

© 2025 Mosonnytee. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question