

Romorgniz B0F637WFKP

Romorgniz 11-Drawer Dresser Instruction Manual

Model: B0F637WFKP

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Romorgniz 11-Drawer Dresser. Please read this manual thoroughly before beginning assembly or use to ensure proper setup and safe operation. Keep this manual for future reference.



Image 1.1: Front view of the Romorgniz 11-Drawer Dresser. This dresser features a black metal frame, a wooden top, and eleven fabric drawers with black handles, providing ample storage.

2. SAFETY INFORMATION

- **Anti-Tip Kit:** Always install the included anti-tip kit to prevent accidental tipping, which can cause serious injury. Secure the dresser to a wall stud using the provided hardware.
- **Weight Capacity:** Do not exceed the recommended weight capacity for the top surface or individual drawers. Overloading can compromise stability and cause damage.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened before use. Periodically check and retighten fasteners as needed.
- **Placement:** Place the dresser on a level surface. Use the adjustable feet to stabilize the unit on uneven floors.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the dresser.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

Hardware and Tools:

- Screws (various sizes)
- Allen Wrench
- Adjustable Feet
- Anti-Tip Kit (wall anchor, screw, strap)

Components:

- Wooden Top Panel
- Metal Frame Sections (vertical and horizontal bars)
- Fabric Drawers (5 large, 6 small)
- Drawer Handles

4. SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly. It is recommended to assemble the dresser on a soft, clean surface to prevent scratches.

Assembly Video Guide:

Your browser does not support the video tag.

Video 4.1: This video provides a step-by-step visual guide for assembling the 11-drawer dresser, demonstrating how to connect the frame components and install the drawers.

Step-by-Step Instructions:

1. **Assemble the Base Frame:**

Attach the adjustable feet to the bottom metal frame sections. Connect the horizontal support bars to the vertical frame pieces using the designated screws. Ensure all connections are secure but do not fully tighten screws until the entire frame is assembled.



Image 4.2: Detail showing the adjustable feet for leveling and the anti-tipping device for securing the dresser.

2. Attach the Wooden Top:

Carefully place the wooden top panel onto the assembled metal frame. Align the pre-drilled holes on the underside of the wooden top with the holes on the top of the metal frame. Secure the top using the appropriate screws. Now, fully tighten all screws on the metal frame.

3. Install Fabric Drawers:

Unfold each fabric drawer. Insert the bottom panel into the base of each drawer to provide stability. Attach the handles to the front of each fabric drawer using the provided screws.



Image 4.3: Illustration of the 3-layer thickened fabric drawer, designed for durability and shape retention.

4. Insert Drawers into Frame:

Slide the assembled fabric drawers into their respective slots within the metal frame. Ensure the drawers slide smoothly.



Image 4.4: The dresser with several drawers pulled out, demonstrating its spacious storage capacity for various items.

5. Install Anti-Tip Kit:

Follow the instructions provided with the anti-tip kit to securely fasten the dresser to a wall. This is a critical safety step.

5. OPERATING INSTRUCTIONS

Your Romorgniz 11-Drawer Dresser is designed for versatile storage in various rooms.

Drawer Usage:

- The dresser features 5 large drawers and 6 small drawers. Utilize the large drawers for bulkier items like sweaters, pants, or blankets. The smaller drawers are suitable for organizing undergarments, socks, ties, and accessories.
- The fabric drawers are designed to slide in and out smoothly. Avoid forcing drawers if they feel stuck; check for obstructions.

Top Surface:

- The sturdy wooden top surface can hold decorative items, books, or serve as a TV stand for televisions up to 55 inches.
- When used as a TV stand, consider using a cable management solution to maintain a tidy appearance.



Image 5.1: The dresser functioning as a TV stand, suitable for televisions up to 55 inches.

Adjustable Feet:

- The adjustable feet allow you to level the dresser on uneven floor surfaces, preventing wobbling and protecting your floors from scratches. Rotate the feet clockwise or counter-clockwise to adjust the height.

6. MAINTENANCE

- **Cleaning:** Wipe the wooden top and metal frame with a soft, damp cloth. For fabric drawers, spot clean with a mild detergent and allow to air dry. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten as necessary.
- **Drawer Care:** Avoid overfilling drawers to prevent stretching or damage to the fabric.

7. TROUBLESHOOTING

Common Issues and Solutions:

- **Dresser is Wobbly:**
Ensure all frame screws are fully tightened. Adjust the leveling feet on the bottom of the dresser to stabilize it on uneven surfaces.
- **Drawers Do Not Slide Smoothly:**
Check that the drawers are correctly inserted into their designated slots. Ensure no items are obstructing the drawer's path. Verify that the bottom panel is fully inserted into the fabric drawer.
- **Missing Parts:**
If any parts are missing upon arrival, please refer to the 'Warranty and Support' section to contact customer service for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	Romorgniz
Model	B0F637WFKP
Product Dimensions	47.2"W x 11.87"D x 29.5"H
Color	Black
Room Type	Bedroom, Entryway, Living Room
Assembly Required	Yes
Drawer Count	11 (5 large, 6 small)
Material	Metal frame, Wooden top, Fabric drawers

9. WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your Romorgniz 11-Drawer Dresser, please contact Romorgniz customer service. While specific warranty details are not provided in this manual, please refer to your purchase documentation or the seller's website for warranty information.

Contact Information: Please refer to the contact details provided at the point of purchase or on the official Romorgniz website.