Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HAMMER HTWS003

HAMMER Ultra Pods HTWS003 TWS Wireless Bluetooth Earbuds User Manual

Model: HTWS003

1. Introduction

Thank you for choosing the HAMMER Ultra Pods HTWS003 TWS Wireless Bluetooth Earbuds. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your new earbuds. Please read this guide thoroughly before use to ensure optimal performance and longevity of your device.



Image: HAMMER Ultra Pods HTWS003 TWS Wireless Bluetooth Earbuds in blue, shown with charging case.

2. What's in the Box

Upon unboxing your HAMMER Ultra Pods HTWS003, please ensure all the following items are present:

- 1 Unit Earbuds (Left and Right)
- 1 Unit Charging Case
- 1 Unit USB Type-A to C Charging Cable
- Ear Cushions (various sizes)
- User Manual (Digital version available via QR Code)




Image: Contents of the HAMMER Ultra Pods HTWS003 box, including earbuds, charging case, USB-C cable, and user manual.

3. Setup

3.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. Use the provided USB Type-C cable to connect the charging case to a power source. A full charge typically takes 1 hour.



Image: Illustration showing the HAMMER Ultra Pods charging case and earbuds, highlighting 50 hours of playtime and 1 hour to full charge via USB Type-C.

3.2. Pairing with a Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available devices and select "HAMMER Ultra Pods HTWS003" from the list.
4. Once connected, the earbuds are ready for use. They will automatically reconnect to the last paired device when taken out of the case.




Image: Diagram illustrating Bluetooth V6.0 features: 10-meter transmission range, 1-step pairing, auto reconnect, and low latency.

4. Operating the Earbuds

4.1. Touch Controls

The Ultra Pods feature intuitive touch controls for managing audio playback, calls, and voice assistant functions.

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Long Press (Left/Right)	Activate Voice Assistant, Reject Call

Action	Function
Press and hold right earbud for 2 seconds	Switch ANC Modes



Image: A person demonstrating touch control on an earbud, with text indicating 'Control the Rhythm WITH A TOUCH'.

4.2. Voice Assistant

To activate your device's voice assistant (e.g., Siri, Google Assistant), press and hold either the left or right earphone for a few seconds until you hear a prompt.



Image: A person activating voice assistance on an earbud by pressing and holding, with icons for popular voice assistants.

4.3. Making and Receiving Calls

The earbuds feature an in-built high-definition microphone and Environmental Noise Cancellation (ENC) with 4 microphones for clear communication.

- **Answer Call:** Single tap either earbud.
- **End Call:** Single tap either earbud during a call.
- **Reject Call:** Long press either earbud.



Image: A woman wearing an earbud, with text highlighting ENC and 4 microphones for clear calling.

4.4. Active Noise Cancellation (ANC)

The earbuds support Active Noise Cancellation up to 32dB, reducing unwanted background sound. To switch between ANC modes, press and hold the right earbud for 2 seconds.




Image: Illustration showing 32dB ANC feature with a person wearing earbuds in a quiet outdoor setting.

5. Features

- **Immersive Sound:** Equipped with 13mm dynamic drivers for deep bass and clear highs.



Image: Close-up of an earbud driver with sound waves, indicating 13mm sound driver for deep bass and crystal-clear vocals.

- **Extended Playtime:** Up to 50 hours of combined playback with the charging case, and 100 hours of standby time.
- **Advanced Bluetooth:** Bluetooth V6.0 ensures stable connectivity, faster pairing, and lower latency within a 10-meter range.



Image: Illustration of Next-Gen Bluetooth V6.0 offering faster, stronger, and more reliable connectivity with quick pairing and stable connection.

- **Water Resistance:** IPX5 water-resistant rating protects against splashes and sweat, making them suitable for workouts.

- **Compact Design:** Ergonomically designed for comfort and portability.




Image: Image showcasing the compact and bold design of the earbuds and charging case.

6. Maintenance

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Ear Tips:** Remove and clean ear tips periodically with water and mild soap, then dry completely before reattaching.
- **Charging Ports:** Ensure the USB-C charging port is free from dust and debris.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from damage and dust. Avoid extreme temperatures.

7. Troubleshooting

If you encounter issues with your earbuds, refer to the following common solutions:

- **Earbuds not pairing:** Ensure earbuds are charged. Turn off and on your device's Bluetooth. Try forgetting the device in your Bluetooth settings and re-pairing.
- **No sound from one earbud:** Place both earbuds back in the case, close it, wait a few seconds, then take them out again. Ensure they are properly charged.
- **Charging issues:** Check the USB-C cable and power adapter. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- **Low volume or poor sound quality:** Adjust the volume on your connected device. Ensure ear tips are correctly sized and seated in your ear for a good seal. Clean any earwax from the earbud nozzles.
- **Voice Assistant not responding:** Ensure the earbuds are connected and your device's voice assistant is enabled. Check the touch control settings.

8. Specifications

Feature	Detail
Model Number	HTWS003
Brand	HAMMER
Ear Placement	In Ear
Form Factor	In Ear
Bluetooth Version	6.0
Bluetooth Range	10 Metres
Audio Driver Size	13 Millimetres
Playtime	Up to 50 Hours (with charging case)
Standby Time	100 Hours
Battery Charge Time	1 Hour
Charging Port	USB Type-C
Water Resistance	IPX5 Water Resistant
Control Type	Touch Control
Microphone	In-Built High-Definition Microphone, ENC with 4 Mics
Active Noise Cancellation (ANC)	Up to 32dB
Compatible Devices	Laptops, Smartphones
Item Weight	6 Grams
Material	Plastic
Country of Origin	India

9. Warranty and Support

Your HAMMER Ultra Pods HTWS003 come with a **6-month warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

Customer Support:

For any queries, technical assistance, or warranty claims, please contact HAMMER customer support:

- **Email:** Info@hammeronline.in
- **Phone:** 0180-4008081, 9991108081

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F63DQ9L6

More documents and user manuals: **https://manuals.plus/**