

[manuals.plus](#) /

› [Hello Kitty](#) /

› [Hello Kitty Kuromi Wireless Bluetooth Earbuds User Manual HKTWSRKU](#)

Hello Kitty HKTWSRKU

Hello Kitty Kuromi Wireless Bluetooth Earbuds User Manual

Model: HKTWSRKU

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Hello Kitty Kuromi Wireless Bluetooth Earbuds. Please read this manual thoroughly before using the product and retain it for future reference.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Hello Kitty Kuromi Wireless Bluetooth Earbuds (2)
- Rotating Charging Case
- USB Cable
- User Manual (this document)

3. PRODUCT OVERVIEW

3.1 Components

The Hello Kitty Kuromi Wireless Bluetooth Earbuds system consists of two earbuds and a rotating charging case. The charging case features a unique flip-face design, allowing you to change Kuromi's expression.



This image displays the two purple Kuromi wireless earbuds positioned above their open black charging case. The charging case features the Kuromi character design with pointed ears and an open compartment for the earbuds, revealing the charging contacts and a USB-C port.



The closed black charging case is shown, featuring Kuromi's default facial expression with a pink skull on her forehead and a neutral mouth.



The closed black charging case displays Kuromi's winking facial expression, with one eye closed and a small pink heart near her mouth.



The closed black charging case features Kuromi's heart-eyes facial expression, with two pink hearts replacing her eyes and an open-mouthed smile.

3.2 Controls

The earbuds feature touch controls for various functions. Specific touch gestures may vary; refer to the 'Operating Instructions' section for details.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the earbuds and the charging case.

1. Connect the provided USB cable to the charging port on the case and to a compatible USB power source.
2. Place both earbuds into the charging case. Ensure they are properly seated.
3. The charging indicator lights (if present) will illuminate to show charging status. A full charge typically takes approximately 1 hour.

4.2 Bluetooth Pairing

To connect your earbuds to a device:

1. Ensure the earbuds are charged and removed from the charging case. They should automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.

3. Search for available Bluetooth devices.
4. Select "HKTWSRKU" or a similar name from the list of devices.
5. Once connected, the earbuds will indicate successful pairing (e.g., a voice prompt or LED change).
6. The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Remove the earbuds from the charging case. They will power on automatically.
- **Power Off:** Place the earbuds back into the charging case. They will power off and begin charging automatically.

5.2 Music Playback

Use the touch controls on the earbuds:

- **Play/Pause:** Tap once on either earbud.
- **Next Track:** Double-tap the right earbud.
- **Previous Track:** Double-tap the left earbud.
- **Volume Control:** Volume is typically controlled via your connected device.

5.3 Call Management

The built-in microphone allows for hands-free calling:

- **Answer Call:** Tap once on either earbud when a call comes in.
- **End Call:** Tap once on either earbud during a call.
- **Reject Call:** Press and hold either earbud for approximately 2 seconds.

5.4 Flip-Face Feature

The charging case features a rotating mechanism to change Kuromi's facial expression. Gently rotate the front panel of the case to cycle through the available expressions.

6. CHARGING

6.1 Charging the Earbuds

Place the earbuds into the charging case. They will automatically begin to charge from the case's internal battery.

6.2 Charging the Case

When the charging case battery is low, connect it to a power source using the provided USB cable. The case's indicator lights will show charging status. A full charge for the case typically takes about 1 hour.

7. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.

- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged. Avoid extreme temperatures.
- **Water Exposure:** These earbuds are not waterproof. Avoid exposure to water or excessive moisture.
- **Impact:** Handle the earbuds and case with care to prevent damage from drops or impacts.

8. TROUBLESHOOTING

If you encounter issues, refer to the following table:

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget the device in your Bluetooth settings and re-pair.
No sound from earbuds	Check device volume. Ensure earbuds are connected. Try playing different audio.
Earbuds not charging	Ensure earbuds are correctly seated in the case. Check if the charging cable is securely connected to the case and power source.
Microphone not working	Ensure earbuds are properly connected. Check microphone permissions on your device.

9. SPECIFICATIONS

Key technical details for the Hello Kitty Kuromi Wireless Bluetooth Earbuds:

Feature	Detail
Model Name	Wireless Earbuds (HKTWSRKU)
Connectivity Technology	Bluetooth 5.3
Battery Life (Playtime)	Up to 4 Hours per charge
Charging Time	Approximately 1 Hour
Control Method	Touch
Ear Placement	In Ear
Special Feature	Rotating Charging Case with Flip-Face Feature
Included Components	Rotating Charging Case, USB Cable, User Manual
Manufacturer	Southern Telecom
Item Weight	3.52 ounces

10. WARRANTY INFORMATION

For warranty details, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. Warranty terms and conditions may vary by region and retailer.

11. SUPPORT

If you require further assistance or have questions not covered in this manual, please contact the manufacturer or your retailer's customer support. Keep your purchase receipt and product model number (HKTWSRKU) available when seeking support.