## ULTIMEA Poseidon M60 (U3721)

# ULTIMEA Poseidon M60 5.1 Dolby Atmos Sound Bar User Manual

Model: Poseidon M60 (U3721)

## Introduction

The ULTIMEA Poseidon M60 is a 5.1 channel Dolby Atmos sound bar system designed to deliver immersive surround sound for your home entertainment. Featuring a sleek design, powerful audio output, and advanced connectivity options, it transforms your living space into a cinematic experience without the need for complex setups.




Figure 1: ULTIMEA Poseidon M60 Sound Bar and Subwoofer with mobile app control.

Your browser does not support the video tag.

Video 1: Overview of the ULTIMEA Poseidon M60 5.1ch Dolby Atmos Surround Sound System, highlighting its features and immersive audio capabilities.

## What's in the Box

Verify that all components are present before proceeding with the setup.

- 1x Soundbar
- 1x Wired Subwoofer
- 1x Power Adaptor
- 1x HDMI Cable
- 1x Remote Control (Batteries Not Included)
- 2x Wall Bracket
- 2x Mounting Screws
- 4x Wall Mounted Kit

## Setup

## 1. Soundbar Assembly

The soundbar comes in two parts for compact packaging. Gently slide the two halves together until they click securely into place.



Figure 2: Diagram illustrating the assembly of the two-part soundbar.

## 2. Placement

Place the soundbar on a flat, stable surface in front of your TV, ensuring it does not obstruct the TV's remote sensor. Position the wired subwoofer on the floor near the soundbar, ideally in a corner for enhanced bass response.





Figure 3: Recommended placement and dimensions for the soundbar and subwoofer.

## 3. Connections

Connect the soundbar to your TV using the provided HDMI eARC cable for the best audio quality and CEC control. Alternatively, use an optical cable for digital audio connection. Connect the wired subwoofer to the soundbar using the dedicated SUB OUT port. Finally, connect the power adaptor to the soundbar and plug it into a power outlet.




Figure 4: Connecting the soundbar to a TV using HDMI eARC for lossless audio.





Figure 5: Rear view of the soundbar showing HDMI to TV (eARC), Optical, USB, Sub Out, and DC In ports.

## Operating Instructions

### Power On/Off

Press the power button on the soundbar or remote control to turn the system on or off. If connected via HDMI eARC, the soundbar may power on/off automatically with your TV.

### Input Selection

Use the 'Source' button on the remote or soundbar to cycle through available inputs: HDMI eARC, Optical, USB, and Bluetooth.

### Volume Control

Adjust the volume using the '+' and '-' buttons on the soundbar or remote control.

### Dolby Atmos and Surround Sound

The Poseidon M60 features five built-in speakers, including side-firing drivers, to create an immersive 5.1-channel Dolby Atmos experience. This technology delivers sound that moves around you in three-dimensional space, providing a more realistic and engaging audio environment.




Figure 6: Illustration of the 5.1 Channel Dolby Atmos sound field created by the Poseidon M60.




Figure 7: Internal speaker layout of the soundbar, including left and right surround channels.

## VoiceMX™ Technology

VoiceMX™ technology enhances dialogue clarity, ensuring that conversations are crisp and easy to understand, even during intense action scenes or complex audio mixes. This feature uses dynamic EQ and adaptive gain to balance vocal frequencies.




Figure 8: VoiceMX™ technology ensures clear dialogue by optimizing vocal frequencies.

## BassMX™ Technology

Experience deep, punchy bass with BassMX™ technology, driven by the 16mm long-excursion driver in the wired subwoofer. This technology ensures powerful and clean low-end frequencies for an impactful audio experience.




Figure 9: The 16mm bass-boosting excursion driver in the subwoofer for powerful low frequencies.

## Bluetooth 5.4 Connectivity

Pair your mobile devices wirelessly using Bluetooth 5.4 for high-quality audio streaming with ultra-low latency. To pair, select the Bluetooth input on the soundbar and search for "Poseidon M60" on your device's Bluetooth settings.

## ULTIMEA App Control

Download the ULTIMEA app from the App Store or Google Play to unlock advanced control features. The app allows you to fine-tune EQ settings, select from 121 sound modes, and receive Over-The-Air (OTA) updates for new features and performance improvements.




Figure 10: ULTIMEA app interface showing equalizer and style customization options, along with OTA update feature.

## Maintenance

To ensure the longevity and optimal performance of your ULTIMEA Poseidon M60 sound system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the soundbar and subwoofer. Avoid using liquid cleaners, aerosols, or abrasive materials, as they may damage the finish or internal components.
- **Ventilation:** Ensure adequate ventilation around the soundbar and subwoofer. Do not block any ventilation openings.
- **Temperature and Humidity:** Operate the system within recommended temperature and humidity ranges. Avoid extreme temperatures or high humidity, which can affect performance and lifespan.
- **Power Off When Not in Use:** For extended periods of inactivity, it is recommended to power off the sound system and unplug it from the wall outlet.

## Troubleshooting

If you encounter issues with your ULTIMEA Poseidon M60, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
| --- | --- | --- |
| No Sound | Power not connected.<br>Incorrect input selected.<br>Volume too low or muted.<br>Cable connection loose. | Ensure power adaptor is securely plugged in.<br>Select the correct input source (HDMI eARC, Optical, Bluetooth).<br>Increase volume and check mute status.<br>Verify all audio cables are firmly connected. |
| Distorted Sound | Volume too high.<br>Poor audio source quality.<br>Incorrect EQ settings. | Lower the volume.<br>Try a different audio source.<br>Adjust EQ settings via the ULTIMEA app or remote. |
| Bluetooth Pairing Issues | Soundbar not in pairing mode.<br>Device too far from soundbar.<br>Interference from other devices. | Ensure soundbar is set to Bluetooth input and ready to pair.<br>Move your device closer to the soundbar.<br>Turn off other Bluetooth devices nearby. |
| Remote Control Not Working | Batteries are dead or incorrectly inserted.<br>Obstruction between remote and soundbar. | Replace batteries (2x AAA, not included).<br>Ensure clear line of sight to the soundbar's IR receiver. |

## Specifications

| Feature | Detail |
| --- | --- |
| Model Name | Poseidon M60 |
| Model Number | U3721 |
| Speaker Type | Soundbar with Wired Subwoofer |
| Surround Sound Channel Configuration | 5.1 |

| Feature | Detail |
|---|---|
| Audio Encoding | Dolby Atmos |
| Speaker Maximum Output Power | 300 Watts (Peak) |
| Subwoofer Diameter | 5.25 Inches |
| Frequency Response | 45 Hz |
| Connectivity Technology | HDMI eARC, Optical, Bluetooth 5.4 |
| Wireless Communication Technology | Bluetooth 5.4 |
| Control Method | App, Remote Control |
| Product Dimensions (Soundbar) | 31.5"D x 3.54"W x 2.76"H |
| Item Weight | 8.8 Pounds |
| Mounting Type | Tabletop or Wall Mount |

## Warranty and Support

ULTIMEA provides a worry-free warranty and dedicated customer support for the Poseidon M60 sound system. For any inquiries, technical assistance, or warranty claims, please contact ULTIMEA customer service through their official website or the contact information provided in your product packaging.

**Service Promise:**

- Pre-Sale Consultation
- 7/24 Service
- Worry-Free Warranty

For the most up-to-date support information and resources, visit the official ULTIMEA website:www.ultimea.com

© 2025 ULTIMEA. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question