

IDEALHOUSE Dresser-250424001

IDEALHOUSE Farmhouse 5-Drawer Dresser

INSTRUCTION MANUAL - MODEL: DRESSER-250424001

1. Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Always use proper lifting techniques when moving the dresser to prevent injury.
- Be cautious when operating the sliding barn door to avoid pinched fingers.
- Ensure all hardware is securely tightened during assembly. Periodically check and re-tighten hardware as needed.
- Install the anti-collapse device to prevent tipping. This is crucial for the safety of children and pets.
- Do not allow children to climb on or play with the dresser.
- Distribute weight evenly in drawers and on shelves to maintain stability.

2. Product Overview

The IDEALHOUSE Farmhouse 5-Drawer Dresser is designed for versatile storage in various rooms. It features a space-saving vertical design with five drawers and a sliding barn door that conceals adjustable shelving.



Image 2.1: Front view of the assembled IDEALHOUSE Farmhouse 5-Drawer Dresser in grey finish, featuring five drawers and a sliding barn door.

Key Features:

- **Space-Saving Design:** Overall dimensions of 15.7"D x 31.3"W x 48"H, ideal for compact spaces.
- **Dual-Size Drawers:** Three smaller top drawers (11.8"D x 12.2"W x 6.5"H) and two larger bottom drawers (11.8"D x 26.7"W x 6.5"H) for varied storage needs.
- **Sliding Barn Door:** A smooth-gliding barn door conceals three adjustable and removable shelves.
- **Durable Construction:** Made from high-quality engineered wood with reinforced panels and a scratch-resistant, water-resistant 3D wood grain finish.
- **Anti-Collapse Design:** Includes hardware to secure the dresser to a wall, enhancing safety.



Image 2.2: Diagram illustrating the overall dimensions of the dresser (15.7"D x 31.3"W x 48"H) and individual drawer dimensions.

3. Setup and Assembly

Assembly is required for this dresser. It is recommended to have two people for assembly. Ensure you have adequate space and the necessary tools (typically a screwdriver and hammer, not included).

Before You Begin:

1. Unpack all components and lay them out on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches.
2. Verify all parts against the included parts list in your package. If any parts are missing or damaged, contact customer support immediately.
3. Familiarize yourself with the hardware and assembly steps by reviewing the provided instruction booklet.

Assembly Steps (General Guidance):

1. Assemble the main frame of the dresser according to the step-by-step instructions. Ensure all pre-drilled holes align correctly.
2. Attach the drawer slides to the dresser frame and to the drawer components.
3. Assemble the drawers, ensuring the bottoms are securely in place and the handles are attached.
4. Install the sliding barn door track and attach the barn door. Test its smooth operation.
5. Insert the adjustable shelves into the cabinet section behind the barn door.

6. **Install the Anti-Collapse Device:** Secure the dresser to a wall stud using the provided anti-collapse hardware. This step is critical for safety.



Image 3.1: The dresser positioned in a bedroom, showcasing its aesthetic integration.



Adjustable Shelves

Storing items of different sizes

Smooth-gliding Drawers

Quiet operation to your items



Metal Corner Ornament

Attractive farmhouse decor that stands out

Image 3.2: Illustration of the anti-collapse design, demonstrating how to secure the dresser to a wall to prevent tipping.

4. Operating and Usage

This dresser is designed for organizing clothes, linens, utensils, and other daily items. Its versatile design allows it to be used in bedrooms, hallways, living rooms, or kitchens.

Drawers:

- The dresser features three smaller top drawers and two wider bottom drawers.
- Drawers are equipped with smooth-gliding mechanisms for quiet operation.
- To open, gently pull the drawer handle. To close, push firmly until the drawer is fully seated.




Image 4.1: The dresser with all five drawers partially open, demonstrating the storage capacity and drawer configuration.

Sliding Barn Door and Adjustable Shelves:

- The barn door slides smoothly along a metal track to reveal or conceal the interior shelves.
- The three shelves behind the barn door are adjustable and removable, allowing for customized storage configurations.
- To adjust a shelf, carefully lift it and reposition it into the desired shelf pin holes. Ensure it is level and secure before placing items on it.

Sliding Barn Doors



Space-saving and Easy Access

This dresser is equipped with sliding barn doors that smoothly glide open to reveal a roomy storage space. With this convenient design, you can effortlessly retrieve and arrange your belongings, making it an ideal complement to any room in your home. No more digging through messy drawers to find what you need!

Image 4.2: A close-up view of the sliding barn door mechanism, highlighting the metal track and door design.

Anti-collapse Design

Protect your kids and pets




Image 4.3: A composite image showing details of the adjustable shelves, smooth-gliding drawers, and the decorative metal corner ornament.

5. Maintenance

Proper care will ensure the longevity and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage. The finish is water-resistant but not waterproof.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten as necessary to maintain structural integrity.
- **Placement:** Avoid placing the dresser in direct sunlight or near heat sources, which can cause fading or warping.

6. Troubleshooting

If you encounter issues during assembly or use, refer to the following common problems and solutions:

- **Missing or Damaged Parts:** If you find any parts missing or damaged upon opening the package, do not proceed with assembly. Contact IDEALHOUSE customer support immediately for assistance.
- **Drawers Do Not Slide Smoothly:** Ensure the drawer slides are correctly installed and aligned. Check for any obstructions in the tracks. Verify that all screws securing the slides are tight.
- **Parts Do Not Align:** Double-check the assembly steps and ensure you are using the correct parts for each step. Sometimes, parts may appear similar but have subtle differences. Loosen connections slightly, adjust alignment, and then re-tighten.
- **Dresser Wobbles:** Ensure the dresser is placed on a level surface. Check that all assembly hardware is fully tightened. If wobbling persists, verify that the anti-collapse device is securely installed.

7. Specifications

Attribute	Detail
Brand	IDEALHOUSE
Model Name	Dresser-250424001
Product Dimensions (D x W x H)	15.7"D x 31.3"W x 48"H
Color	Grey
Item Weight	104.5 Pounds
Assembly Required	Yes
UPC	199414170727
Recommended Uses	Clothes, Daily items, Decorative items, Kitchenware, Linens, Utensils

8. Warranty and Support

IDEALHOUSE is committed to customer satisfaction. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact our customer support team.

- **Customer Support:** Refer to the contact information provided in your product packaging or on the IDEALHOUSE official website.
- **Warranty Information:** Specific warranty details are typically included with your purchase documentation. Please retain your proof of purchase for any warranty claims.

