MONSGA MR1 SE

MONSGA MR1 SE Robot Vacuum Cleaner Instruction Manual

Model: MR1 SE
Brand: MONSGA

1. Introduction

Thank you for choosing the MONSGA MR1 SE Robot Vacuum Cleaner. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

The MONSGA MR1 SE is designed to simplify your cleaning routine with its powerful 4000Pa suction, ultra-slim profile, and intelligent navigation. It features multiple cleaning modes, smart app control, voice command compatibility, and automatic recharging, making it suitable for various floor types and household needs.

2. Safety Information

To reduce the risk of injury or damage, read and follow all safety precautions. This device is for indoor use only. Do not use it in wet environments or on wet surfaces. Keep hair, loose clothing, fingers, and all body parts away from openings and moving parts. Do not operate the robot in areas where there are lit candles or fragile objects. Supervise children and pets when the robot is operating.

- Ensure the charging dock is placed against a wall on a level surface.
- Do not use the robot to pick up large debris, liquids, or burning objects.
- Regularly clean the brushes and filters to maintain optimal performance.
- Only use the original power adapter and charging dock provided with the device.

3. Package Contents

Verify that all items are present in your package:

- MONSGA MR1 SE Robot Vacuum (x1)
- Self-Charging Station (x1)
- Remote Control (x1)
- AAA Batteries (x2, for remote)
- User Manual (x1)

- Dustbox (340ml, pre-installed)
- Mop Cloth (x1)
- HEPA Filter (x1, extra)
- Side Brush (x2, extra)
- Cleaning Tool (x1)



Image: All components included in the MONSGA MR1 SE Robot Vacuum Cleaner package, laid out on a table.

4. Setup

4.1 Initial Preparation

1. **Unpack the Robot:** Carefully remove the robot vacuum and all accessories from the packaging.
2. **Remove Protective Strips:** Locate and remove all protective films and bumper strips from the robot. Ensure the side brushes are securely attached.
3. **Install Remote Batteries:** Open the battery compartment on the remote control and insert the two AAA batteries

provided, observing polarity.

4. **Position the Charging Dock:** Place the charging dock against a wall in an open, uncluttered area. Ensure there is at least 0.5 meters (1.6 feet) of clear space on either side and 1.5 meters (4.9 feet) in front of the dock. Plug the power adapter into the charging dock and then into a wall outlet.
5. **First Charge:** Place the robot onto the charging dock. The indicator light on the robot will pulse during charging. For optimal battery life, fully charge the robot before its first use (approximately 5-6 hours).

4.2 App Connection

The MONSGA MR1 SE can be controlled via the SmartLife or TuyaSmart app for advanced features and scheduling.

1. Download the SmartLife or TuyaSmart app from your phone's app store.
2. Press and hold the 'On & Off' button on the robot for 5 seconds until the light flashes, indicating pairing mode.
3. Turn on your phone's Bluetooth. Open the app, tap the '+' icon at the top right corner, and select 'Add Device'.
4. Connect your phone to a 2.4GHz Wi-Fi network.
5. Follow the in-app instructions to complete the connection. The app will show 'Added successfully' when the light stops flashing.



Image: Visual guide for connecting the robot vacuum to the SmartLife mobile application.

5. Operating Instructions

5.1 Control Methods

The MONSGA MR1 SE offers multiple ways to initiate and manage cleaning:

- **Button Control:** Press the power button on the robot's top panel to start or pause cleaning. Press and hold to send it back to the charging dock.
- **Remote Control:** Use the included remote for basic functions like starting/pausing, changing cleaning modes, and directing the robot.
- **App Control:** The SmartLife or TuyaSmart app provides full control, including scheduling, mode selection, real-time status monitoring, and cleaning path visualization.
- **Voice Control:** Integrate with Amazon Alexa or Google Assistant for hands-free operation. Simply use voice

commands to start, stop, or send the robot to its dock.




Image: The remote control for the robot vacuum, highlighting its various functions.



Remote Control: No WiFi Needed

Perfect for kids, seniors, or no-WiFi homes—just press buttons to start cleaning, spot-clean, or edge-clean. Simple, no app required!




Image: The mobile application interface for controlling the robot vacuum, showing scheduling and mode selection options.

Button Control: Start, Pause, Dock

No app needed—press the top buttons to power on, pause mid-clean, or send it back to charge. Perfect for quick controls without your phone!





Image: The robot vacuum being controlled via voice commands using smart home assistants.

5.2 Cleaning Modes

The robot offers diverse cleaning modes to suit different needs:

- **Auto Mode:** The robot intelligently navigates and cleans your entire floor area, adjusting suction for different surfaces.
- **Spot Mode:** Targets specific areas with concentrated dirt or spills for intensive cleaning.
- **Edge Mode:** Cleans along walls and furniture edges to ensure thorough coverage.
- **Manual Mode:** Allows you to direct the robot's movement using the app or remote control for precise cleaning.



Image: Visual representation of the robot vacuum performing various cleaning modes in different room layouts.

5.3 Smart Features

- **Powerful Suction:** Equipped with 4000Pa suction power, the robot effectively picks up dust, pet hair, and debris from hard floors and low-pile carpets.
- **Ultra-Slim Design:** At just 3.2 inches tall, the MR1 SE can easily clean under furniture like beds, sofas, and cabinets.

- **Adaptive Carpet Boost:** The robot automatically detects carpeted surfaces and increases suction power for deeper cleaning.
- **Anti-Collision and Anti-Fall System:** High-precision infrared obstacle detectors and cliff sensors enable the robot to navigate around obstacles and avoid stairs.
- **Automatic Recharging:** When the battery level drops below 15%, the robot automatically returns to its charging dock to recharge, ensuring it's always ready for the next cleaning cycle.
- **Scheduled Cleaning:** Use the app to set daily or weekly cleaning schedules, allowing the robot to clean automatically at your preferred times.



Image: The robot vacuum showcasing its 4000Pa suction power on a carpet, effectively removing debris.



Image: The robot vacuum's slim design allows it to clean under low-clearance furniture.



Image: The robot vacuum automatically increasing suction power when moving onto a carpet.




Image: The robot vacuum utilizing its smart sensors to avoid collisions and drops.



Image: The robot vacuum automatically docking for recharge when its battery level is low.

5.4 Official Product Video

Your browser does not support the video tag.

Video: An official product video from MONSGA showcasing the features and operation of the MR1 SE Robot Vacuum. This video demonstrates its slim design, powerful suction, various cleaning modes, and smart navigation capabilities.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your robot vacuum.

6.1 Dustbin and Filter

1. **Empty the Dustbin:** Press the dustbin release button and pull out the dustbin. Open the dustbin cover and empty its contents into a trash bin.

2. **Clean the Filter:** Remove the HEPA filter and foam filter from the dustbin. Tap them gently to remove dust. Rinse the foam filter and dustbin with water (do not rinse the HEPA filter). Allow all parts to air dry completely before reassembling.
3. **Replace Filter:** Replace the HEPA filter every 3-6 months, or as needed, to maintain filtration efficiency.



Image: The spacious 550ml dustbin and high-efficiency HEPA filter, demonstrating ease of removal and cleaning.

6.2 Side Brushes and Main Brushroll

1. **Clean Side Brushes:** Regularly check the side brushes for tangled hair or debris. Gently pull them off to remove any obstructions.
2. **Clean Main Brushroll:** Turn the robot over and remove the main brush cover. Lift out the brushroll and use the provided cleaning tool to remove any tangled hair or debris.
3. **Replace Brushes:** Replace side brushes every 3-6 months and the main brushroll every 6-12 months, or when visibly worn.

7. Troubleshooting

If you encounter issues with your MONSGA MR1 SE, refer to the following common solutions:

- **Robot not turning on:** Ensure the robot is fully charged. Check if the power button is pressed correctly.
- **Robot not charging:** Verify the charging dock is powered on and the robot is correctly aligned with the charging contacts. Clean the charging contacts on both the robot and the dock.
- **Robot getting stuck frequently:** Clear obstacles from the cleaning path. Ensure the robot's sensors are clean.
- **Poor cleaning performance:** Empty the dustbin and clean the filters. Check and clean the side brushes and main brushroll for tangled hair or debris.
- **App connection issues:** Ensure your Wi-Fi network is 2.4GHz. Restart your router, phone, and robot. Try re-pairing the device through the app.

For more detailed troubleshooting or persistent issues, please contact MONSGA customer support.

8. Specifications

Feature	Detail
Brand	MONSGA
Model Name	MR1 SE
Suction Power	4000Pa
Product Dimensions	11.4"L x 11.4"W x 3.4"H
Battery Life	140 minutes
Coverage Area	Up to 1,500 sqft
Dustbin Capacity	340ml
Filter Type	HEPA Filter
Control Methods	App, Push Button, Remote, Voice (Alexa/Google Assistant)
Compatible Devices	Amazon Echo, Google Home, Smartphones, Tablets
Item Weight	6.71 pounds
Power Source	Battery Powered
Surface Recommendation	Hard Floor, Low-Pile Carpet, Hardwood Floor, Laminate, Luxury Vinyl, Tile

9. Warranty and Support

MONSGA is committed to product quality and customer satisfaction. The MONSGA MR1 SE Robot Vacuum Cleaner comes with a **2-year warranty service** and **lifetime technical support**.

If you have any questions, suggestions, or require assistance, please do not hesitate to contact the MONSGA After-sales Team. We aim to provide a quick response within 24 hours.

Thank you for choosing MONSGA.

© 2025 MONSGA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question