Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Casaottima B01172301003

Casaottima 48 Inch Gaming Desk Instruction Manual

Model: B01172301003 | Brand: Casaottima

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Casaottima 48 Inch Gaming Desk. Please read all instructions carefully before assembly and use to ensure proper function and safety.

Safety Information

- Keep all small parts and packaging materials away from children.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload the desk or shelves beyond their stated weight capacity.
- Avoid placing hot items directly on the desktop surface without protection.



Image 1.1: The Casaottima 48 Inch Gaming Desk, showcasing its LED lighting and integrated storage solutions.

2. Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Included Components:

- Desktop Panel (Carbon Fiber Texture)
- Metal Frame Components (Legs, Support Bars)
- Display Shelves
- Fabric Drawer
- LED Light Strip with Remote Control
- Headphone Hook (2 units)

- Assembly Hardware (Screws, Allen Wrench, etc.)
- Instruction Manual

3. Setup and Assembly

Assembly is required for this computer desk. All necessary tools and instructions are included. It is recommended to assemble the desk with two people.

Reversible Design

The storage shelf unit can be assembled on either the right or left side of the desk to suit your room layout or personal preference. Plan your desired orientation before starting assembly.




Image 3.1: The desk's reversible design allows the storage unit to be placed on either side.

Assembly Steps:

1. Unpack all components and verify against the package contents list.
2. Identify the main metal frame components.
3. Attach the desk legs to the main desktop panel using the provided hardware. Do not fully tighten screws until all components are aligned.
4. Assemble the storage shelf unit, deciding on the left or right orientation.
5. Integrate the storage shelf unit with the main desk frame.

6. Insert the fabric drawer into its designated slot within the storage unit.
7. Attach the headphone hooks to the side of the desk as desired.
8. Once all components are in place and aligned, securely tighten all screws.
9. Install the LED light strip according to the separate instructions provided with the lighting kit.

4. Operating Instructions

LED Lighting System

The built-in RGB LED strip offers customizable lighting to enhance your gaming or work environment. It features 16 colors and 10 dynamic modes, controlled by a remote.



Image 4.1: The remote control for the RGB LED light strip, showing various color and mode options.

Remote Control Functions:

- **On/Off:** Power button to turn the lights on or off.
- **Color Selection:** Buttons for 16 static colors (R, G, B, W, and various shades).
- **Dynamic Modes:** Cycle through 10 dynamic lighting effects.
- **Brightness Control:** Adjust the intensity of the lights.
- **Speed Control:** Adjust the speed of dynamic modes.
- **Timing Function:** Set a timer for the lights to turn off automatically.

Storage Solutions

The desk is designed with multiple storage options to keep your workspace organized.



Image 4.2: Overview of the desk's storage features.

- **Elevated Tower Platform:** Provides a dedicated space for your gaming PC case, keeping it off the floor.
- **Fabric Drawer:** A soft-sided drawer for storing accessories, cables, or personal items.
- **Bottom Storage Shelf:** Additional space for books, games, or other equipment.
- **Side Headphone Hooks:** Conveniently hang headphones or other peripherals.

5. Maintenance and Care

To ensure the longevity and appearance of your Casaottima Gaming Desk, follow these maintenance guidelines:

- **Cleaning the Desktop:** The carbon fiber textured desktop is scratch-resistant and water-resistant. Wipe with a soft, damp cloth and mild detergent if necessary. Avoid abrasive cleaners.
- **Frame Care:** Clean the metal frame with a soft, dry cloth.
- **Fabric Drawer:** Spot clean the fabric drawer with a mild fabric cleaner. Do not machine wash.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **LED Strip:** Ensure the LED strip and its connections are dry and free from dust.



Image 5.1: The carbon fiber textured desktop is designed for durability and easy cleaning.

6. Troubleshooting

Problem	Possible Cause	Solution
Desk is wobbly after assembly.	Screws are not fully tightened or desk is on an uneven surface.	Ensure all assembly screws are securely tightened. Adjust the desk's position or use leveling pads if the floor is uneven.
LED lights are not turning on.	Power connection issue, remote battery low, or LED strip malfunction.	Check if the LED strip is properly plugged into a power source. Replace the remote control battery. Ensure the remote is pointed directly at the receiver.
Fabric drawer does not slide smoothly.	Drawer is overloaded or misaligned.	Reduce the weight in the drawer. Ensure the drawer is correctly seated in its slot and not obstructed.

7. Specifications



Image 7.1: Key dimensions of the Casaottima 48 Inch Gaming Desk.

Feature	Detail
Brand	Casaottima
Model Number	B01172301003
Product Dimensions (D x W x H)	18.9"D x 47.24"W x 45.28"H
Item Weight	12.55 Kilograms
Color	Carbon Fiber Black
Material	Carbon Fiber (Top), Metal (Base)
Special Feature	Reversible Design, LED Lights, Storage Shelves, Fabric Drawer, Headphone Hook
Number of Drawers	1
Number of Shelves	2
Assembly Required	Yes (All tools included)

8. Warranty and Support

Customer Service

If you encounter any product problems related to assembly, damage, or have questions, please contact Casaottima customer service directly. Refer to the contact information provided with your purchase or on the official Casaottima website.
For general inquiries or to visit the brand store, please refer to the following link:Casaottima Store

Warranty Information

Specific warranty details are typically provided with your purchase documentation. Please retain your proof of purchase for warranty claims. Protection plans may also be available for extended coverage.

© 2025 Casaottima. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F66KXN58

More documents and user manuals: **https://manuals.plus/**