

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [roborock](#) /

› [roborock F25 RT Wet Dry Vacuum Cleaner & Washable Filter Replacement User Manual](#)

## roborock F25 RT

# roborock F25 RT Wet Dry Vacuum Cleaner & Washable Filter Replacement User Manual

Brand: roborock | Model: F25 RT

## PRODUCT OVERVIEW

The roborock F25 RT is an advanced wet and dry vacuum cleaner designed for comprehensive hard floor cleaning. It combines powerful suction with efficient mopping capabilities, featuring innovative self-cleaning and drying technologies to ensure optimal performance and hygiene. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.



Image: The roborock F25 RT wet dry vacuum cleaner shown with its included washable filters and floor cleaning solution.

## Key Features:

- **All-in-One Hard Floor Cleaning:** Combines wet dry vacuuming with 180° flat reach for comprehensive cleaning.
- **Powerful Mopping Performance:** Features 20000Pa suction power and 450 rpm spin mopping for effective dirt removal.
- **Hot Water Self-Cleaning & Hot Air Drying:** Utilizes 194°F hot water for self-cleaning and 194°F hot air for drying, preventing odors and ensuring hygiene.
- **Easy Filter Replacement:** Designed for quick and effortless filter changes without tools.
- **High Performance Filter:** Teflon-coated filter accessory provides long-lasting, effective air filtration.

## SETUP AND INITIAL USE

## 1. Unpacking and Assembly

Carefully remove all components from the packaging. Ensure all parts listed in the packing list are present. Assemble the handle to the main body of the vacuum cleaner by aligning the connection points and pushing firmly until it clicks into place.

## 2. Battery Installation and Charging

Insert the battery pack into its designated slot on the vacuum cleaner. Ensure it is securely seated. For first-time use, fully charge the device. Place the vacuum cleaner on its charging dock. The charging indicator lights will illuminate to show charging status. A full charge typically takes several hours.

# Easy to Install



Image: A user demonstrating the easy installation of the battery pack into the roborock F25 RT vacuum cleaner.

## 3. Filling the Clean Water Tank

Locate the clean water tank. Open the cap and fill it with clean tap water. For enhanced cleaning, you may add a small amount of roborock-approved floor cleaning solution, following the solution's instructions for dilution. Close the cap securely and reinsert the tank into the device.

## OPERATING INSTRUCTIONS

### 1. Powering On and Selecting Mode

Press the power button to turn on the roborock F25 RT. The device will typically start in a default cleaning mode. Use the mode selection button to switch between different cleaning modes, such as standard wet vacuuming, dry vacuuming, or specific spot cleaning functions, if available.



Image: An illustration highlighting the core functionalities of the roborock F25 RT, including its powerful suction, hot water cleaning, and flexible design.

### 2. Cleaning Performance

The roborock F25 RT delivers 20000Pa suction power and 450 rpm spin mopping to effectively clean various hard floor surfaces. Guide the vacuum cleaner across the floor at a steady pace. For heavily soiled areas, you may need to pass over them multiple times.

## 20000Pa Vacuum & Mop All in One



Image: A visual demonstration of the roborock F25 RT's cleaning efficacy, illustrating a floor before and after a liquid mess has been cleaned.

### 3. Reaching Difficult Areas

The 180° lie-flat design allows the roborock F25 RT to reach under furniture and into tight spaces with ease, ensuring thorough cleaning even in hidden areas.

## Zero-Tangle & Streak Free



Image: The roborock F25 RT demonstrating its 180-degree lie-flat capability, allowing it to clean effectively under low-clearance furniture.

### 4. Compatibility

This product, including its washable filter replacement, is specifically designed for compatibility with the roborock F25 Series Wet Dry Vacuum Cleaner.

# Compatible With roborock



Image: The roborock F25 RT vacuum cleaner with an overlay indicating its compatibility with the F25 series filter, emphasizing seamless integration.

## MAINTENANCE

### 1. Hot Water Self-Cleaning and Hot Air Drying

After each use, return the roborock F25 RT to its charging dock to initiate the self-cleaning cycle. The device uses 194°F hot water to clean the roller brush and internal components, effectively melting grease and debris. Following the wash, 194°F hot air drying eliminates moisture and odors, ensuring the device remains clean and ready for its next use.

# Leave the Dirty Work to Itself



**194°F**

**Hot Water Self-Cleaning**  
Makes it Complete Clean

**194 °F**

**Hot Air Drying**  
Makes it Truly Dry



Image: A visual explanation of the roborock F25 RT's automated self-cleaning and drying functions, highlighting the use of high-temperature water and air.

## 2. Emptying the Dirty Water Tank

Regularly empty the dirty water tank after each cleaning session. Remove the tank, open its lid, and dispose of the dirty water. Rinse the tank with clean water to prevent residue buildup and odors. Reinstall the tank securely.

## 3. Filter Cleaning and Replacement

The washable filter should be cleaned regularly to maintain optimal suction and air filtration. Remove the filter from its compartment. Rinse it under running water until clean. Allow the filter to air dry completely before reinserting it. For best performance, replace the filter periodically, especially if you notice a decrease in suction or an increase in motor noise.

# Reusable and Washable




Image: A washable filter being cleaned under running water, illustrating its design for repeated use and easy maintenance.

## 4. Roller Brush Maintenance

Periodically inspect the roller brush for tangled hair or debris. The roborock F25 RT features dual scrapers to achieve a 0% tangle rate, minimizing hair wrap. If necessary, remove the roller brush and use the provided cleaning tool or scissors to cut and remove any entangled hair or fibers. Rinse the brush if needed and allow it to dry before reinstallation.

## 180° Lie-Flat Design for Hidden Areas



4.92 inch: Based on internal testing carried out by the manufacturer.

Image: A detailed view of the roborock F25 RT's roller brush system, highlighting the dual scrapers designed to prevent hair tangles and ensure streak-free cleaning.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Battery is not charged or not properly installed.	Ensure the battery is fully charged and correctly inserted. Check charging dock connection.
Poor suction performance.	Dirty filter, clogged air duct, or full dirty water tank.	Clean or replace the filter. Check for and clear any blockages in the air duct. Empty the dirty water tank.

Problem	Possible Cause	Solution
Water streaks on floor.	Dirty roller brush or insufficient water flow.	Clean the roller brush thoroughly. Ensure the clean water tank is filled and properly installed.
Unpleasant odor from device.	Dirty water tank or roller brush not properly dried.	Empty and rinse the dirty water tank immediately after use. Ensure the self-cleaning and hot air drying cycle completes fully. Manually dry components if necessary.

If the problem persists after attempting these solutions, please refer to the warranty and support section for further assistance.

## SPECIFICATIONS

**Model:** F25 RT

**Type:** Wet Dry Vacuum Cleaner

**Suction Power:** 20000Pa

**Roller Brush Speed:** 450 rpm

**Self-Cleaning Water Temperature:** 194°F (90°C)

**Drying Air Temperature:** 194°F (90°C)

**Design Feature:** 180° Lie-Flat

**Filter Type:** Washable, Teflon-coated

**ASIN:** B0F66N8YVG

## WARRANTY AND SUPPORT

robôrock products are manufactured to high quality standards and are covered by a limited warranty from the date of purchase. Please refer to the warranty card included with your product for specific terms and conditions, including warranty period and coverage details.

For technical support, troubleshooting assistance beyond what is provided in this manual, or warranty claims, please contact robôrock customer service. Contact information can typically be found on the official robôrock website or on the product packaging.

When contacting support, please have your product model (F25 RT) and purchase information readily available to expedite the process.

© 2024 roborock. All rights reserved.