



[Manuals.plus](#) /

> [Devoko](#) /

> Devoko 8'x8' Outdoor Gazebo Instruction Manual

Devoko 8'x8' Outdoor Gazebo

Devoko 8'x8' Outdoor Gazebo Instruction Manual

Model: 8'x8' Outdoor Gazebo

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Devoko 8'x8' Outdoor Gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and safe use of your gazebo.

SAFETY INSTRUCTIONS

Adhering to these safety guidelines is crucial for preventing injury and damage to the product.

- Always assemble and disassemble the gazebo with care, following the provided instructions.
- Keep children and pets away from the assembly area to prevent accidents.
- Secure the gazebo to a stable foundation using the provided expansion bolts or other appropriate anchoring methods to prevent it from tipping over, especially in windy conditions.
- Do not use the gazebo in thunderstorms, during high winds, or heavy snowfall. Disassemble or secure the canopy during severe weather to prevent damage.
- Inspect the gazebo regularly for any damage, loose connections, or wear and tear on the frame and canopy. Perform necessary maintenance to ensure its safety and longevity.
- Ensure all parts are correctly installed and tightened before use.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed in the parts diagram (refer to the separate parts list document) are present and undamaged. If any parts are missing or damaged, contact customer support.

Product Size

8FT x 8FT



1 paper box



Sunshade



Easy to install



Waterproof



Convenient

Image: Product Size Diagram. This image illustrates the overall dimensions of the 8'x8' gazebo, including height and footprint, and indicates it comes in one package.

SETUP AND ASSEMBLY

Assembly typically requires two or more adults. Follow the steps below in sequence. Do not overtighten bolts until instructed.

- 1. Prepare the Area:** Choose a flat, level surface for assembly. Clear the area of any obstructions.
- 2. Unpack Components:** Carefully unpack all parts and lay them out. Refer to the parts list to identify each component.
- 3. Assemble the Base Frame:** Connect the horizontal base beams to the vertical support posts. Ensure all connections are secure but do not fully tighten bolts yet.
- 4. Install Vertical Posts:** Attach the main vertical posts to the base frame.
- 5. Construct the Roof Frame:** Assemble the upper roof frame structure. This typically involves connecting various beams and connectors to form the double-layer roof design.

6. **Attach Roof Frame to Posts:** Carefully lift and secure the assembled roof frame onto the vertical posts. Tighten all frame bolts once the entire structure is upright and stable.
7. **Install Canopy:** Drape the main canopy fabric over the roof frame. Secure it using the integrated fasteners or ties. Ensure the double-layer roof is properly aligned for ventilation and drainage.
8. **Attach Mosquito Nettings and Privacy Screens:** Hang the mosquito nettings and privacy screens from the designated tracks or hooks on the frame. Use the high-quality Velcro straps to secure them as needed.
9. **Anchor the Gazebo:** Secure the gazebo to the ground using the provided expansion bolts or other suitable anchoring hardware. This is critical for stability and safety.



Product Details


Thoughtful And Rational Design
To Add Comfort To Your Outdoor Time



Minimalist
Form Factor




Stable Steel Frame
Construction



01

Anchorage Frame



02

High Quality Velcro



03

Triangular Solid Structure

Image: Product Details. This image highlights key structural features such as the anchorage frame for securing the gazebo, high-quality Velcro for curtains, and the triangular solid structure for enhanced stability.

OPERATING INSTRUCTIONS

Your Devoko gazebo is designed for outdoor use, providing shade and a comfortable space.

- **Mosquito Nettings and Privacy Screens:** Utilize the zipper mesh curtains to block insects and provide

privacy. They can be easily opened and closed as desired.

- **Ventilation:** The double-layer roof design promotes air circulation, helping to keep the interior cool.
- **Accessory Hook:** A top hook is provided for hanging lightweight items such as a chandelier or a small fan (ensure weight limits are observed and electrical safety precautions are followed).
- **Weather Protection:** The canopy offers UV protection and is designed to be waterproof. However, it is not intended for use in extreme weather conditions.




Image: Mosquito Netting and Quality Fabric Curtains. This image details the fine mesh of the mosquito netting and the texture of the quality fabric curtains, highlighting their function for insect protection and privacy.



UV PROTECTION

Helps protect you from UV rays



SNOW LOAD

Withstands up to 4 inches of snow



RAINWATER PROOF

Prevent rain from invading your outdoor life

Image: Weather Protection Features. This image illustrates the gazebo's capabilities regarding UV protection, resistance to up to 4 inches of snow load, and rainwater proofing, emphasizing its suitability for various weather conditions.

MAINTENANCE

Regular maintenance will extend the life of your gazebo.

- **Cleaning the Canopy:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before storage.
- **Frame Cleaning:** Wipe the metal frame with a damp cloth. For stubborn dirt, use mild soap and water. Ensure the frame is dry to prevent rust.
- **Hardware Check:** Periodically check all bolts and connections to ensure they remain tight. Retighten as necessary.
- **Winter Storage:** In areas with heavy snow or prolonged freezing temperatures, it is recommended to remove the canopy and store it indoors to prevent damage. The frame can remain outdoors if properly anchored and maintained.

- **Drainage:** The double-layer roof includes drainage holes to prevent water accumulation. Ensure these remain clear of debris.

TROUBLESHOOTING

If you encounter issues with your gazebo, refer to the following common solutions:

- **Gazebo feels unstable:** Ensure all frame bolts are fully tightened. Verify that the gazebo is properly anchored to a solid surface using all provided expansion bolts. Check that the ground is level.
- **Water pooling on canopy:** Check if the canopy is stretched taut and correctly installed on the roof frame. Ensure the double-layer roof is properly aligned and drainage holes are clear. Heavy rain may still cause some temporary pooling, but the design includes drainage.
- **Curtains/Nettings not closing properly:** Inspect the zippers for obstructions or damage. Ensure the Velcro straps are aligned and clean. Check if the tracks are clear.
- **Parts missing or damaged during assembly:** Review the package contents list. Contact Devoko customer support immediately for replacement parts.

SPECIFICATIONS

| Feature | Detail |
|--------------------------------|---|
| Brand | Devoko |
| Model | 8'x8' Outdoor Gazebo |
| Product Dimensions (L x W x H) | 96"L x 96"W x 108"H (8'L x 8'W x 9'H) |
| Frame Material | Alloy Steel (Powder Coated) |
| Canopy Material | High-quality fabric (Waterproof, UV Protection) |
| Color | Gray |
| Water Resistance Level | Waterproof |
| Ultraviolet Light Protection | UV Protection |
| Shape | Rectangular |
| Occupancy | 4-5 People |
| Assembly Required | Yes |

WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical support, please contact Devoko customer service. Keep your purchase receipt and model information handy when contacting support.

Contact information can typically be found on the product packaging or the official Devoko website.

