

BUGANI Brief Pro

BUGANI Shock Bluetooth Speaker User Manual

Model: Brief Pro

1. PRODUCT OVERVIEW

The BUGANI Shock Bluetooth Speaker is a powerful and portable audio device designed for both indoor and outdoor use. Featuring 60W super power output, Bluetooth 5.4 connectivity, and IPX6 waterproofing, it delivers robust sound quality and durability. Its long-lasting battery also functions as a power bank for your mobile devices.



Front view of the BUGANI Shock Bluetooth Speaker, showcasing its rugged design and orange accents.

2. WHAT'S IN THE BOX

Upon unboxing your BUGANI Shock Bluetooth Speaker, please ensure all the following items are present:

- BUGANI Shock Bluetooth Speaker
- Type-C Charging Cable
- AUX Cable
- User Manual (this document)
- Quick Start Guide



Image showing the BUGANI Shock speaker, user manual, and charging cables included in the package.

3. KEY FEATURES

3.1. Powerful Audio System

The speaker features two mid-bass external magnetic speakers, two tweeters, and two subwoofer diaphragms. With 60 watts of power, it delivers robust sound quality with deep bass and clear treble, providing surprisingly loud, room-filling volume without distortion, even at maximum levels.

HD SOUND SPEAKER

powerful treble and deep bass



An exploded view illustrating the internal speaker components, including the drivers and passive radiators, designed for powerful treble and deep bass.

3.2. Advanced Bluetooth 5.4 Connectivity

Equipped with the latest Bluetooth 5.4 technology, the speaker ensures faster connection speeds, more stable signal transmission, and lower power consumption. It offers a wireless connection range of up to 100 feet, allowing seamless pairing with mobile phones, computers, and MP3 players. A built-in microphone supports hands-free calls.

3.3. True Wireless Stereo (TWS) Functionality

For an enhanced audio experience, you can connect two BUGANI Shock speakers together to achieve a combined 120W stereo surround sound. This feature creates a dynamic and immersive listening environment.



Two BUGANI Shock speakers wirelessly connected, demonstrating the True Wireless Stereo feature for a more powerful sound experience.

3.4. IPX6 Waterproof Rating

The BUGANI Shock speaker boasts an IPX6 waterproof mechanical casing, making it resistant to high-pressure, heavy sprays of water. This robust design ensures durability and reliability for outdoor adventures, whether at the beach, by the pool, or during camping trips.

IPX6 Waterproof



The BUGANI Shock speaker positioned near a pool, illustrating its IPX6 waterproof capability, suitable for wet environments.

3.5. Built-in Power Bank Function


The speaker includes a massive built-in battery that provides up to 32 hours of playtime on a single charge. Additionally, it can function as a power bank, allowing you to charge your smartphone or other USB-powered devices via a USB cable, ensuring your devices stay powered during outdoor activities.



A visual representation of the BUGANI Shock speaker's power bank function, showing it charging a mobile phone via a USB cable.

3.6. Dual EQ Modes (Indoor/Outdoor)

The speaker offers two equalization (EQ) modes, optimized for indoor and outdoor listening environments, allowing you to adjust the sound profile for the best audio experience wherever you are.



The BUGANI Shock speaker in an outdoor party setting, highlighting its two EQ modes for optimized sound in different environments.

4. SETUP

4.1. Charging the Speaker

1. Connect the provided Type-C charging cable to the speaker's charging port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Once fully charged, the light will change or turn off.

4.2. Bluetooth Pairing

1. Ensure the speaker is powered on. The Bluetooth indicator light will flash, indicating it's in pairing

mode.

2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "BUGANI Shock" from the list of devices.
4. Once connected, the Bluetooth indicator light will become solid, and you will hear an audible confirmation.

4.3. True Wireless Stereo (TWS) Pairing

To pair two BUGANI Shock speakers for TWS:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (often indicated by two interlocking circles or a similar icon) for a few seconds until you hear a pairing tone.
3. The primary speaker will automatically search for and connect to the secondary speaker.
4. Once successfully paired, both speakers will emit a confirmation tone, and their TWS indicator lights will become solid.
5. Now, connect your device to the primary speaker via Bluetooth as described in section 4.2. Audio will play through both speakers in stereo.

Official video demonstrating the features of the BUGANI SHOCKW Bluetooth Speaker, including its powerful sound, Bluetooth 5.3 connectivity, IPX6 waterproofing, and True Wireless Stereo pairing.

5. OPERATING INSTRUCTIONS

5.1. Controls Overview

Button/Port	Function
Power Button	Press and hold to power ON/OFF. Short press to play/pause music.
Volume +	Short press to increase volume.
Volume -	Short press to decrease volume.
Previous Track	Long press Volume - to go to previous track.
Next Track	Long press Volume + to go to next track.
Mode (M) Button	Short press to switch between Bluetooth, AUX, and TF Card modes.
TWS Button	Press and hold to initiate TWS pairing (see section 4.3).
AUX-in Port	Connect external audio devices via 3.5mm AUX cable.
TF Card Slot	Insert TF card for direct music playback.
USB-A Output Port	Use as a power bank to charge external devices.
USB-C Input Port	Charging port for the speaker.

5.2. Switching EQ Modes

The BUGANI Shock speaker features two EQ modes: Indoor and Outdoor. To switch between these modes, locate the dedicated EQ button (if present, otherwise it might be integrated with another button or automatic). Refer to the Quick Start Guide for specific button functionality related to EQ mode switching.

6. MAINTENANCE

6.1. Cleaning

Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure all ports are dry before charging or connecting cables.

6.2. Water Resistance (IPX6)

The IPX6 rating means the speaker can resist high-pressure, heavy sprays of water. It is not designed for submersion. Ensure the charging port cover is securely closed before exposing the speaker to water.

6.3. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to approximately 50% every few months to maintain battery health.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Speaker does not power on	Low battery	Charge the speaker fully.
Cannot pair via Bluetooth	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker	Ensure speaker is in pairing mode (flashing light). Turn on device Bluetooth. Move device closer to speaker (within 100ft).
No sound or low volume	Volume too low on speaker/device; Incorrect input mode; Not connected properly	Increase volume on both speaker and device. Press 'M' button to cycle through modes. Re-pair Bluetooth or re-connect AUX cable.
TWS pairing fails	Speakers already connected to other devices; Too far apart	Disconnect both speakers from any other Bluetooth devices. Ensure speakers are within close proximity during TWS pairing.
Charging external device fails	Speaker battery low; Incorrect cable	Ensure speaker has sufficient charge. Use a compatible USB cable for your device.

8. TECHNICAL SPECIFICATIONS

Specification	Value
Model Name	Brief Pro
Speaker Type	3D
Compatible Devices	MP3 Player, Tablet, Smartphone
Unit Count	1.0 Count
Surround Sound Channel Configuration	2.1


Specification	Value
Color	orange
Battery Life	32 Hours
Product Dimensions	3"D x 3"W x 3"H
Item Weight	7.26 pounds (3.3 Kilograms)
Is Waterproof	true (IPX6)
Maximum Range	100 Feet (Bluetooth)
Control Method	Remote (via connected device)
Wireless Communication Technology	Bluetooth
Power Source	Battery Powered
Number of Batteries	1 A batteries required (internal rechargeable)
Audio Driver Type	Dynamic Driver
Connectivity Protocol	Bluetooth, Auxiliary
Style	M83
Manufacturer	BUGANI
Speaker Maximum Output Power	160 Watts (Peak)
Audio Output Mode	Stereo, Surround

9. WARRANTY AND SUPPORT

The BUGANI Shock Bluetooth Speaker comes with a **Limited Warranty**. Please refer to the warranty card included in your package for specific terms and conditions.

BUGANI also offers **Lifetime Technical Support** for this product. If you encounter any issues or have questions not covered in this manual, please contact our support team:


- **Email:** support@bugani.com (example)
- **Phone:** 1-800-BUGANI (example)
- **Website:** [Visit the BUGANI Store on Amazon](#)



[Bugani Brief Pro Quick Start Guide](#)

A quick start guide for the Bugani Brief Pro real jazz music speaker, covering charging, power, Bluetooth connection, TWS mode, AUX input, button controls, and reset.

lang:en **score:49** filesize: 5.24 M page_count: 6 document date: 2025-03-21



[\[pdf\] Instructions Guide](#)

BUGANI M192 20250219 m192 instructions à bugani global BUGANi Brief Pro GUIDE DE
DEMARRAGE RAPIDE 20250321 v 1742890196 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO GUIDE DE DMARRAGE RAPIDE VRAI HAUT-PARLEUR DE MUSIQUE
JAZZ CHARGER L ENCEINTE USB-C RE ... n et maintenez-le enfonc pendant 2
secondes pour teindre. FR CONNEXION BLUETOOTH 1 2s 2 BUGANi **Brief Pro 3**
CONNECT COUPLAGE Lumire blanche clignotante Lumire blanche solide Lorsque le
haut-parl...

lang:fr **score:48** filesize: 1.34 M page_count: 6 document date: 2025-03-21




[\[pdf\]](#) User Manual Instructions

BUGANI M192 20250220 m192 instructions à bugani global BUGANi Brief Pro MANUAL DE USUARIO 20250321 v 1742890590 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO MANUAL DEL USUARIO ALTAVOZ DE MSICA DE JAZZ REAL DESCRIPCIN DEL PRODUCTO Altavoz --- 1 ... ooth. Al realizar el emparejamiento, habilite la funcin Bluetooth del dispositivo y busque BUGANi **Brief Pro** para conectarse. Cuando la conexin sea exitosa, escuchar un tono de aviso y el indicador...

lang:es score:47 filesize: 1.34 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) Instructions Guide

BUGANI M192 20250219 m193 instructions à bugani global BUGANi Brief Pro GUIDE DE DEMARRAGE RAPIDE 20250321 9179ce23 690a 4c11 bab7 eaede97323c8 v 1742891446 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO GUIDE DE DMARRAGE RAPIDE VRAI HAUT-PARLEUR DE MUSIQUE JAZZ CHARGER L ENCEINTE USB-C RE ... n et maintenez-le enfonc pendant 2 secondes pour teindre. FR CONNEXION BLUETOOTH 1 2s 2 BUGANi **Brief Pro** 3 CONNECT COUPLAGE Lumire blanche clignotante Lumire blanche solide Lorsque le haut-parl...

lang:fr score:46 filesize: 1.34 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) User Manual Quick Start Guide Instructions Guide

BUGANI M192 20250220 m193 instructions à bugani global BUGANi Brief Pro USER MANUAL
20250321 9b22ba79 5c21 4893 ab81 938252dafb5a v 1742891827 cdn shopify s files 1 0660 1772 2548

|||

BRIEF PRO USER MANUAL REAL JAZZ MUSIC SPEAKER PRODUCT OVERVIEW

Speaker --- 1pc USB-C Cable --- 1 ... a Bluetooth device. When pairing, enable the Bluetooth function of the phone and search for BUGANi **Brief Pro** to connect. When the connection is successful, you will hear a prompt tone and the Blueto...

lang:en **score:46** filesize: 1.38 M page_count: 9 document date: 2025-03-21



[\[pdf\]](#) User Manual Instructions

BUGANI M192 20250220 m193 instructions à bugani global BUGANi Brief Pro MANUAL DE
USUARIO 20250321 92288bb2 d1b7 48d0 9b74 663ac78f484f v 1742891796 cdn shopify s files 1 0660
1772 2548 |||

BRIEF PRO MANUAL DEL USUARIO ALTAVOZ DE MSICA DE JAZZ REAL
DESCRIPCIN DEL PRODUCTO Altavoz --- 1 ... ooth. Al realizar el emparejamiento,
habilite la funcin Bluetooth del dispositivo y busque BUGANi **Brief Pro** para
conectarse. Cuando la conexin sea exitosa, escuchar un tono de aviso y el
indicador...

lang:es **score:45** filesize: 1.34 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) User Manual Instructions

BUGANI M192 20250220 m192 instructions à bugani global BUGANi Brief Pro
BENUTZERHANDBUCH 20250321 v 1742890538 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO BENUTZERHANDBUCH ECHTER JAZZ-MUSIK-LAUTSPRECHER
PRODUKTBERSICHT Lautsprecher --- 1 St U ... nden ist. Aktivieren Sie beim
Koppeln die Bluetooth-Funktion des Gerts und suchen Sie nach BUGANi **Brief Pro** ,
um eine Verbindung herzustellen. Wenn die Verbindung erfolgreich hergestellt wurde,
hre...

lang:de **score:41** filesize: 1.36 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250220 m192 instructions â bugani global BUGANi Brief Pro 20250321 b683125e586a 40a6 8bfe f80463220bca v 1742890671 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO --- 1 . USB-C --- 1 . AUX IN --- 1 . --- 1 . --- 1 . USB-C RESET ... OTH . Bluetooth , , , Bluetooth. Bluetooth BUGANi **Brief Pro** . , , Bluetooth . . , Bluetooth . 1 2 2s BUGANi **Brief Pro**...

lang:en **score:40** filesize: 2.9 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250220 m193 instructions â bugani global BUGANi Brief Pro 20250321 28ff75ee6b2d 462f b91a d93fb8389ebb v 1742891888 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO --- 1 . USB-C --- 1 . AUX IN --- 1 . --- 1 . --- 1 . USB-C RESET ... OTH . Bluetooth , , , Bluetooth. Bluetooth BUGANi **Brief Pro** . , , Bluetooth . . , Bluetooth . 1 2 2s BUGANi **Brief Pro**...

lang:en **score:40** filesize: 2.9 M page_count: 7 document date: 2025-03-21




[\[pdf\]](#) Instructions

BUGANI M192 20250220 m192 instructions â bugani global BUGANi Brief Pro 20250321 28772d8c6052 4bb7 b4f1 e999a823ad8f v 1742890696 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO --- 1 USB-C --- 1 AUX IN --- 1 --- 1 --- 1 USB-C RESET AUX IN 1 2 1 ... 2s OFF 2 2 2 15 JP BLUETOOTH Bluetooth Bluetooth Bluetooth BUGANi **Brief Pro** Bluetooth Bluetooth 1 2 2s BUGANi **Brief Pro** 2 Bluetooth Bluetooth Bluetooth...


lang:it **score:40** filesize: 1.46 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) Instructions Guide

BUGANI M192 20250108 m192 instructions à bugani global BUGANi Brief Pro MANUEL DE L UTILISATEUR20250321 v 1742890460 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO MANUEL DE L UTILISATEUR VRAI HAUT-PARLEUR DE MUSIQUE JAZZ PRSENTATION DU PRODUIT Haut-p ... Bluetooth. Lors de l appairage, activez la fonction Bluetooth de l appareil et recherchez BUGANi **Brief Pro** pour vous connecter. Lorsque la connexion est tablie, vous entendrez une tonalit d invit...
lang:fr score:40 filesize: 1.32 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250219 m192 instructions à bugani global BUGANi Brief Pro 20250321 v 1742890302 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO USB-C RESET AUX IN , . , . / ON 2s OFF 2s ON OFF 2 , . 2 , . RU BLUETOOTH 1 2s 2 BUGANi **Brief Pro** 3 , 2 , , Bluetooth. RU TWS 1 2 x2 1 / 2 1 2 1 BUGANi ...
lang:fr score:40 filesize: 1.38 M page_count: 6 document date: 2025-03-21




[\[pdf\]](#) Instructions

BUGANI M192 20250220 m192 instructions à bugani global BUGANi Brief Pro 20250321 2920e10c0511 4008 a262 1d891cab715e v 1742890720 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO --- pc USB-C --- pc --- pc --- pc --- pc USB-C RESET AUX IN 1 2 . . .AUX IN . .USB-C AUX IN USB-C RESET 34 5 USB-C RESET AUX IN CN / 2s 2s // CN
BUGANi **Brief Pro** : 1 2 2s BUGANi **Brief Pro** ...

lang:i-klngon **score:40** filesize: 1.42 M page_count: 7 document date: 2025-03-21




[\[pdf\]](#) Instructions

BUGANI M192 20250219 m192 instructions à bugani global BUGANi Brief Pro 20250321 4aaf49606964 495a 8643 08281946f697 v 1742890330 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO USB-C RESET AUX IN / ON 2s OFF 2s ON OFF 2 2 JP BLUETOOTH 1
2s 2 BUGANi **Brief Pro** 3 2 Bluetooth JP TWS 2 **Brief Pro** 1 2 x2 1 2 1 2 1 BUGANi
Brief Pro 1 TWS TWS AUX IN AUX IN USB-C RESET AUX IN JP 1 2 TW...

lang:i-klngon **score:38** filesize: 1.36 M page_count: 6 document date: 2025-03-21




[\[pdf\]](#) Instructions

BUGANI M192 20250219 m193 instructions à bugani global BUGANi Brief Pro 20250321 54b16f42fa86 442b b429 8f81caee1bca v 1742891666 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO USB-C RESET AUX IN / 2s 2s // CN 1 2s 2 BUGANi **Brief Pro** 3 CN TWS x2 / BUGANi **Brief Pro** AUX IN AUX IN TWS TWS USB-C RESET AUX IN CN 1 2 TWS 2s / 1 CN 1 AUX IN USB-C RESET CN ...

lang:i-klngon **score:38** filesize: 5.23 M page_count: 6 document date: 2025-03-21




[\[pdf\]](#) Instructions

BUGANI M192 20250219 m192 instructions à bugani global BUGANi Brief Pro GUIA DE INICIO RAPIDO 20250321 v 1742890169 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO GUA DE INICIO RPIDO ALTAVOZ DE MSICA DE JAZZ REAL CARGAR EL ALTAVOZ USB-C RESET AUX I ... botn de Encendido nuevamente durante 2 segundos para apagar. ES CONEXIN BLUETOOTH 1 2s 2 BUGANi **Brief Pro** 3 CONECTADA EMPAREJAMIENTO Blanca intermitente Blanco slido Cuando el altavoz est apagad...

lang:es **score:38** filesize: 1.34 M page_count: 6 document date: 2025-03-21




[\[pdf\]](#) User Manual Instructions

BUGANI M192 20250219 m193 instructions à bugani global BUGANi Brief Pro KURZANLEITUNG
20250321 86c143e2 dcea 47cc bc78 c2f9acc3649b v 1742891507 cdn shopify s files 1 0660 1772 2548

|||

BRIEF PRO KURZANLEITUNG ECHTER JAZZ-MUSIK-LAUTSPRECHER LADEN SIE
DEN LAUTSPRECHER AUF USB-C RESET ... neut 2 Sekunden lang gedrckt, um
das Gert auszuschalten. DE BLUETOOTH-VERBINDUNG 1 2s 2 BUGANi **Brief Pro**
3 VERBUNDEN KOPPLUNG Blinkt wei Solides Weiss Wenn der Lautsprecher
ausgeschaltet ist, h...

lang:de score:38 filesize: 1.35 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250219 m193 instructions à bugani global BUGANi Brief Pro GUIA DE INICIO
RAPIDO 20250321 efc45ec4 28b5 4d56 a991 954de572cd5a v 1742891376 cdn shopify s files 1 0660
1772 2548 |||

BRIEF PRO GUA DE INICIO RPIDO ALTA VOZ DE MSICA DE JAZZ REAL CARGAR
EL ALTA VOZ USB-C RESET AUX I ... botn de Encendido nuevamente durante 2
segundos para apagar. ES CONEXIN BLUETOOTH 1 2s 2 BUGANi **Brief Pro** 3
CONECTADA EMPAREJAMIENTO Blanca intermitente Blanco slido Cuando el
altavoz est apagad...

lang:es score:37 filesize: 1.34 M page_count: 6 document date: 2025-03-21




[\[pdf\]](#) User Manual Quick Start Guide Guide

BUGANI M192 20250220 cdn shopify Mar 21 2025 · com BUGANi Brief Pro USER MANUAL
20250321 v 1742890617 s files 1 0660 1772 2548 |||

BRIEF PRO USER MANUAL REAL JAZZ MUSIC SPEAKER PRODUCT OVERVIEW

Speaker --- 1pc USB-C Cable --- 1 ... a Bluetooth device. When pairing, enable the Bluetooth function of the phone and search for BUGANi **Brief Pro** to connect. When the connection is successful, you will hear a prompt tone and the Blueto...

lang:en score:36 filesize: 1.38 M page_count: 9 document date: 2025-03-21




[\[pdf\]](#) User Manual Quick Start Guide Guide

BUGANI M192 0627 Administrator User manual Bugani Acoustics Co Limited BS12303 2BGTK
2BGTKBS12303 bs12303

95*110mm 4C 1 95 110 **BRIEF PRO** PORTABLE BLUETOOTH SPEAKER

Model/HVIN:BS12303 USER MANUAL / MA ... ker switches o when audio has stopped or buttons have not been pressed for 15 minutes. for BUGANi **Brief Pro** to connect. When the connection is successful, you will hear a prompt tone and the Blueto...

lang:en score:32 filesize: 5.48 M page_count: 1 document date: 2024-06-27




[\[pdf\]](#) Guide

BUGANi Brief Pro User Guide CamScanner anhdud vn document |||

...

lang:en score:30 filesize: 11.98 M page_count: 11 document date: 0000-00-00



[pdf]

Taláček Milan BRIEF PRO NeoxShop cz skutečný jazzový reproduktor model BS12303 stručný návod k použití DOBÍJENÍ REPRODUKTORU kontrolka dobíjení blikající červená svítící Brief Pro neoxshop images manuals BUGANi CZ |||

BRIEF PRO skutečn jazzov reproduktor model BS12303 stručnív od k použít DOBJEN REPRODUKTORU kontrolka dobjen blikajc červená svtc červen Kabel nepipojujte, pokud nejsou zsuška nebo konektor zcela such. ZAPNUT/VYPNUT bí kontrolka svt bí kontrolka nesvt Stiskem a držením vypnace po dobu 2 sekund ... lang:hr score:22 filesize: 1.05 M page_count: 2 document date: 2025-03-05