

EMLIVIAR GE255BL BK

EMLIVIAR GE255BL BK Outdoor Wall Sconce Instruction Manual

Model: GE255BL BK

Brand: EMLIVIAR

1. SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to do so could lead to electric shock, fire, or other injuries that could be hazardous or even fatal.

- **WARNING:** Risk of electric shock. Disconnect power at the circuit breaker or fuse box before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Contact a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- This fixture is intended for use in a 120V/60Hz circuit.
- Do not install any fixture assembly closer than 6 inches from any combustible material.
- Ensure the fixture is securely mounted to a structural element of the building.
- Do not exceed the maximum wattage specified for the bulb (Max. 60W).
- Wear safety glasses and appropriate protective equipment during installation.

2. PACKAGE CONTENTS

Carefully unpack your new fixture and lay out all parts on a clear area. Ensure all components listed below are present before discarding any packaging materials.

- 1 x Outdoor Wall Sconce Fixture
- 1 x Mounting Hardware Kit (includes mounting plate, screws, wire nuts)
- 1 x Instruction Manual


Note: Bulb (E26 base, Max. 60W) is not included and must be purchased separately.

3. SPECIFICATIONS

Model Number	GE255BL BK
Dimensions (W x H x D)	5.9" x 11.3" x 7.4" (extends 7.4" from wall)
Back Plate Diameter	5.1"
Material	Metal (Black Finish) & Clear Tempered Glass
Bulb Base	E26 (Bulb not included)
Max Wattage	60W
Voltage	120V
Frequency	60Hz
Indoor/Outdoor Usage	Outdoor
Water Resistance Level	Water Resistant
Certification	UL Listed

PRODUCT DIMENSION

B U L B N O T I N C L U D E D



E m l i v i a r

Figure 1: Product Dimensions (5.9" W x 11.3" H, extends 7.4" from wall)

PRODUCT DETAILS



Adding different ambiance to your patio design



Black Finish



Metal Construction



Clear Tempered Glass

Figure 2: Product Details (Black Finish, Metal Construction, Clear Tempered Glass)

4. SETUP AND INSTALLATION

Follow these steps for safe and proper installation of your outdoor wall sconce. If you are unsure about any step, consult a qualified electrician.

1. **Turn Off Power:** Before starting, ensure the power to the circuit you are working on is turned off at the main electrical panel (circuit breaker or fuse box).
2. **Prepare Mounting Surface:** Ensure the junction box is securely installed and capable of supporting the fixture's weight.
3. **Attach Mounting Plate:** Secure the mounting plate (included in hardware kit) to the junction box using the provided screws. Ensure the plate is oriented correctly for the fixture.

4. Make Electrical Connections:

- Connect the **black** wire from the fixture to the **black** (hot) wire from the junction box using a wire nut.
- Connect the **white** wire from the fixture to the **white** (neutral) wire from the junction box using a wire nut.
- Connect the **ground** wire from the fixture (usually bare copper or green) to the **ground** wire from the junction box and the ground screw on the mounting plate.

Ensure all connections are tight and secure.

- 5. **Mount Fixture:** Carefully tuck all wires into the junction box. Align the fixture with the mounting plate and secure it using the provided screws.
- 6. **Install Bulb:** Insert one E26 base bulb (Max. 60W, not included) into the socket. Do not overtighten.
- 7. **Restore Power:** Once the fixture is securely installed and the bulb is in place, restore power at the main electrical panel.

OUTDOOR WALL LIGHT

P e r f e c t f o r y o u r p a t i o



E m i t t i v e

Figure 3: Example of installed outdoor wall sconce

5. OPERATING INSTRUCTIONS

This EMLIVAR outdoor wall sconce is designed for simple operation once installed.

1. **Power On:** Ensure the light fixture is properly installed and connected to a power source. Turn on the wall switch or circuit breaker controlling the fixture.
2. **Bulb Type:** Use only E26 base bulbs with a maximum wattage of 60W. Compatible bulb types include LED, Incandescent, and CFL.
3. **Control:** The light is controlled by an external wall switch (not included).

BULB NOT INCLUDED

P e r f e c t f o r y o u r p a t i o



Figure 4: Bulb Type and Wattage Information

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your outdoor wall sconce.

- **Cleaning:** To clean the fixture, turn off the power and wipe it with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or glass.
- **Bulb Replacement:** Ensure power is off before replacing the bulb. Allow the old bulb to cool completely before removing. Screw in the new E26 base bulb (Max. 60W) gently.
- **Inspection:** Periodically check the fixture for any signs of damage, loose connections, or wear. Address any issues promptly.



Waterproof



Heat Resistant



Stormproof



Frost Resistant

WEATHER RESISTANT

Black Outdoor Lighting

Figure 5: Weather Resistant Features

7. TROUBLESHOOTING

If you encounter issues with your EMLIVIAR outdoor wall sconce, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse. Ensure wall switch is ON.
	Loose wire connections.	Turn off power, check all wire connections. Re-secure if loose.
	Defective bulb.	Replace bulb with a new E26 base, Max. 60W bulb.
Light flickers.	Loose bulb.	Turn off power, tighten bulb in socket.
	Incorrect bulb type or wattage.	Ensure bulb is E26 base and does not exceed 60W.
	Loose wire connections.	Turn off power, check all wire connections. Re-secure if loose.
Glass is broken or cracked.	Impact or manufacturing defect.	Contact EMLIVIAR customer support for replacement parts.

If the problem persists after trying these solutions, please contact EMLIVIAR customer support.

8. WARRANTY AND SUPPORT

This EMLIVIAR outdoor wall sconce (Model GE255BL BK) is backed by a **one-year warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. For warranty claims, technical support, or replacement parts, please contact EMLIVIAR customer service through the retailer where the product was purchased or visit the official EMLIVIAR website for contact information. Please retain your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question