



[Manuals.plus](#) /

> [Sportspower](#) /

> Sportspower Arcadia Star Burst Swing Set Instruction Manual

## Sportspower MSC-5858

# Sportspower Arcadia Star Burst Swing Set Instruction Manual

Model: MSC-5858

## 1. INTRODUCTION

---

Thank you for choosing the Sportspower Arcadia Star Burst Swing Set. This heavy-duty metal playset is designed to provide a fun and engaging outdoor experience for children, featuring a unique LED light-up slide, swings, and a trapeze bar. This manual provides essential information for the safe assembly, operation, and maintenance of your swing set. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Arcadia Star Burst Swing Set includes 6 play stations: two non-slip adjustable swing seats, one trapeze bar, one two-person glider, and one five-foot wavy LED light-up slide. It is designed to accommodate up to 6 children simultaneously.

## 2. SAFETY INFORMATION

---

Your safety and the safety of others are paramount. Please adhere to all safety guidelines.

- This product meets or exceeds all ASTM safety standards.
- Adult assembly is required. Ensure all components are securely fastened before use.
- Supervise children at all times while they are using the swing set.
- The swing set is designed for children aged 3-8 years.
- Maximum total weight capacity is 600 lbs. Do not exceed this limit.
- Swing chains are safely wrapped in sturdy vinyl for added protection against pinching.
- Frame legs are foam-padded for additional safety.
- Always use the provided 4-piece anchor kit to secure the swing set to the ground for extra safety and stability.
- Ensure a safe play area around the swing set, free from obstacles, at least 6 feet in all directions.

### 3. SETUP AND ASSEMBLY

Careful assembly is crucial for the stability and safety of the swing set. Adult assembly is required. It is recommended to have at least two adults for assembly.

#### 3.1 Unpacking and Component Check

- Carefully unpack all components and lay them out.
- Verify that all parts listed in the instruction manual's parts list are present and undamaged. If any parts are missing or damaged, contact customer support immediately.

#### 3.2 Frame Assembly

The swing set is crafted from 2-inch heavy-duty weather-resistant steel tubes with welded joints and an A-Frame design for strength and stability. The frame is powder-coated for durability.



Image: Illustration of the swing set's A-frame structure, highlighting its rust-resistant and powder-coated finish for enhanced durability.

- Follow the step-by-step instructions provided in the separate assembly manual for connecting the steel tubes and A-frames.
- Ensure all bolts, nuts, and washers are used correctly and tightened securely. Do not overtighten to avoid damaging components, but ensure a firm connection.

### 3.3 Attaching Play Features

- Attach the swing seats, glider, and trapeze bar according to the assembly manual. Ensure all connections are secure and the chains are properly installed.
- Install the 5-foot wavy LED light-up slide. This slide features a double-walled, blow-molded design for durability.



*Image: Detailed view of the 5-foot LED light-up slide, emphasizing its robust double-walled, blow-molded construction and safe landing area.*

### 3.4 Ground Anchoring

The swing set must be anchored to the ground for stability and safety.



*Image: The 4-piece anchor kit, consisting of wavy metal stakes, designed to secure the swing set firmly to the ground.*

- Use the provided 4-piece anchor kit to secure each leg of the swing set firmly into the ground.
- Ensure the anchors are fully embedded and provide maximum stability.

## 4. OPERATING INSTRUCTIONS

---

This section provides guidance on how to use the various play features of your Sportspower Arcadia Star Burst Swing Set.

### 4.1 Swings



*Image: A child enjoying a swing, with close-ups illustrating the comfortable textured seat, protective PVC chain covers, and adjustable chain mechanism.*

- The two blow-molded swing seats are height-adjustable to accommodate growing children. Adjust the chain length as needed.
- Rubber-coated swing chains protect children's hands during play.
- Ensure children sit properly on the swing seats and hold onto the chains firmly.

#### **4.2 Glider and Trapeze**

## 2-PERSON GLIDER



## METAL TRAPEZE

*Image: Children engaging with the two-person glider and the metal trapeze bar, demonstrating the interactive play options.*

- The double-seat flying glider allows two children to swing together. Ensure both children are seated and holding the handles securely.
- The metal trapeze bar is for single-user acrobatics. Ensure a firm grip before performing any maneuvers.

### 4.3 LED Light-Up Slide

- The 5-foot wavy slide features an LED light-up function for nighttime play.
- To activate the LED lights, 3 AA batteries are required (not included). Install batteries into the designated compartment on the slide according to polarity markings.
- Ensure children slide down feet first and one at a time.

## 5. MAINTENANCE

Regular maintenance will extend the life of your swing set and ensure continued safe operation.

- **Monthly Checks:** Inspect all nuts and bolts for tightness. Re-tighten as necessary. Check for any signs of rust on metal components, especially at joints.

- **Seasonal Checks:** Before and after each play season, inspect all moving parts, including swing chains, seats, glider, and trapeze bar, for wear, cracks, or damage. Replace any worn or damaged parts immediately.
- **Cleaning:** Clean plastic and metal surfaces with mild soap and water. Avoid abrasive cleaners.
- **LED Slide Batteries:** Check the batteries in the LED slide periodically. Replace with fresh 3 AA batteries when lights dim or stop working. Ensure the battery compartment is sealed properly after replacement.
- **Ground Anchors:** Verify that the ground anchors remain firmly embedded. Re-secure if they become loose.
- **Rust Prevention:** Although the frame is powder-coated, minor scratches can expose metal to moisture. Touch up any deep scratches with rust-inhibiting paint to prevent corrosion.

## 6. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your swing set.

- **Swing Set Feels Unstable/Shaky:**
  - Ensure all assembly bolts are tightened securely.
  - Verify that the 4-piece anchor kit is properly installed and fully embedded in the ground.
  - Check that the ground surface is level. Uneven ground can affect stability.
- **LED Slide Not Lighting Up:**
  - Check if 3 AA batteries are installed.
  - Ensure batteries are inserted with correct polarity (+/-).
  - Replace old batteries with new ones.
  - Verify that the battery compartment cover is securely closed.
- **Missing or Incorrect Parts During Assembly:**
  - Double-check the parts list against the received components.
  - Contact Sportspower customer support immediately for assistance with replacement parts.
- **Excessive Wear on Swing Chains/Seats:**
  - Inspect for fraying, cracks, or deformation.
  - Discontinue use of the affected part and contact customer support for replacement.

## 7. SPECIFICATIONS

---

Feature	Detail
Model Number	MSC-5858
Brand	Sportspower
Product Dimensions (L x W x H)	133"D x 100"W x 73"H (11.1'L x 8.3'W x 6.1'H)
Frame Material	Heavy-Duty Metal (Steel)

Finish Type	Powder Coated
Color	Blue, White
Item Weight	81.4 Pounds
Age Range	3-8 Years
Maximum Weight Capacity	600 lbs
Play Stations	2 Swings, 1 Trapeze, 1 Glider, 1 LED Slide
Slide Length	5 feet
Slide Features	LED Light-Up (requires 3 AA batteries, not included), Double-Walled, Blow-Molded
Safety Standards	Meets or Exceeds all ASTM Safety Standards

## USA-BASED CUSTOMER SUPPORT



**REAL HELP,  
REAL FAST**

**OUR USA-BASED SUPPORT  
TEAM HAS YOUR BACK  
EVERY STEP OF THE WAY.**



**NO WAITING DAYS FOR HELP —  
WE'RE ON IT.**



**MISSING A PIECE? WE'LL SHIP  
IT ASAP, NO HASSLE.**



**NO BOTS. NO LOOPS. JUST  
HELPFUL PEOPLE WHO CARE.**



**WE KNOW OUR PRODUCT —  
YOU'RE TALKING TO THE PROS.**


*Image: An illustrative overview of the swing set, detailing its dimensions, recommended age range (3-8), maximum weight capacity (600 lbs), 1-year warranty, and compliance with ASTM safety standards.*

## 8. WARRANTY

The Sportspower Arcadia Star Burst Swing Set comes with a **1-Year Warranty** on parts and accessories from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use and service. Please retain your proof of purchase for warranty claims. The warranty does not cover damage due to misuse, improper assembly, neglect, accident, or unauthorized modifications.

## 9. CUSTOMER SUPPORT

For any questions, missing parts, or assistance with assembly or operation, please contact Sportspower's USA-based customer support team. Our team is dedicated to providing prompt and helpful assistance.



*Image: Visual representation of USA-based customer support, emphasizing readily available assistance for product inquiries and assembly.*  
Please refer to the contact information provided in your product packaging or visit the official Sportspower website for the most up-to-date support details.