

# Pamray L Shaped Computer Desk S14black49 User Manual

Comprehensive instructions for assembly, operation, and maintenance of your Pamray L Shaped Computer Desk.

## 1. INTRODUCTION

Thank you for choosing the Pamray L Shaped Computer Desk. This manual provides detailed instructions for the safe assembly, proper operation, and effective maintenance of your new desk. Please read this manual thoroughly before beginning assembly or use to ensure optimal performance and longevity of the product.

## 2. SAFETY INFORMATION

### Important Safety Precautions:

- **Maximum Weight Recommendation:** This desk has a maximum weight recommendation of **150 pounds (68 kg)**. Ensure that the total weight placed on the desk, including the desk itself, does not exceed this limit to maintain stability and prevent accidents.
- **Stability:** For added safety, especially in areas with high foot traffic or where children may be present, it is recommended to anchor the desk to the wall or floor.
- **Assembly:** Follow all assembly instructions carefully. Do not overtighten screws. Ensure all connections are secure before use.
- **Electrical Safety:** The built-in power outlets and USB ports are designed for standard use. Do not overload the outlets. Disconnect power before cleaning or if any damage occurs.
- **Children and Pets:** Keep small parts and packaging materials away from children and pets during assembly to prevent choking hazards.

## 3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop Panels (L-shaped sections)

- Metal Frame Components (legs, support bars, X-braces)
- 5-Tier Shelf Panels
- Built-in Power Outlet Unit (with AC outlets and USB ports)
- LED Light Strip (with app control functionality)
- Headphone/Bag Hook
- Assembly Hardware (screws, bolts, nuts, washers)
- Assembly Tools (e.g., Allen wrench, screwdriver)
- Instruction Manual

## 4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two people. All necessary tools are included in the accessory box. For visual guidance, comprehensive installation videos are available via a QR code on the packaging or on the product page.

### 4.1. Prepare Your Workspace

Clear a spacious area for assembly. Lay out all components and hardware, ensuring they are easily accessible.

### 4.2. Assemble the Desk Frame

1. Attach the desk legs to the main desktop panels using the provided screws. Ensure all connections are finger-tight initially.
2. Connect the support bars between the legs to form a stable base.
3. Install the two "X"-shaped back braces on the sides of the desk frame. These braces enhance overall stability and prevent wobbling.



Image: The assembled desk frame showing the X-shaped back braces for enhanced stability.

#### 4.3. Install the Reversible 5-Tier Shelves

The 5-tier side shelf unit can be installed on either the left or right side of the desk to suit your space and preference.

1. Assemble the shelf frame according to the desired orientation (left or right).
2. Securely attach the shelf panels to the frame.
3. Connect the assembled shelf unit to the main desk frame.



## Adjustable Design

Place the shelves on either side to fit your space.

Image: Two Pamray L Shaped Computer Desks demonstrating the reversible shelf design, allowing the shelves to be placed on either side.

### 4.4. Integrate Power Outlets and LED Lights

1. Carefully place the built-in power outlet unit into its designated slot on the desktop. Secure it with the provided screws.
2. Attach the LED light strip to the underside of the shelves or desktop as desired. Ensure the adhesive surface is clean and dry for optimal adhesion.




Image: Close-up view of the integrated power outlet unit featuring two AC outlets and two USB ports, with a smartphone charging.

## 4.5. Final Adjustments

1. Once all components are assembled, tighten all screws securely.
2. Attach the headphone or bag hook to the desired location on the desk frame.
3. Adjust the leveling feet at the bottom of the desk legs to ensure the desk is stable and level on uneven floors.



Image: Close-up of the adjustable leveling feet on the desk's metal legs, designed to stabilize the desk on uneven surfaces.

## 5. OPERATING INSTRUCTIONS

### 5.1. Using the Built-in Power Outlets and USB Ports

The desk is equipped with 3 AC outlets (125V/12A) and 2 USB ports (5V/2A) for convenient charging of your electronic devices. The power cord is 4.92 feet long, and the unit has a rated power of 1500W.

- Plug the desk's main power cord into a wall outlet.
- Connect your devices (phones, tablets, laptops, etc.) to the AC outlets or USB ports as needed.
- Avoid exceeding the maximum rated power of 1500W to prevent electrical hazards.

### 5.2. Controlling the LED Lights

The integrated LED light strip offers customizable lighting options to enhance your workspace ambiance.

- **App Control:** The LED lights can be remotely controlled via a dedicated smartphone application. Download the app (refer to packaging or product information for app name/QR code).
- **Features:** The app allows you to select from 213 dynamic modes and over 10,000 color options. You can adjust brightness, hues, and potentially synchronize with music or other settings.

# RGB LED Lights Strip



## APP CONTROL



213 Dynamic  
Multicolor lighting Modes



Built-in Mic



Music Sync



60000 Colors

Image: The RGB LED light strip illuminating the desk shelves, with an illustration of the smartphone app interface for controlling colors and modes.

## 5.3. Using the Headphone/Bag Hook

A convenient hook is provided for hanging headphones, bags, or other accessories, helping to keep your workspace tidy.

- Simply hang your items on the hook. Ensure the weight does not exceed the hook's capacity to prevent damage or detachment.



Image: A close-up view of the integrated hook on the desk frame, designed for hanging headphones or bags.

## 6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your desk.

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** The tabletop is designed to be resistant to minor spills. Promptly wipe up any liquid spills to prevent potential damage.
- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **LED Lights:** If the LED strip adhesive weakens, use a suitable, non-damaging adhesive to re-secure it.



Image: Water droplets on the desk surface, illustrating its resistance to minor liquid spills.

## 7. TROUBLESHOOTING

If you encounter issues with your Pamray L Shaped Computer Desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk wobbles or is unstable	Uneven floor; loose connections; X-braces not installed/tightened.	Adjust leveling feet. Tighten all screws and bolts. Ensure X-braces are correctly installed and secured.
LED lights not working	Power not connected; app not paired; faulty strip.	Ensure the LED strip is properly connected to power. Check app pairing. If issues persist, contact support.
Power outlets/USB ports not functioning	Desk power cord unplugged; circuit overload; faulty unit.	Verify the desk's main power cord is securely plugged into a working wall outlet. Reduce the number of connected devices if overloaded.
LED light strip detaching	Adhesive weakening; surface not clean during installation.	Clean the surface and re-apply the LED strip using a strong, suitable adhesive.

## 8. SPECIFICATIONS

- **Brand:** Pamray
- **Model Number:** S14black49
- **Shape:** Rectangular (L-shaped configuration)
- **Product Dimensions (D x W x H):** 18.9"D x 48.8"W x 29.61"H (48cm D x 124cm W x 75.2cm H)

- **Color:** Black
- **Style:** Modern
- **Base Material:** Metal
- **Top Material Type:** Tabletop made of FSC-Certified Wood
- **Finish Type:** Powder Coated
- **Item Weight:** 42.4 Pounds (19.2 kg)
- **Number Of Shelves:** 5 (reversible)
- **Maximum Weight Recommendation:** 150 Pounds (68 kg)
- **Power Outlets:** 3 AC Outlets (125V/12A), 2 USB Ports (5V/2A)
- **Power Cord Length:** 4.92 FT
- **Rated Power:** 1500W
- **LED Lights:** RGB, App Controlled, 213 Modes, 10,000+ Colors
- **Assembly:** Required, tools included

## 9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact Pamray customer support directly. Pamray is committed to providing a safer and cozier home and office environment. For any questions, assistance, or to report missing/damaged parts, please visit the official Pamray store or contact their customer service department.

**Pamray Store:** [Visit the Pamray Store on Amazon](#)