

[Manuals.plus](#) /

› [Pamray](#) /

› Pamray 49 Inch L-Shaped Gaming Computer Desk with Shelves and Storage White - Instruction Manual

Pamray S14white49

Pamray 49 Inch L-Shaped Gaming Computer Desk - Instruction Manual

Model: S14white49

1. INTRODUCTION

Thank you for choosing the Pamray 49 Inch L-Shaped Gaming Computer Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use of your new desk. Please read this manual thoroughly before beginning assembly and retain it for future reference.

2. SAFETY INFORMATION

- Ensure the desk is properly assembled with all provided 'X'-shaped back braces to maintain stability.
- Do not exceed the maximum weight recommendation of 150 pounds (68 kg) to prevent tipping or damage.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Place the desk on a level surface to prevent wobbling.
- Avoid exposing the desk to excessive moisture or direct sunlight.
- Do not stand or sit on the desk.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop Panels
- Metal Frame Components
- 5-Tier Shelf Panels
- Built-in Power Outlet Unit (with AC outlets and USB ports)
- LED Light Strip
- Headphone Hook
- Assembly Hardware (screws, bolts, Allen wrench)

4. ASSEMBLY INSTRUCTIONS

This desk is designed for straightforward assembly. Comprehensive installation videos are available via the product page or by scanning the transparency label on the packaging. Follow the included clear installation instructions and use all necessary tools provided in the accessory box.


General Assembly Tips:

- Lay out all parts and hardware before starting. Separate components by their labels.
- Pay close attention to the orientation of boards and poles as depicted in the diagrams. Incorrect orientation can lead to misaligned holes. If holes do not align, try flipping the board or component.
- Do not fully tighten all screws until the entire frame is assembled, then tighten them securely.
- The 5-tier shelf unit is reversible and can be installed on either the left or right side of the desk. Refer to the specific instructions for your desired configuration.

Visual Guide: Reversible Design



Image showing the Pamray L-shaped desk with the 5-tier shelf unit installed on the right side. The desk is white and features a monitor, keyboard, and decorative items on the shelves.



Adjustable Design

Place the shelves on either side to fit your space.

Image showing the Pamray L-shaped desk with the 5-tier shelf unit installed on the left side. The desk is black and features a gaming setup with multiple monitors and LED lighting.

Assembly Video:

Your browser does not support the video tag.

Official video demonstrating the assembly process and key features of the L-shaped computer desk, including the reversible side storage shelves and LED lighting.

5. FEATURES OVERVIEW

- **Ample Storage Space:** Features a 5-tier side shelf for organizing books, office supplies, files, decor, or gaming accessories. Includes a headphone hook for convenient storage.
- **Built-in Power Outlet & Colorful LED Lights:** Equipped with 3 AC outlets and 2 USB ports for charging devices. The integrated LED light strip offers 213 modes and over 10,000 color options, controllable via an app.

- **Reversible 5-Tier Shelves:** The side shelf can be installed on either the left or right side to suit your space and preference.
- **Sturdy Structure:** Enhanced stability with two "X"-shaped back braces, preventing wobbling during use.

Feature Details:



Detailed view of the 5-tier bookshelf, showcasing its storage capacity and integrated LED lighting. The shelves are illuminated with a blue light.



3 AC Outlets
125V / 12A



2 USB Ports
5V / 2A



Power Cord
4.92FT



Rated Power
1500W

Close-up image of the built-in power outlet unit, featuring two AC outlets and two USB ports. A smartphone is shown charging via one of the USB ports.

RGB LED Lights Strip



APP CONTROL


213 Dynamic
Multicolor Lighting Modes


Built-in Mic


Music Sync


60000 Colors

Image illustrating the RGB LED light strip feature, highlighting app control, 213 dynamic multicolor lighting modes, a built-in microphone for music sync, and over 60,000 color options.

6. OPERATION

6.1. Power Outlet Usage

The desk includes a built-in power outlet unit with 3 AC outlets and 2 USB ports. Simply plug the desk's main power cord into a wall outlet. You can then connect your electronic devices directly to the desk's integrated outlets for convenient power access.

6.2. LED Light Control

The integrated LED light strip can be controlled via a dedicated mobile application. Download the app (details typically found in the LED light packaging or a QR code) to access various lighting modes, adjust brightness, and select from over 10,000 color options. The lights can also sync with music.

7. MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, which can damage the finish.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Weight Distribution:** Distribute weight evenly across the desktop and shelves. Do not place excessively heavy items on any single point.
- **Environmental Conditions:** Keep the desk in a dry environment and avoid direct exposure to extreme temperatures or humidity.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Holes do not align during assembly.	Incorrect orientation of a board or frame component.	Review the instruction diagrams carefully. Try flipping the component (e.g., a shelf panel or metal bar) to ensure correct alignment.
Desk is wobbly after assembly.	Screws are not fully tightened; desk is on an uneven surface; X-braces not installed correctly.	Ensure all screws are securely tightened. Verify that the 'X'-shaped back braces are properly installed. Move the desk to a level surface or use adjustable feet if available.
LED light strip adhesive is weak.	Surface not clean; adhesive quality.	Ensure the surface is clean and dry before applying. If necessary, use additional adhesive tape (not included) to secure the strip.
Built-in power outlet not working.	Desk's main power cord not plugged in; outlet unit not properly connected.	Check that the desk's power cord is securely plugged into a functional wall outlet. Ensure the power outlet unit is correctly installed and connected within the desk structure.

9. SPECIFICATIONS

DIMENSIONS



Large Desktop Generous Workspace

Detailed diagram illustrating the dimensions of the L-shaped desk, including desktop length, width, and height, as well as shelf dimensions.

Attribute	Detail
Brand	Pamray
Model Number	S14white49
Product Dimensions (D x W x H)	18.9"D x 48.8"W x 29.61"H (48cm D x 124cm W x 75.2cm H)
Item Weight	42.4 pounds (19.2 kg)
Color	White
Material Type	Metal, Wood (FSC-Certified Tabletop)
Number of Shelves	5

Attribute	Detail
Maximum Weight Recommendation	150 pounds (68 kg)
Included Components	Built-in Outlet, Headphone Hook, Built-in USB Port, LED Lights
Room Type	Bedroom, Dormitory, Living Room, Office, Study Room

10. WARRANTY AND SUPPORT

10.1. Warranty Information

This Pamray desk comes with a Limited Warranty. Please refer to the warranty card included in your package for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects under normal use.

10.2. Customer Support

For any questions, missing parts, or issues not covered in this manual, please contact Pamray customer support. Contact information can usually be found on the product packaging, the brand's official website, or through your retailer's support channels. Please have your model number (S14white49) and purchase date ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question