Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

INFURTURE BH127AU

INFURTURE Wearable Bluetooth Speaker User Manual

Model: BH127AU
Brand: INFURTURE

Introduction

This manual provides comprehensive instructions for the safe and effective use of your INFURTURE Wearable Bluetooth Speaker. Please read this manual thoroughly before operating the device and retain it for future reference.



Figure 1: INFURTURE Wearable Bluetooth Speaker (Blue)

Package Contents

Ensure all items are present in the package:

- 1 x INFURTURE Wearable Bluetooth Speaker
- 1 x Power Cable (USB-C)
- 1 x User Manual (this document)

Setup

1. Initial Charging

Before first use, fully charge the speaker. Connect the provided USB-C power cable to the speaker's charging port and a compatible USB power source. A full charge takes approximately 1.5 hours and provides up to 15 hours of playtime.



Figure 2: Charging the speaker and battery life indication.

2. Power On/Off

- To Power On: Press and hold the Multi-Function Button (MFB) for 2-3 seconds until the indicator light illuminates.
- To Power Off: Press and hold the MFB for 2-3 seconds until the indicator light turns off.

3. Bluetooth Pairing

The speaker will automatically enter pairing mode when powered on for the first time or if no device is connected. The indicator light will flash rapidly.

1. Ensure Bluetooth is enabled on your device (smartphone, tablet, laptop).
2. Search for "INFURTURE BH127AU" in your device's Bluetooth settings.
3. Select the speaker to connect. Once connected, the indicator light will remain solid.

The speaker utilizes Bluetooth 5.4 for stable, low-latency connectivity, with a range of up to 10 meters (33 feet).

Operating Instructions

Basic Controls

Button	Function
MFB (Multi-Function Button)	Single Press: Play/Pause music, Answer/End call Double Tap: Activate Voice Assistant (Siri/Google/Alexa) Press and Hold (2-3s): Power On/Off
'+' Button	Single Press: Increase Volume Press and Hold: Next Track
'-' Button	Single Press: Decrease Volume Press and Hold: Previous Track
Flashlight Button	Single Press: Toggle Flashlight On/Off (2 levels of brightness) Long Press (2-3s): Switch between 2 RGB light modes

Voice Assistant & Hands-Free Calls

Double-tap the MFB button to activate your device's voice assistant (Siri, Google Assistant, Alexa). The built-in noise-reduction microphone allows for clear, hands-free calls, keeping you connected without needing to access your phone.




Figure 3: Voice assistant activation and hands-free functionality.



Figure 4: Hands-free call management features.

Flashlight and RGB Lighting

The speaker features a built-in flashlight with two brightness levels, activated by a single press of the dedicated flashlight button. Long press the flashlight button to cycle through two RGB light modes, enhancing your listening experience.



Figure 5: Speaker flashlight illuminating the path during night activity.



Figure 6: Multi-color RGB lighting feature.

Wearing the Speaker

The INFURTURE speaker is designed for portability and hands-free use. Weighing only 72g, it features a reinforced anti-slip clamp for secure attachment to clothing, backpacks, belts, or other suitable surfaces. This allows for open playback, maintaining awareness of your surroundings.



Figure 7: Examples of wearing the speaker during various activities.



Figure 8: Versatile usage scenarios for the wearable speaker.

Official Product Video

Your browser does not support the video tag.

Video 1: Overview of the Wearable Waterproof Bluetooth Speaker with RGB/Flashlight, showcasing its features and portability.

Maintenance

Cleaning

Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the charging port cover is securely closed before cleaning or exposing to water.

Waterproof & Dustproof Features

The speaker is IPX6 rated, meaning it is protected against high-pressure water jets from any direction and is dustproof. While it can withstand splashes and rain, it is not designed for submersion. Always ensure the charging port cover is sealed to maintain water resistance.



Figure 9: IPX6 waterproof and dustproof capabilities.

Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to approximately 50% every few months to preserve battery life.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Bluetooth not enabled on device; speaker not in pairing mode; too far from device.	Ensure Bluetooth is on. Power cycle speaker to enter pairing mode. Move device closer to speaker (within 10m).
No sound or low volume.	Volume too low on speaker or device; speaker not connected.	Increase volume on both speaker and connected device. Re-pair the speaker.
Flashlight/RGB light not working.	Low battery; button malfunction.	Charge the speaker. If problem persists, contact support.

Specifications

Feature	Detail
Model Name	BH127AU
Speaker Type	Portable Speaker
Special Features	Built-in Microphone, LED Light, Lightweight, Portable, Waterproof
Connectivity Technology	Bluetooth 5.4
Bluetooth Range	Up to 10 meters (33 feet)
Power Source	Battery Powered
Battery Life	Up to 15 hours (at 80% volume)
Charging Time	Approx. 1.5 hours
Waterproof Rating	IPX6
Speaker Output Power	10 Watts
Audio Output Mode	Surround
Product Dimensions (DxWxH)	1.1" x 1.97" x 3.15"
Item Weight	3.2 ounces (72g)
Control Method	Touch buttons
Included Components	Power Cable



Figure 10: Internal view of the speaker's audio components.



Figure 11: Battery capacity and playtime details.



Figure 12: Button layout and functions for easy operation.

Warranty Information

This INFURTURE product comes with a Limited Warranty. Please refer to the warranty card included in your package for specific terms and conditions. Retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty inquiries, please contact INFURTURE customer support. Contact details can typically be found on the product packaging or the official INFURTURE website.

© 2025 INFURTURE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6BKTWJ6

More documents and user manuals: **https://manuals.plus/**