

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [SWEETFULL](#) /
- › [SWEETFULL S70 Neck Fan Instruction Manual](#)

SWEETFULL S70

SWEETFULL S70 Neck Fan Instruction Manual

Model: S70 | Brand: SWEETFULL

INTRODUCTION

This instruction manual provides detailed guidance for the safe and effective use of your SWEETFULL S70 Neck Fan. Please read this manual thoroughly before operating the device and retain it for future reference.

PRODUCT OVERVIEW

The SWEETFULL S70 Neck Fan is a portable, hands-free cooling device designed for personal comfort. It features a unique 3-motor system providing 360° surrounding airflow, an LED display for battery and speed indication, and a long-lasting 5200mAh rechargeable battery.


- **3 Turbo Motors:** Delivers powerful 360° airflow for comprehensive cooling.
- **4 Speed Settings:** Customize your cooling experience from a gentle breeze to a strong gust.
- **LED Display:** Clearly shows battery level and current fan speed.
- **5200mAh Battery:** Provides extended usage time on a single charge.
- **Ergonomic Neck Support:** Designed for comfortable, hands-free wearing with a universal fit.
- **Bladeless Design:** Ensures safety and operates at a quiet 25-45 dB.



Image: The SWEETFULL S70 Neck Fan in black, showcasing its sleek design and ergonomic shape.

True 360° Cooling System

3 Motors. 150% Cooling Boost



Triple Motor Turbo

360° Cooling Around You

Image: An X-ray view illustrating the three internal turbo motors and the 360-degree cooling system.

Smart Digital Display Screen

Instant Battery & Gear Status

64%

Charge Level

F4

Fan Speed

99%

Battery Level




Image: A close-up of the smart digital display screen, showing battery percentage and fan speed.

SETUP

Unpacking

Carefully remove the neck fan and all accessories from the packaging. The package includes the neck fan, a USB-C charging cable, and this user manual.

Initial Charging

Before first use, fully charge the device. Connect the provided USB-C cable to the charging port on the fan and plug the other end into a compatible USB power adapter (not included). The LED display will indicate

the charging status and battery level. A full charge takes approximately 3 hours and provides up to 9 hours of use depending on the speed setting.




Image: An illustration of the large 5200mAh battery integrated within the neck fan, highlighting its capacity.

Wearing the Fan

Place the neck fan around your neck. The flexible design and ergonomic neck support allow for a comfortable and secure fit. Adjust the fan to ensure the airflow vents are positioned optimally for cooling. The unique hinge technology allows it to fit various neck sizes.

Adjust & Set Technology

3.5" to 7" Custom Fit



Flex-Angle Cooling

One-Size Fits Most Body Types

Image: Two individuals wearing the neck fan, demonstrating its adjustable and custom fit for different neck sizes.

Upgraded Soft Neck Support

Stay Dry & Comfortable



Environmentally friendly
materials



Wearing with zero
sensation



Image: A detailed view of the upgraded soft silicone neck support, designed for comfort and to prevent sweating.

OPERATING INSTRUCTIONS

Power On/Off

Locate the power button on the side of the fan. Press the button once to turn the fan on. The LED display will light up, showing the current fan speed and battery percentage. To turn the fan off, cycle through all speed settings until the display turns off, or press and hold the power button for a few seconds.

Adjusting Fan Speeds

Once powered on, short press the power button to cycle through the 4 available speed settings (F1, F2,

F3, F4). Each press will increase the fan speed. The LED display will update to show the selected speed.

Bladeless Design & Quiet Operation

The SWEETFULL S70 features a patented bladeless system that maintains strong airflow while operating at a low noise level (25-45 dB), comparable to library quietness. This design also prevents hair from getting caught, enhancing safety and comfort.

Your browser does not support the video tag.

Video: An official demonstration of the SWEETFULL S70 Neck Fan, including unboxing, charging, wearing, and cycling through its four speed settings. This video highlights the fan's quiet operation and effective cooling.

MAINTENANCE

Cleaning

To clean the fan, gently wipe the exterior surfaces with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water. Ensure the air inlets and outlets are free from dust and debris for optimal performance.

Storage

When not in use, store the neck fan in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to fully charge the battery before long-term storage to preserve battery health.

TROUBLESHOOTING

- **Fan not turning on:**

Check the battery level on the LED display. Recharge the fan if the battery is low. Ensure the power button is pressed and held correctly for a few seconds to activate the device.

- **Weak airflow:**

Inspect the air inlets and outlets for any obstructions like dust or lint. Clean them if necessary. Ensure the fan is fully charged, as low battery can affect performance. Increase the fan speed setting to a higher level.

- **Battery not holding charge:**

Verify that the USB-C charging cable and the power adapter are functioning correctly. Try using a different cable or adapter if available. If the issue persists, the battery may require service.

- **Unusual noise during operation:**

While the fan is designed for quiet operation, check for any foreign objects that might have entered the air vents. Ensure the fan is placed correctly around your neck and not obstructed.

SPECIFICATIONS

Brand	SWEETFULL
Model Name	S70
Color	Black

Power Source	Battery Powered
Battery Capacity	5200mAh
Product Dimensions	3.2"D x 4"W x 10"H
Item Weight	12 ounces
Noise Level	25 dB (minimum)
Number of Power Levels	4
Connector Type	USB Type C
Special Features	Portable, Neck Support, Quiet Operation, Bladeless, Digital Display

WARRANTY AND SUPPORT

Your SWEETFULL S70 Neck Fan comes with a standard manufacturer's warranty. For detailed warranty information, product support, or technical assistance, please refer to the contact information provided in the original product packaging or visit the official SWEETFULL website. Always purchase from authorized retailers to ensure valid warranty coverage.

For further assistance, you may also refer to the [SWEETFULL Store on Amazon](#).