

LINKHOO 10x30 FT - 5 Removable Sidewalls

LINKHOO 10x30 FT Outdoor Canopy Party Tent Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and effective assembly, operation, and maintenance of your LINKHOO 10x30 FT Outdoor Canopy Party Tent. Please read these instructions thoroughly before setup and retain them for future reference.

The tent measures 10 by 30 feet, offering substantial space for various outdoor gatherings. It features removable sidewalls for adaptable shading and ventilation. Constructed with a strong steel frame and waterproof material, it also provides UV protection. The design allows for customization by adding or removing walls as needed.

PRODUCT OVERVIEW



Figure 1: Fully assembled LINKHOO 10x30 FT Outdoor Canopy Party Tent with five removable sidewalls, set up on a grassy lawn.

PRODUCT SIZE



Figure 2: Diagram illustrating the dimensions of the 10x30 FT canopy tent, showing a length of 355 inches, width of 118 inches, and height of 103 inches.

SIDEWALLS ARE REMOVEABLE




Figure 3: Three images demonstrating the versatility of the tent's removable sidewalls: top shows no walls, middle shows some walls with windows, bottom shows all walls with windows.



Figure 4: Close-up images of tent components: a zippered door sidewall, a window sidewall, and a foot pad for the tent poles.

SETUP INSTRUCTIONS

Assembly of the tent is designed to be straightforward. For optimal speed and ease, it is recommended that four people participate in the installation process, which typically takes between 15 to 30 minutes.

1. Unpack all components and verify against the parts list (not provided in this manual, refer to product packaging).
2. Assemble the main frame structure by connecting the poles and joints. Ensure all connections are secure.
3. Drape the canopy cover over the assembled frame, ensuring it is centered and taut.
4. Attach the removable sidewalls as desired. These can be installed or removed to adjust for shading or ventilation.
5. Secure the tent using the provided ground nails and windproof ropes. Proper anchoring is crucial for stability.

Setup Demonstration Video

Video 1: This video demonstrates the features of a 10x30 party tent, including mesh windows and overall structure,

providing visual guidance for assembly.

Video 2: Detailed setup video for a 10x20 party tent with mesh windows, demonstrating assembly steps. While a 10x20 model, the general assembly principles apply.

Video 3: This video showcases the JupiterForce tent, highlighting its design and potential uses, which may offer additional visual context for tent features.

OPERATING THE TENT

The tent is designed for versatility in various outdoor conditions. The removable sidewalls can be adjusted to control sunlight exposure and airflow. For optimal shading, keep all sidewalls attached. For increased ventilation, remove some or all sidewalls.



Figure 5: The tent is suitable for various events, including garden parties and weddings.

MAINTENANCE

To ensure the longevity and performance of your tent, proper maintenance is essential:

- **Cleaning:** Clean the tent fabric with mild soap and water. Avoid harsh chemicals or abrasive cleaners that could damage the material.

- **Drying:** Ensure the tent fabric is completely dry before storage to prevent mold and mildew.
- **Storage:** Store the tent in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Regularly inspect poles, connectors, ropes, and ground nails for any signs of wear or damage. Replace damaged parts as necessary.



**ROPE
REINFORCEMENT**

Figure 6: Proper use of rope reinforcement is crucial for tent stability.

TROUBLESHOOTING AND SAFETY INFORMATION

Important Safety Notice: This tent is designed for temporary use in fair weather conditions. **Do not use in adverse weather conditions, including strong winds or heavy rain.** Failure to adhere to this warning can result in damage to the tent and potential injury. Dismantling and re-erecting the tent multiple times may affect its structural integrity and effectiveness over time.



**Not Suitable for
Strong Winds or
Heavy Rain**



Figure 7: Warning against using the tent in strong winds or heavy rain.

SPECIFICATIONS

Feature	Detail
Brand	LINKHOO
Model	10x30 FT - 5 Removable Sidewalls
Material	Iron (Frame), Alloy Steel (Poles)
Color	White
Item Weight	37.5 pounds
Product Dimensions	355"L x 118"W x 103"H
Ultraviolet Light Protection	Yes
Water Resistance Level	Waterproof

Floor Area	300 Square Feet
Assembly Required	Yes
UPC	705794273486

WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not available in the provided product data. Please refer to the product packaging or contact the manufacturer directly for details.