

[manuals.plus](#) /› [Rfiver](#) /› [Rfiver Rolling TV Stand \(Model TF1404OAK-U\) Instruction Manual](#)**Rfiver TF1404OAK-U**

Rfiver Rolling TV Stand (Model TF1404OAK-U) Instruction Manual

For 32-60 Inch TVs up to 88 lbs

1. PRODUCT OVERVIEW

The Rfiver Rolling TV Stand, Model TF1404OAK-U, is designed to provide a versatile and mobile solution for displaying televisions ranging from 32 to 60 inches, with a maximum weight capacity of 88 lbs. It features a sturdy wooden base, height adjustment, and a 70-degree swivel function for optimal viewing from various angles. The stand is equipped with lockable wheels for easy mobility and secure positioning.



Image: Rriver Rolling TV Stand with a TV displaying colorful boats.

2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 88 lbs (40 kg).
- **TV Size:** Ensure your TV is between 32 and 60 inches.
- **VESA Compatibility:** Verify your TV's VESA pattern is within 100x100mm to 400x400mm.
- **Stability:** Always ensure the TV is securely mounted and the wheels are locked when the stand is in a stationary position to prevent accidental movement or tipping.
- **Children and Pets:** Keep children and pets away from the stand during movement to prevent injury.
- **Surface:** Use on a flat, stable surface. While designed for various floor types, exercise caution when moving on uneven or heavily carpeted surfaces.

3. SETUP AND ASSEMBLY

This TV stand is designed for straightforward, drill-free assembly. It is recommended to have a second person assist during certain steps, especially when mounting the television.

3.1 Package Contents

Before beginning, ensure all parts are present and undamaged. Refer to the included parts list in your packaging.

WIDE TV COMPATIBILITY



Image: Diagram showing TV compatibility and weight capacity.

3.2 Assembly Steps

- Attach Wheels to Base:** Secure the four 360-degree rotating lockable wheels to the wooden base using the provided hardware. Ensure they are tightened for stability.
- Assemble Vertical Column:** Connect the vertical support column sections.
- Attach Column to Base:** Secure the assembled vertical column to the wooden base.
- Install TV Brackets:** Attach the TV mounting brackets to the back of your television, ensuring the correct VESA pattern is used.
- Mount TV to Stand:** Carefully lift the television and hook the TV brackets onto the vertical column's mounting plate.
- Secure TV with Safety Lock:** Engage the safety lock mechanism to prevent the TV from accidentally dislodging from the stand.
- Cable Management:** Use the integrated cable management system to route and organize TV cables along the vertical column.

3.3 Assembly Demonstration Video

Watch this video for a visual guide on assembling and utilizing the features of your Rfiver Rolling TV Stand.

Your browser does not support the video tag.

Video: Official product video demonstrating the features and assembly of the Rriver Rolling TV Stand, including height adjustment, swivel, and mobility.

4. OPERATING INSTRUCTIONS

4.1 Adjusting TV Height

The stand allows for flexible height adjustment to achieve an optimal viewing experience. To adjust the height, loosen the securing mechanisms on the vertical column, slide the TV to your desired height (between 49.5 and 52.0 inches), and then firmly re-tighten the mechanisms.



Image: Diagram showing height adjustment range.

4.2 Swiveling the TV

The TV mount can swivel up to 70 degrees (35 degrees left and 35 degrees right). Gently push the TV to the desired angle. This feature helps reduce glare and provides a better viewing experience from different positions in a room.

70° OF SWIVEL

OPTIMAL VIEWING ANGLE




Image: Diagram showing the 70-degree swivel capability.

4.3 Moving the TV Stand

The stand is equipped with four 360-degree rotating lockable wheels for easy movement. To move the stand, unlock all four wheels. Once the stand is in the desired position, lock all wheels to ensure stability and prevent unintended movement.

**ROLLS SMOOTHLY
ON CARPETS / FLOORS**



Image: Close-up of lockable wheels.

4.4 Cable Management

Utilize the provided cable management straps or clips to neatly route and secure all TV and accessory cables along the vertical column. This helps maintain a tidy appearance and prevents cables from becoming tangled or damaged.



Image: Cable management system.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your TV stand.

- **Cleaning:** Wipe the stand with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary.
- **Wheel Functionality:** Keep the wheels free of debris to ensure smooth rolling. Test the locking mechanism regularly.

6. TROUBLESHOOTING

If you encounter issues with your Rfiver Rolling TV Stand, refer to the following common solutions:

- **TV Does Not Fit:** Double-check your TV's size, weight, and VESA mounting pattern against the specifications (32-60 inches, max 88 lbs, VESA 100x100-400x400mm). Ensure you are using the correct screws and spacers for your TV model.
- **Stand is Unstable:** Verify that all assembly hardware is securely tightened. Ensure the stand is placed on a flat, level surface. If moving, ensure wheels are locked once in position.
- **Wheels Not Rolling Smoothly:** Check for any debris (hair, dust, carpet fibers) caught in the wheels. Clean as necessary. Ensure the wheel locks are fully disengaged.
- **TV Not Swiveling:** Ensure no cables are snagged or preventing movement. The swivel mechanism should operate smoothly with gentle pressure.

7. SPECIFICATIONS

Feature	Specification
Model Number	TF1404OAK-U
Compatible TV Sizes	32 - 60 inches
Maximum Weight Capacity	88 lbs (40 kg)
VESA Compatibility	100x100mm to 400x400mm
Height Adjustment Range	49.5 - 52.0 inches
Swivel Angle	±35° (70° total)
Base Dimensions	16.7 x 12.8 x 1 inches (approx.)
Item Weight	15.27 lbs
Color	White






8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Rfiver customer service directly. You can also visit the official Rfiver store for more information:

[Visit the Rfiver Store](#)

© 2025 Rfiver. All rights reserved.

Related Documents - TF1404OAK-U

	<p>RFIVER TF3001U TV Stand Installation Manual</p> <p>Detailed installation guide for the RFIVER TF3001U TV Stand, including parts list, step-by-step assembly instructions, VESA compatibility chart, and safety guidelines. Learn how to safely mount your TV.</p>
	<p>Rfiver TF2002 TV Stand Assembly Instructions and User Guide</p> <p>Comprehensive guide for assembling the Rfiver TF2002 TV stand. Includes parts list, step-by-step instructions, safety warnings, and cable management tips for your floor TV mount.</p>
	<p>Rfiver Universal Swivel Tabletop TV Stand Assembly Manual</p> <p>Assembly manual for the Rfiver Universal Swivel Tabletop TV Stand, Model UT2001. Provides step-by-step instructions and parts list for safe and proper installation.</p>
	<p>RFIVER UT5002 TV Stand Assembly Instructions and User Guide</p> <p>This document provides assembly instructions, parts list, and safety notices for the RFIVER UT5002 TV Stand. Learn how to safely assemble and install your TV stand for optimal viewing.</p>
	<p>RFIVER TF3001U TV Stand Installation Manual</p> <p>Detailed installation guide for the RFIVER TF3001U TV Stand, including parts list, step-by-step assembly instructions, VESA compatibility chart, and safety guidelines. Learn how to safely mount your TV.</p>
	<p>Latitude Run Convertible Sofa Assembly Instructions</p> <p>Detailed assembly instructions for the Latitude Run Convertible Sofa, including parts list, step-by-step guidance, and cushion care tips.</p>