Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SOBERNA A3

FAMOO Wireless Earbuds User Manual

Model: A3

Introduction

Thank you for choosing the FAMOO Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

Safety Information

- Do not disassemble or modify the earbuds or charging case.
- Keep the device away from extreme temperatures, humidity, and corrosive substances.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Keep out of reach of children and pets.
- Use only the provided charging cable or a certified equivalent.

Package Contents

- FAMOO Wireless Earbuds (L/R)
- Charging Case
- USB Charging Cable
- User Manual

Product Overview

Familiarize yourself with the components of your FAMOO Wireless Earbuds and charging case.



Image: The FAMOO Wireless Earbuds in their charging case. The case features a digital LED display showing battery percentages for the case and individual earbuds (L and R). The earbuds themselves have touch control areas indicated by a fingerprint icon.

Earbud Components:

- **Touch Control Area:** For managing playback, calls, and voice assistant.
- **LED Indicator:** Shows pairing status and battery level.
- **Microphone:** For calls and voice commands.
- **Charging Contacts:** For charging inside the case.

Charging Case Components:

- **LED Digital Display:** Shows the charging case battery percentage and individual earbud battery levels (L and R).
- **USB-C Charging Port:** For charging the case.
- **Earbud Charging Slots:** Securely holds and charges the earbuds.

Setup

1. Charging the Earbuds and Case

1. **Initial Charge:** Before first use, fully charge both the earbuds and the charging case.
2. **Charging the Case:** Connect the provided USB charging cable to the charging port on the case and a USB power source (e.g., computer, wall adapter). The LED display will show the battery percentage increasing.
3. **Charging the Earbuds:** Place the earbuds into their respective slots in the charging case. They will automatically begin charging. The LED display on the case will show the charging status of each earbud.
4. **Full Charge Indication:** The LED display will show "100" for the case and full battery icons for the earbuds when fully charged.

2. Pairing with Your Device

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode. The LED indicator on the earbuds will flash.
2. **Activate Bluetooth:** On your device (smartphone, tablet, computer), go to the Bluetooth settings and enable Bluetooth.
3. **Select Device:** Look for "FAMOO A3" (or similar name) in the list of available Bluetooth devices and select it to connect.
4. **Connection Confirmation:** Once successfully paired, the earbud LED indicators will turn off, and you will hear an audible confirmation.
5. **Automatic Reconnection:** After the initial pairing, the earbuds will automatically connect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.

Operating Instructions

Wearing the Earbuds

Gently insert the earbuds into your ears, ensuring a comfortable and secure fit. Adjust them until the sound quality is optimal and they feel stable.

Touch Controls

Function	Action (Left/Right Earbud)
Play/Pause	Single tap
Next Track	Double tap (Right earbud)
Previous Track	Double tap (Left earbud)
Volume Up	Triple tap (Right earbud)
Volume Down	Triple tap (Left earbud)

Function	Action (Left/Right Earbud)
Answer/End Call	Single tap
Reject Call	Press and hold for 2 seconds
Activate Voice Assistant	Press and hold for 3 seconds

Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are IP7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. However, the charging case is not waterproof. Do not expose the charging case to liquids. Ensure earbuds are dry before placing them back in the case.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge regularly.

Troubleshooting

Problem	Solution
Earbuds not charging	◦ Ensure the charging cable is securely connected to both the case and the power source. ◦ Check if the charging contacts on the earbuds and inside the case are clean and free of debris. ◦ Try a different charging cable or power adapter.
Earbuds not pairing with device	◦ Ensure Bluetooth is enabled on your device. ◦ Make sure the earbuds are in pairing mode (LED flashing). ◦ Forget "FAMOO A3" from your device's Bluetooth list and try pairing again. ◦ Ensure the earbuds are charged. ◦ Try restarting your device and the earbuds (by placing them back in the case and taking them out).
Only one earbud working	◦ Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and take them out again. ◦ Ensure both earbuds are charged. ◦ Reset the earbuds (refer to specific reset instructions if available, otherwise try re-pairing).

Problem	Solution
Poor sound quality or disconnections	◦ Ensure the earbuds are within the Bluetooth range of your device (typically 10 meters/33 feet). ◦ Avoid obstacles between the earbuds and your device. ◦ Check for interference from other wireless devices. ◦ Ensure the earbuds are clean and free of earwax buildup.

Specifications

Feature	Detail
Model Name	A3
Connectivity Technology	Wireless (Bluetooth V5.4)
Ear Placement	In Ear
Form Factor	In Ear
Color	Black
Waterproof Rating	IP7 (Earbuds only)
Playtime	Up to 48 hours (with charging case)
Manufacturer	soberna

Warranty and Support

FAMOO products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official SOBERNA website. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6CR65K6

More documents and user manuals: **https://manuals.plus/**