

TecTake 405373-3

Instruction Manual

TECTAKE0 RATTAN STORAGE CABINET WITH 4 COMPARTMENTS

Model: 405373-3

Safety Information	Package Contents	Setup & Assembly	Operation	Maintenance
Troubleshooting	Specifications	Warranty & Support		

1. Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure all components are present and undamaged before beginning assembly.
- Assemble the cabinet on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly to avoid damaging components.
- This cabinet is designed for outdoor storage. While water-resistant, it is not fully waterproof. Protect sensitive items from prolonged exposure to heavy rain.
- Do not exceed the maximum load capacity of 15 kg per shelf or 75 kg total.
- Keep children away from the assembly area. Small parts can be a choking hazard.
- The safety glass top is durable but can break if subjected to extreme impact. Handle with care.

2. Package Contents

Verify that all the following parts are included in your package:

- Rattan Cabinet Panels (sides, back, top, bottom)
- Aluminium Frame Components
- 2 Hinged Doors
- Safety Glass Top
- Adjustable Shelves (quantity may vary, typically 2-3)

- Magnetic Closure Mechanisms
- Elegant Handles (2 pieces)
- Assembly Hardware (screws, nuts, washers, floor-protecting plastic caps)
- Assembly Tool (e.g., Allen key)

3. Setup & Assembly

Follow these steps to assemble your tectake0 Rattan Storage Cabinet. It is recommended to have two people for assembly.



Image: Fully assembled tectake0 Rattan Storage Cabinet, showcasing its design and internal compartments.

1. **Prepare the Base Frame:** Lay out the bottom aluminium frame components. Connect them using the provided screws and the assembly tool. Ensure the frame is stable and square. Attach the floor-protecting plastic caps to the bottom of the legs.
2. **Attach Side Panels:** Secure the side rattan panels to the assembled base frame. Use the appropriate screws, ensuring they are finger-tight initially.
3. **Install Back Panel:** Slide or attach the back rattan panel into the designated grooves or attachment points on the side panels. Secure it with screws.

4. **Assemble Top Frame:** Connect the top aluminium frame components. Place this frame onto the top edges of the side and back panels. Secure it with screws.
5. **Insert Shelves:** Place the adjustable shelves into the desired positions within the cabinet. The cabinet features multiple slots for shelf height adjustment. Ensure shelves are level and securely seated. The cabinet typically has 4 compartments, meaning 3 shelves are included.



Image: Visual representation of the cabinet's internal structure and shelf placement options.

6. **Attach Doors:** Mount the two hinged doors to the front frame of the cabinet. Align the hinges and secure them with screws. Test the door swing to ensure smooth operation.
7. **Install Handles:** Attach the elegant handles to the front of each door. Ensure they are firmly secured.



Rust-free frame
made from weather-resistant aluminium



Premium polyrattan
weave is very durable and high-quality



Ample storage space
can be divided and organised with shelves



Secure closure
of the two hinged doors with a magnetic system

Image: Detail of the elegant handles, showing their design and attachment point on the door.

- 8. Install Magnetic Closures:** Attach the magnetic closure mechanisms to the top interior of the cabinet frame and the corresponding points on the doors. These ensure the doors remain securely closed.





Image: Detailed view of the magnetic closure system, demonstrating how it secures the doors.

9. **Place Safety Glass Top:** Carefully place the safety glass top onto the top surface of the cabinet. It should sit securely within the frame. The glass top is removable for cleaning or relocation.



1. **Low-maintenance garden cabinet** made from elegant polyrattan weave and a sturdy aluminum frame with 4 compartments



2. **Removable safety glass top** is held in place by suction cups and is resistant to high impacts and shocks



3. **2 hinged doors with stylish handles** are smooth-operating and provide comfortable and easy access to the contents



4. **Strong magnetic closure** allows for highly reliable and pleasantly quiet opening and closing

Image: Close-up of the safety glass top, highlighting its placement and finish.

10. **Final Tightening:** Once all components are in place and aligned, carefully tighten all screws. Do not overtighten.

4. Operating Instructions

Using your tectake0 Rattan Storage Cabinet is straightforward:

- **Opening Doors:** Gently pull the handles to disengage the magnetic closure and open the doors.
- **Closing Doors:** Push the doors firmly until the magnetic closures engage, ensuring they are securely shut.
- **Storing Items:** Place items evenly on the shelves, ensuring not to exceed the weight limit of 15 kg per shelf. Distribute weight to maintain stability.
- **Adjusting Shelves:** To adjust shelf height, remove all items from the shelf, lift the shelf, and reposition it into the desired slots. Ensure it is fully seated before placing items back.

5. Maintenance

To ensure the longevity and appearance of your cabinet:

- **Cleaning:** Wipe the rattan surfaces with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. For the glass top, use a standard glass cleaner.
- **Frame Care:** The aluminium frame is rust-resistant. If necessary, wipe it clean with a damp cloth.
- **Seasonal Care:** While designed for outdoor use, consider covering the cabinet during extreme weather conditions (heavy snow, prolonged freezing temperatures) to extend its lifespan.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

6. Troubleshooting

Problem	Possible Cause	Solution
Doors do not close properly.	Misaligned hinges or magnetic closures.	Check hinge alignment and adjust if needed. Ensure magnetic plates on doors and frame are aligned.
Cabinet feels wobbly.	Loose screws or uneven surface.	Tighten all assembly screws. Move cabinet to a level surface.
Glass top slides.	Not properly seated or missing suction cups (if applicable).	Ensure the glass top is correctly placed within the frame's recess. If suction cups were provided, ensure they are in place.
Water inside cabinet after rain.	Heavy rain or cabinet not fully waterproof.	This cabinet is water-resistant, not fully waterproof. For sensitive items, use waterproof containers inside or cover the cabinet during heavy precipitation.

7. Specifications




Feature	Detail
Product Dimensions (Overall)	84.5 cm (W) x 40.5 cm (D) x 103.5 cm (H)
Interior Dimensions	83 cm (W) x 35 cm (D) x 94.5 cm (H)
Glass Top Dimensions	83.5 cm x 39 cm x 0.5 cm
Load Capacity per Shelf	15 kg


Feature	Detail
Total Load Capacity	75 kg
Weight	15.5 kg
Material (Base)	Aluminium, Polyethylene (Rattan Weave)
Material (Top)	Safety Glass
Water Resistance Level	Water-resistant
Model Number	405373-3

8. Warranty & Support

For warranty information and customer support, please refer to the purchase documentation or contact TecTake customer service directly. Keep your proof of purchase for any warranty claims. You can visit the TecTake Store for more information:[TecTake Official Store](#)

Related Documents

	<p>TecTake Rattan Garden Furniture Assembly Instructions</p> <p>Comprehensive assembly instructions for TecTake rattan garden furniture sets, including a detailed parts list and step-by-step visual guidance. Model numbers: 403696, 403697, 403880, 403881.</p>
	<p>TecTake Cabinet Assembly Instructions - Models 402483, 402938</p> <p>Comprehensive assembly guide for TecTake cabinets (models 402483, 402938), featuring a detailed parts list and step-by-step instructions with textual descriptions of diagrams.</p>
	<p>tectake Gazebo Instruction Manual - Assembly Guide</p> <p>Comprehensive instruction manual for assembling and maintaining your tectake gazebo. Includes parts list, step-by-step assembly, location advice, care instructions, and contact information.</p>



[TecTake 402486/402941 Furniture Assembly Instructions](#)

Comprehensive assembly manual for TecTake furniture models 402486 and 402941, providing step-by-step instructions and a parts list for building the unit.