

EXREIZST MP-802P

EXREIZST MP-802P Cold Press Juicer Instruction Manual

Model: MP-802P | Brand: EXREIZST

1. INTRODUCTION

Thank you for choosing the EXREIZST MP-802P Cold Press Juicer. This appliance is designed to efficiently extract juice from a variety of fruits and vegetables, preserving nutrients through its slow masticating technology. Please read this manual thoroughly before operation to ensure safe and optimal performance.

Important Safety Information

- Always ensure the juicer is properly assembled before connecting to power.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils away from moving parts during operation. Use the food pusher provided.
- Unplug the juicer from the power outlet before cleaning, assembling, or disassembling.
- This appliance is not intended for use by children. Supervise children to ensure they do not play with the appliance.
- Avoid juicing hard items such as lemons, sugarcane, ice, or nuts, as this can damage the appliance.
- The juicer features an automatic safety stop if the cover is opened during operation.

2. PRODUCT COMPONENTS

Familiarize yourself with the parts of your EXREIZST MP-802P Cold Press Juicer:

1. Motor Base
2. Juice Cup
3. Pulp Collection Cup
4. Auger (Spiral Extractor)
5. Filter Screen (Metal-free, Detachable)

6. Feed Chute Assembly (with Lid)
7. Food Pusher
8. Cleaning Brush



Figure 2.1: Main Components of the EXREIZST MP-802P Juicer

3. SETUP AND ASSEMBLY

Follow these steps to assemble your juicer before first use:

1. **Install the Juice Cup and Pulp Collection Cup:** Place the juice cup under the juice outlet and the pulp collection cup under the pulp outlet on the motor base.
2. **Install the Filter Screen:** Place the metal-free filter screen onto the motor base, ensuring it sits securely.
3. **Screw in the Auger:** Insert the spiral auger into the center of the filter screen and rotate it gently until it locks into place.
4. **Install the Feed Chute Assembly:** Align the feed chute assembly with the motor base. Ensure the alignment marks are matched. Rotate the feed chute clockwise until it clicks into the locked position. The juicer will not operate if not correctly locked.
5. **Close the Lid:** Ensure the lid of the feed chute is securely closed and locked. The juicer has a safety mechanism that prevents operation if the lid is open.



Figure 3.1: Quick Installation Steps



Figure 3.2: Lid Safety Mechanism and Correct Assembly

4. OPERATING INSTRUCTIONS

Operating your EXREIZST juicer is straightforward:

1. **Prepare Ingredients:** Wash fruits and vegetables thoroughly. For most items, the 5.3-inch large feed chute allows you to insert whole fruits and vegetables without pre-chopping. Remove any hard pits or large seeds.
2. **Connect Power:** Plug the juicer into a suitable power outlet.
3. **Start Juicing:** Turn the control knob to the 'ON' position. The auger will begin to rotate slowly.
4. **Feed Ingredients:** Gradually feed the prepared fruits and vegetables into the feed chute. Use the food pusher to gently guide ingredients down, if necessary. Do not force ingredients into the chute.
5. **Reverse Function:** If ingredients become clogged, turn the knob to the 'REV' (Reverse) position for a few seconds to clear the blockage, then return to 'ON' to resume juicing.
6. **Finish Juicing:** Once all ingredients are processed, turn the knob to the 'OFF' position and unplug the appliance.

Tips for Best Results:

5. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your juicer. Always unplug the appliance before cleaning.

1. **Disassembly:** Rotate the feed chute assembly counter-clockwise to unlock and remove it. Then, remove the auger and filter screen from the motor base.
2. **Rinse Parts:** Rinse all detachable parts (feed chute, lid, auger, filter screen, juice cup, pulp cup) under running water immediately after use to prevent pulp from drying and sticking.
3. **Use Cleaning Brush:** Use the provided cleaning brush to remove any stubborn pulp residue from the filter screen and other components.
4. **Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse it in water.
5. **Drying:** Allow all parts to air dry completely before reassembling or storing.
6. **Sealing Plug:** For thorough cleaning, open the sealing plug at the bottom of the pulp outlet to remove any trapped pulp, then install it back into place before next use.

Note: All detachable parts are recommended for hand washing only. Do not wash in a dishwasher.



Figure 5.1: Rinsing Detachable Juicer Parts



Figure 5.2: Upgraded Metal-Free Detachable Filter



Figure 5.3: Cleaning Instructions for Sealing Plug

6. TROUBLESHOOTING

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not properly assembled or lid not closed. Power cord not plugged in.	Ensure all parts are correctly assembled and locked. Close the lid securely. Check power connection.
Juicer stops during operation.	Lid opened accidentally. Overload protection activated.	Ensure lid is closed. If overloaded, turn off, unplug, clear blockage, and wait 15-20 minutes before restarting.
Pulp is wet, or low juice yield.	Ingredients fed too quickly. Filter screen clogged.	Feed ingredients slowly. Clean the filter screen thoroughly.
Loud noise or vibration.	Improper assembly. Hard ingredients.	Check assembly. Avoid juicing hard items like ice or nuts.

If the problem persists after trying these solutions, please contact customer support.

7. SPECIFICATIONS

Brand	EXREIZST
Model Name	Slow Juicer (MP-802P)
Power	300W
Special Features	Cold Press Juicer, Efficient Physical Juicing, Overheat Protection, Quiet Motor, Whole Fruit Processing, 5.3" Large Feed Chute, BPA Free, Metal-free Filter
Product Dimensions	15"D x 5.5"W x 7.8"H
Item Weight	9.06 pounds
Product Care Instructions	Hand Wash Only

8. WARRANTY AND SUPPORT

EXREIZST is committed to providing high-quality products and customer satisfaction. If you have any questions, concerns, or require assistance with your MP-802P Cold Press Juicer, please do not hesitate to contact our customer service team.

Please refer to your purchase documentation for specific warranty details and contact information. Our professional customer service team will provide a solution as soon as possible.

For support, you may visit the official EXREIZST store on Amazon: [EXREIZST Store](#)

