

GIVI E340NT2

GIVI 34L MONOLOCK Tech Case E340NT2 User Manual

Model: E340NT2

1. INTRODUCTION

Thank you for choosing the GIVI 34L MONOLOCK Tech Case, model E340NT2. This top-case is designed to provide secure and convenient storage for your motorcycle, enhancing your riding experience with its robust construction and practical features. This manual provides essential information for the proper installation, operation, and maintenance of your GIVI MONOLOCK Tech Case.



Image 1.1: The GIVI 34L MONOLOCK Tech Case E340NT2, showcasing its sleek black design with silver internal lenses.

2. SETUP AND INSTALLATION

The GIVI E340NT2 MONOLOCK Tech Case comes with a universal mounting plate for installation on most motorcycles equipped with a rear rack. Ensure your motorcycle's rear rack is suitable for carrying the weight of the case and its contents.

2.1. Package Contents

- GIVI 34L MONOLOCK Tech Case (E340NT2)
- Universal Mounting Plate
- Mounting Hardware (bolts, washers, clamps)
- Keys for the locking mechanism

2.2. Mounting Plate Installation

1. Position the universal mounting plate on your motorcycle's rear rack. Ensure it is centered and aligned properly.
2. Use the provided mounting hardware (bolts, washers, and clamps) to secure the plate to the rack.

Tighten all fasteners evenly to ensure a stable and secure fit. Do not overtighten.

3. Verify that the mounting plate is firmly attached and does not wobble.

2.3. Case Attachment

1. Align the bottom of the GIVI case with the locking mechanism on the installed universal mounting plate.
2. Press down firmly on the case until you hear a 'click', indicating that it is securely locked onto the plate.
3. Gently pull upwards on the case to confirm it is properly attached and cannot be easily removed without using the key.



Image 2.1: The GIVI MONOLOCK Tech Case securely mounted on the rear rack of a motorcycle.

3. OPERATING INSTRUCTIONS

3.1. Opening the Case

1. Insert the key into the lock cylinder located at the front of the case.
2. Turn the key to the 'unlock' position.
3. Press the release button (usually integrated with the lock mechanism) to unlatch the lid.

4. Lift the lid to access the interior of the case.

3.2. Closing and Locking the Case

1. Lower the lid until it clicks shut. Ensure it is fully closed.
2. Turn the key to the 'lock' position and remove it. This secures the lid and prevents unauthorized opening.

3.3. Detaching the Case from the Motorcycle

1. Ensure the case is unlocked (key turned to 'unlock' position).
2. Locate the red release button or lever, typically near the lock mechanism on the case or mounting plate.
3. Press and hold the release button/lever while simultaneously lifting the case upwards from the mounting plate.
4. The case should detach smoothly.

3.4. Carrying Capacity

The GIVI E340NT2 has a capacity of 34 liters. Always adhere to the maximum load capacity specified by GIVI and your motorcycle manufacturer. Overloading can affect motorcycle handling and stability.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your GIVI Tech Case.

4.1. Cleaning

- Clean the exterior of the case with a mild soap solution and a soft cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- Rinse thoroughly with water and dry with a clean, soft cloth.
- For the interior, wipe with a damp cloth and allow to air dry completely before closing.

4.2. Lock Mechanism

- Periodically lubricate the lock cylinder and key mechanism with a small amount of graphite powder or a silicone-based lubricant.
- Ensure the key turns smoothly and the locking mechanism engages correctly.

4.3. Mounting Hardware

- Regularly check all mounting bolts and clamps for tightness. Vibrations from riding can cause them to loosen over time.
- Inspect the universal mounting plate for any signs of wear or damage. Replace components if necessary.

5. TROUBLESHOOTING

5.1. Case Not Locking Properly

- **Check Lid Alignment:** Ensure the lid is properly aligned with the base of the case before attempting to close and lock.
- **Clear Obstructions:** Verify that no items inside the case are preventing the lid from closing completely.
- **Lubricate Lock:** Apply lubricant to the lock mechanism as described in the Maintenance section.

5.2. Difficulty Detaching Case

- **Ensure Unlocked:** Confirm the key is in the 'unlock' position.
- **Press Release Button Firmly:** Ensure the release button/lever is fully depressed while lifting the case.
- **Check for Debris:** Inspect the mounting plate and case's locking mechanism for any dirt or debris that might be causing a jam.

5.3. Water Inside Case

- **Check Lid Seal:** Inspect the rubber seal around the lid for any damage, cracks, or misalignment.
- **Ensure Lid is Fully Closed:** Make sure the lid is completely closed and latched before riding in wet conditions.
- While GIVI cases offer good weather protection, they are not always 100% waterproof under extreme conditions. Consider using waterproof bags for sensitive items.

6. SPECIFICATIONS

Feature	Detail
Model	E340NT2
Brand	GIVI
Capacity	34 Liters
Color	Black with silver internal lenses
Material	Metal (main construction), Plastic (outer shell)
Mounting Type	MONOLOCK System (Universal Mounting Plate included)
Approximate Dimensions (L x W x H)	11.79 in (30 cm) x 11 in (28 cm) x 8.25 in (21 cm)
GTIN (Global Trade Item Number)	08019606352620

7. WARRANTY AND SUPPORT

7.1. Warranty Information

Specific warranty details for the GIVI 34L MONOLOCK Tech Case E340NT2 are not provided in this manual. Please refer to the warranty documentation included with your purchase or contact your authorized GIVI retailer or the official GIVI website for comprehensive warranty terms and conditions.

7.2. Customer Support

For technical assistance, spare parts, or any other inquiries regarding your GIVI product, please contact your local authorized GIVI dealer or visit the official GIVI website. Ensure you have your product model number (E340NT2) and proof of purchase available when seeking support.

