**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**IQIRAF B0F6KBNL84**

# IQIRAF Foldable 4-Wheel Mobility Scooter User Manual

Model: B0F6KBNL84

## Introduction

Thank you for choosing the IQIRAF Foldable 4-Wheel Mobility Scooter. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new mobility device. Please read this manual thoroughly before using the scooter to ensure proper function and safety.

## Important Safety Information

Always prioritize safety when operating your mobility scooter. Failure to follow these instructions could result in injury or damage to the scooter.

- **Read the Entire Manual:** Familiarize yourself with all controls, features, and operating procedures before first use.
- **Weight Capacity:** Do not exceed the maximum weight recommendation of 150 kg (300 lbs).
- **Pre-Operation Check:** Before each use, ensure all components are securely fastened, tires are in good condition, and the battery is sufficiently charged.
- **Environmental Conditions:** Avoid operating the scooter in extreme weather conditions, on excessively steep inclines, or on uneven terrain that could compromise stability.
- **Visibility:** Use headlights and reflectors during low-light conditions to ensure visibility to others.
- **Braking:** The scooter is equipped with electromagnetic brakes. Understand how they function and test them in a safe area before operating in public.
- **Children and Pets:** Keep children and pets away from the scooter during operation and when it is charging.

## Setup and Assembly

The IQIRAF mobility scooter requires minimal assembly. Follow these steps to prepare your scooter for use.

1. **Unpack Components:** Carefully remove all parts from the packaging. You should have the main scooter body, seat, armrests, and front basket.
2. **Raise the Tiller:** Loosen the knob at the base of the tiller (steering column). Lift the tiller to your desired angle. The tiller has gears for secure positioning. Tighten the knob firmly to lock it in place.
3. **Install the Seat:** Align the seat post with the receiver on the scooter body. Push down firmly until the seat is securely

seated. The seat can swivel and be locked into position using the lever underneath.

4. **Attach Armrests:** Slide the armrests into the designated slots on either side of the seat. Use the provided knobs to tighten them in place, adjusting for desired width.
5. **Attach Front Basket:** Slide the front basket onto the mounting bracket located at the front of the tiller. Ensure it is securely seated.




Image: Scooter components ready for assembly, including the main body, seat, armrests, and basket.




Image: The IQIRAF mobility scooter fully assembled and ready for use.

Video: A person demonstrating the simple assembly process of the IQIRAF mobility scooter, including attaching the tiller, seat, and armrests.

## Operating Instructions

Understand the controls and features for safe and effective operation.

## Controls Overview




Image: Detailed view of the scooter's dashboard, showing the key ignition, speed dial, battery level indicator, headlight switch, and horn button.

- **Key Ignition:** Insert the key and turn to the 'ON' position to power on the scooter. Only the provided key will start the scooter.
- **Speed Dial:** Adjust the maximum speed using the dial on the dashboard. The scooter has a top speed of 10 km/h (6.2

mph).

- **Direction Control:** Use the levers on the handlebars to control forward and reverse motion.
- **Battery Level Indicator:** Monitor the battery charge level on the dashboard to avoid unexpected power loss.
- **Headlights and Horn:** Activate the headlights for improved visibility and use the horn to alert others.

## Driving and Maneuvering

- **Steering:** The scooter features flexible steering for easy navigation in various environments.
- **Braking System:** The scooter is equipped with powerful electromagnetic brakes that engage automatically when the throttle is released, providing reliable stopping power.
- **Terrain Capability:** The scooter is designed to handle varied terrain, including gravel, grass, and mud, thanks to its explosion-proof tires and robust motor.
- **Cornering:** The compact design allows for tight-turn handling with a 45-degree cornering capability, maintaining stability.
- **Nighttime Operation:** Bright headlights provide remote illumination, enhancing safety during evening use.




Image: A person operating the mobility scooter on a paved path, demonstrating its use for daily outings.




Image: The scooter performing a tight 45-degree turn, highlighting its maneuverability in confined spaces.




Image: The scooter's bright headlights illuminating a path at night, ensuring visibility and safety.




Image: Close-up of the scooter's tires, illustrating its capability to traverse gravel, grass, and mud.

Video: Demonstrations of the scooter's flexible steering, powerful driving force, remote illumination, ability to travel over rough terrain, and downhill safety features.

## Folding and Storage

The scooter features a foldable frame for convenient transport and storage.

- Consult the specific folding mechanism instructions provided with your scooter for detailed steps.
- Once folded, the compact design allows it to fit into most vehicle trunks.




Image: The mobility scooter in its folded configuration, demonstrating its compact size for travel and storage.




Image: Diagram showing the dimensions of the scooter, including its height, width, and length, useful for assessing storage space.

## Battery Charging

The scooter is powered by a battery. Proper charging ensures optimal performance and battery longevity.

- Always use the charger provided with your scooter.
- Plug the charger into a standard wall outlet and then connect it to the scooter's charging port.
- Charge the battery fully before first use and after each significant period of use.

- Avoid completely draining the battery, as this can reduce its lifespan.
- Do not interrupt the charging cycle.
- The average battery life is 2.58 hours, providing a range of up to 15.5 miles.

## Maintenance

Regular maintenance helps ensure the longevity and safe operation of your scooter.

- **Cleaning:** Wipe down the scooter with a damp cloth. Avoid using excessive water or harsh chemicals.
- **Tire Inspection:** Regularly check the 9-inch explosion-proof tires for wear or damage.
- **Battery Care:** Store the scooter with a charged battery. If storing for extended periods, charge the battery at least once a month.
- **Fastener Checks:** Periodically check all nuts, bolts, and fasteners to ensure they are tight.
- **Professional Service:** For any complex repairs or issues, contact qualified service personnel.

## Troubleshooting

If you encounter issues with your scooter, refer to the following common troubleshooting tips:

- **Scooter Does Not Power On:** Ensure the key is fully inserted and turned to the 'ON' position. Check the battery level and ensure it is charged. Verify all electrical connections are secure.
- **Loss of Power During Operation:** This typically indicates a low battery. Charge the battery immediately.
- **Unresponsive Controls:** Check that the scooter is powered on and the key is correctly inserted. If issues persist, power off and restart the scooter.
- **Unusual Noises:** Stop using the scooter immediately and inspect for loose parts or obstructions. Contact customer support if the noise continues.

## Specifications

| Feature | Specification |
|---|---|
| Brand | IQIRAF |
| Model Number | B0F6KBNL84 |
| Color | Red |
| Material | Alloy Steel |
| Maximum Weight Recommendation | 150 Kilograms (300 lbs) |
| Maximum Speed | 6.2 Miles per Hour (10 km/h) |
| Wheel Size | 9 Inches |
| Brake Style | Electromagnetic Brake |
| Power Source | Battery Powered |
| Battery Average Life | 2.58 Hours |

| | |
|---|---|
| Special Features | Foldable, Portable |
| Seat Depth | 35.6 Centimetres |
| Assembly Required | Yes |

## Warranty and Support

IQIRAF is committed to providing comprehensive customer support.

- For assistance with setup, operation, or any product-related inquiries, please contact our customer support team.
- Refer to your purchase documentation for specific warranty details and return policy information.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

### Answered questions about this manual

**How long should the first battery charge take for the IQIRAF B0F6KBNL84 Foldable 4-Wheel Mobility Scooter?**

The user manual for the IQIRAF B0F6KBNL84 Foldable 4-Wheel Mobility Scooter does not specify a precise number of hours for the initial charge, but it provides the following critical instructions for battery care: Charge...

Read full answer

**Is the battery removable on the IQIRAF B0F6KBNL84 Foldable 4-Wheel Mobility Scooter?**

Based on the provided manual for the IQIRAF Foldable 4-Wheel Mobility Scooter (Model B0F6KBNL84), the

documentation does not explicitly state that the battery is removable. The instructions for charging specify connecting the charger directly...

**Read full answer**

---

**Open the live page**

**https://manuals.plus/asin/B0F6KBNL84**

More documents and user manuals: **https://manuals.plus/**