

SM-X620 / X626B

User Manual for Touch Keyboard Case with Mouse

Model: SM-X620 / X626B

1. PRODUCT OVERVIEW

This user manual provides detailed instructions for the Touch Keyboard Case designed for the Samsung Galaxy Tab S10 FE+ Plus 13.1 Inch 2025 Model (SM-X620/X626B). This product includes a magnetically detachable Bluetooth keyboard with a touchpad and a wireless mouse, enhancing your tablet's functionality for productivity and convenience.



Figure 1: The Touch Keyboard Case, showing the keyboard, tablet, and included wireless mouse.

Excellent Color & Feel

Cute Round keys make your keyboard is more beautiful. Nomatter in School, business , home and other places,this keyboard case can offer great feel,there are multiple colors to fit your needs.



Figure 2: The keyboard case in blue, highlighting the round key design.

2. PACKAGE CONTENTS

Please verify that all items are present in the package:

- Tablet Case (1)
- Bluetooth Keyboard (1)
- Wireless Mouse (1)
- USB Charging Cable (1)

3. COMPATIBILITY

This keyboard case is specifically designed for the following tablet model:

Samsung Galaxy Tab S10 FE+ 13.1 inch 2025 Model (SM-X620 / X626B)

Important: This product is not compatible with any other tablet models, including the Galaxy Tab S10+ Plus 12.4-inch 2024 (SM-X820/SM-X826B/SM-X828U) or Galaxy Tab S10 FE 10.9-inch 2025 (SM-X520/X526B/X528U).

Compatibility



Compatible with the
Samsung Galaxy Tab
S10 FE+ Plus 13.1-inch 2025
(Model: SM-X620 / X626B)



Galaxy Tab S10+ Plus
12.4-inch 2024
SM-X820/SM-X826B/SM-X828U



Galaxy Tab S10 FE 10.9"2025
(SM-X520/X526B/X528U)



Figure 3: Visual guide for tablet compatibility, highlighting the correct model.

4. SETUP AND CONNECTION

4.1. Keyboard Setup

1. **Charge the Keyboard:** Fully charge the keyboard using the provided USB cable. The charging indicator light will illuminate and then turn off once fully charged.
2. **Turn On Keyboard:** Locate the power switch on the keyboard and slide it to the "ON" position.
3. **Activate Bluetooth Pairing:** Press the "Fn" key and the "C" key simultaneously to enable the keyboard's Bluetooth pairing mode. The Bluetooth indicator light will blink.
4. **Connect to Tablet:**
 - On your Samsung Galaxy Tab, navigate to **Settings**.
 - Select **Connected devices** or **Bluetooth**.
 - Ensure Bluetooth is enabled.

- Scan for available devices. The keyboard will appear as a discoverable device (e.g., "Bluetooth Keyboard").
- Tap on the keyboard name to connect.

5. **Select Android System:** After successful connection, press the "**Fn**" key and the "**Q**" key simultaneously to set the keyboard to Android system mode. This ensures proper functionality with your Samsung tablet.

Trackpad Keyboard

Detachable Bluetooth keyboard with Touchpad transforms your tablet into a laptop in less than a second.



Figure 4: The detachable Bluetooth keyboard with integrated touchpad.

4.2. Mouse Setup

The wireless mouse supports both Bluetooth and 2.4G wireless connections.

- **Bluetooth Connection:** Follow similar steps as the keyboard to pair the mouse via Bluetooth in your tablet's settings.
- **2.4G Wireless Connection:** Insert the USB receiver (usually found in the mouse's battery compartment) into a USB port on your tablet (an adapter may be required if your tablet does not have a full-size USB port). The mouse should connect automatically.



Figure 5: The wireless mouse, supporting both Bluetooth and 2.4G connections.

5. OPERATING INSTRUCTIONS

5.1. Keyboard Usage

- **Typing:** Use the keyboard as you would a standard laptop keyboard.
- **Touchpad:** The integrated touchpad allows for precise cursor control and multi-touch gestures, similar to a laptop trackpad.
- **Detachable Design:** The keyboard is magnetically attached to the case, allowing for easy detachment when only the tablet

and case are needed.

- **Sleep Mode:** The keyboard automatically enters sleep mode after 15 minutes of inactivity to conserve battery. Press any key to reactivate it.
- **Bluetooth Disconnection:** Bluetooth pairing will automatically interrupt when the tablet enters sleep mode. Reconnect manually if needed after waking the tablet.

5.2. Pencil Holder

The case features a built-in holder at the bottom to securely store your stylus (e.g., Apple Pencil, though not included). This prevents loss and ensures your stylus is always accessible.

Built-in Apple Pencil holder

Pencil Holder on the bottom can prevent the apple pen from being lost. Grab your Apple Pencil effortlessly whenever you want, easily to carry your Apple pencil with your device.



Figure 6: Location of the integrated pencil holder.

6. MAINTENANCE AND BATTERY LIFE

6.1. Charging

- The keyboard features a built-in Li-ion battery. A full charge takes approximately 2-3 hours.

- The keyboard can standby for up to 30 days and operate for at least 80 hours on a single charge.

Long standby time

Built-in premium Li-ion battery



with energy-saving mode
2-3 hours full charge



Standby up to 30 days
work for at least 80 hours



Figure 7: Battery performance details for the keyboard.

6.2. Cleaning and Care

- Wipe the case and keyboard with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- The case is made of soft TPU material with a non-slip design, offering protection and multiple viewing angles.

Soft smooth TPU material

The soft TPU back cover adopts non-slip design, Easy to install, Can support the tablet at multiple angles .



Figure 8: Close-up of the soft TPU material of the case.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not connecting via Bluetooth.	Keyboard not in pairing mode; low battery; tablet Bluetooth off; incorrect system selected.	<ul style="list-style-type: none">• Ensure keyboard is fully charged.• Press Fn + C to enter pairing mode.• Verify Bluetooth is enabled on your tablet.• Ensure Fn + Q has been pressed to select Android system.• Forget the device on your tablet and try pairing again.

Problem	Possible Cause	Solution
Keyboard not responding after inactivity.	Keyboard is in sleep mode.	Press any key to wake the keyboard.
Mouse not connecting.	Low battery; incorrect connection type (Bluetooth/2.4G); receiver not plugged in (for 2.4G).	<ul style="list-style-type: none"> • Check mouse battery. • Ensure correct connection method is being used (Bluetooth pairing or 2.4G receiver). • For 2.4G, ensure the USB receiver is securely plugged into the tablet.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Product Name	Touch Keyboard Case with Mouse
Model Number	SM-X620 / X626B (for compatible tablet)
Brand	Generic
Compatible Devices	Samsung Galaxy Tab S10 FE+ Plus 13.1 inch 2025 (Model: SM-X620 / X626B)
Connectivity Technology	Bluetooth (Keyboard & Mouse), 2.4G Wireless (Mouse)
Keyboard Features	Detachable, Touchpad, Backlit, Round Keys
Mouse Features	Bluetooth + 2.4G Dual Mode
Battery Type	Built-in Li-ion (Keyboard), 1 A battery (Mouse - included)
Charging Time (Keyboard)	2-3 hours
Standby Time (Keyboard)	Up to 30 days
Working Time (Keyboard)	At least 80 hours
Case Material	Soft TPU
Item Weight	1.6 ounces (approx. 45 grams)
Country of Origin	China

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact the seller directly through your purchase platform. Refer to your order details for seller contact information.

Manufacturer: Wuzhuangtai

Related Documents - SM-X620 / X626B

<p>SAMSUNG</p> <p>MANUAL DO USUÁRIO</p>  <p>SM-X820 SM-X920 SM-X520 SM-X620 SM-X920 SM-X526B SM-X626B SM-X400</p> <p>Modelo SM-X620 (S10)</p>	<p>Manual do Usuário Samsung Galaxy Tab S10 FE+ (Modelos Seleccionados)</p> <p>Explore o Manual do Usuário Samsung Galaxy Tab S10 FE+ para modelos seleccionados (SM-X820, SM-X920, SM-X520, SM-X526B, SM-X620, SM-X626B, SM-X400, SM-X406, SM-X406B). Descubra como configurar, usar e gerenciar todas as funções do seu dispositivo Samsung.</p>
<p>SAMSUNG</p> <p>KÄYTTÖOPAS</p>  <p>SM-X820 SM-X920 SM-X520 SM-X620 SM-X920 SM-X526B SM-X626B SM-X400</p> <p>Modelo SM-X620 (S10)</p>	<p>Samsung Galaxy Tab S10 Käyttöopas</p> <p>Tämä kattava käyttöopas tarjoaa yksityiskohtaiset ohjeet Samsung Galaxy Tab S10 -tablettien käyttöön, ominaisuuksiin ja asetuksiin. Opi hyödyntämään laitteesi täysi potentiaali.</p>
<p>SAMSUNG</p> <p>دليل المستخدم</p>  <p>SM-X820 SM-X920 SM-X520 SM-X620 SM-X920 SM-X526B SM-X626B SM-X400</p> <p>Modelo SM-X620 (S10)</p>	<p>دليل المستخدم Samsung Galaxy Tab S10 Series</p> <p>يغطي الإعداد الأولي، الميزات، الإعدادات، دليل شامل لجهاز التطبيقات، احتياطات السلامة، واستكشاف الأخطاء وإصلاحها.</p>
<p>SAMSUNG</p> <p>FELHASZNÁLÓI KÉZIKÖNYV</p>  <p>SM-X820 SM-X920 SM-X520 SM-X620 SM-X920 SM-X526B SM-X626B SM-X400</p> <p>Modelo SM-X620 (S10)</p>	<p>Samsung Galaxy Tab S10 Sorozat Felhasználói Kézikönyv</p> <p>Ez a felhasználói kézikönyv részletes útmutatást nyújt a Samsung Galaxy Tab S10 sorozatú táblagépek funkcióinak és használatának megismeréséhez, beleértve a kezdeti lépéseket, az alkalmazásokat és a beállításokat.</p>
<p>SAMSUNG</p> <p>ΟΔΗΓΟΣ ΧΡΗΣΤΗ</p>  <p>SM-X820 SM-X920 SM-X520 SM-X620 SM-X920 SM-X526B SM-X626B SM-X400</p> <p>Modelo SM-X620 (S10)</p>	<p>Οδηγός Χρήστη Samsung Galaxy Tab S10</p> <p>Ανακαλύψτε πώς να χρησιμοποιήσετε πλήρως τη συσκευή σας Samsung Galaxy Tab S10 με αυτόν τον αναλυτικό οδηγό χρήστη. Καλύπτει όλες τις λειτουργίες, από τις βασικές ρυθμίσεις έως προηγμένες εφαρμογές και ρυθμίσεις συστήματος.</p>

