

SoulBay LC004RS_6pcs

SoulBay Rechargeable Tea Lights Candles User Manual

Model: LC004RS_6pcs

INTRODUCTION

Thank you for choosing SoulBay Rechargeable Tea Lights Candles. This manual provides essential information for the safe and efficient operation of your flameless LED candles. These tea lights offer a realistic flickering effect, remote control functionality, and a convenient charging base, making them a versatile and safe lighting solution for various indoor settings.

WHAT'S IN THE BOX

- 6 x LED Tea Lights
- 1 x Charging Base
- 1 x Remote Control
- 1 x USB-C Charging Cable (2.6FT)

SETUP

Charging the Tea Lights

1. Connect the provided USB-C charging cable to the charging base and a suitable USB power adapter (not included).
2. Place each tea light into an empty slot on the charging base. Ensure the charging contacts on the bottom of the tea light align with the pins in the base.
3. A charging indicator light on the base will illuminate to confirm charging.
4. Allow approximately 1.5 to 2 hours for a full charge. A full charge provides 42-50 hours of illumination, depending on brightness and mode settings.



Image: Tea lights placed on the charging base, connected via USB-C cable.

Initial Use

Before first use, ensure all tea lights are fully charged. Each tea light has a small power switch on its bottom. Turn this switch to the 'ON' position for the remote control to function.



Image: A close-up of a single tea light, highlighting its realistic wick and the charging port on its base.

OPERATING INSTRUCTIONS

Your SoulBay Tea Lights are operated using the included remote control. Ensure the tea lights' bottom switches are in the 'ON' position for remote functionality.

Remote Control Functions

Button	Function
ON/OFF	Turns all connected tea lights on or off.
Luminosity (+/-)	Adjusts the brightness level (5 levels available).

Button	Function
Mode (SL/FL/Light)	Cycles through lighting modes: - SL: Slow Flicker - FL: Fast Flicker - Light: Solid (non-flickering) illumination
Timer (2H/4H/6H/8H)	Sets an automatic timer for the tea lights to stay on for 2, 4, 6, or 8 hours. The lights will turn off after the set duration and automatically turn on at the same time the next day.



5 Brightness Levels

Decrease or increase brightness

4 Lightning Modes

SL - Slow Flicker FL - Fast Flicker

4 Timer Modes

2,4,6,8 Cycle Timer

Image: The remote control with clearly labeled buttons for various functions.

Video: Demonstration of the tea lights being turned on and off, and their flickering effect, using the remote control.

Video: A user demonstrates the various modes and timer settings of the tea lights using the remote control.

Cleaning

To clean the tea lights and charging base, wipe them with a soft, dry cloth. Do not use abrasive cleaners or immerse them in water, as they are not waterproof.

Battery Life & Recharging

The tea lights are equipped with 200mAh rechargeable batteries. A single 1.5-2 hour charge can provide 42-50 hours of light. For optimal battery longevity, avoid fully depleting the battery frequently. Recharge when the light output diminishes.

Storage

Store the tea lights and charging base in a cool, dry place when not in use. If storing for an extended period, ensure the tea lights are fully charged before storage and recharge them every few months to maintain battery health.

TROUBLESHOOTING

- **Tea Lights Not Turning On:** Ensure the small switch on the bottom of each tea light is in the 'ON' position. Verify the tea lights are charged.
- **Remote Control Not Working:** Check if the tea lights' bottom switches are 'ON'. Ensure there are no obstructions between the remote and the tea lights. Replace the remote's battery if necessary.
- **Charging Issues:** Confirm the USB-C cable is securely connected to both the charging base and the power source. Ensure each tea light is properly seated in its slot on the charging base, with contacts aligned.
- **Difficulty Removing Tea Lights from Base:** Some users have reported a tight fit when removing tea lights from the charging base. Gently twist and pull, or use a small, non-abrasive tool if necessary, taking care not to damage the unit.

SAFETY INFORMATION

These flameless LED tea lights are designed for safety. They eliminate the risks associated with traditional candles, such as open flames, smoke, and fire hazards. They are safe for use around children, pets, curtains, and tablecloths. For indoor use only.

SPECIFICATIONS

Feature	Detail
Brand	SoulBay
Model Name	Rechargeable Tea Lights
Model Number	LC004RS_6pcs
Light Source Type	LED
Color	White
Material	Acrylonitrile Butadiene Styrene
Product Dimensions	1.5"D x 1.5"W x 2.28"H (each tea light)
Item Weight	1.06 ounces (each tea light)

Feature	Detail
Power Source	USB
Battery Life	Up to 50 Hours
Control Method	Remote
Special Features	Dimmable, Energy Efficient, Flameless, Rechargeable, Timer
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant

WARRANTY AND SUPPORT

For product support or warranty inquiries, please contact SoulBay customer service. Refer to the product packaging or the official SoulBay website for contact information.

© 2025 SoulBay. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question