

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HOGOKIDS](#) /

› [HOGOKIDS 2025 Advent Calendar Gingerbread House Mini Building Set with Light Instruction Manual](#)

HOGOKIDS HG1068

HOGOKIDS 2025 Advent Calendar Gingerbread House Mini Building Set with Light Instruction Manual

Model: HG1068

1. PRODUCT OVERVIEW

The HOGOKIDS 2025 Advent Calendar Gingerbread House Mini Building Set (Model HG1068) offers a unique building experience with 1452 mini 3.6mm bricks. This set allows for the construction of a festive gingerbread house featuring three distinct display styles and integrated warm LED lighting. Designed for ages 10 and up, it provides an engaging activity for the holiday season.



Image 1.1: Completed HOGOKIDS Gingerbread House with festive decorations and lights.

Key Features:

- **24-Day Advent Calendar:** Individual daily building challenges from December 1st to 24th.
- **Three Display Styles:** The gingerbread house can be configured into three different arrangements without complete disassembly.
- **Mini Building Blocks:** Composed of 1452 high-quality 3.6mm mini bricks.
- **Integrated LED Lighting:** Features a built-in warm lighting kit to illuminate the completed structure.
- **Detailed Design:** Includes elements like a snow-covered roof, candy accents, gingerbread men, and Christmas trees.

AI

3 transform styles (no need to take all apart)



Image 1.2: The HOGOKIDS Gingerbread House can be arranged in three distinct styles.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts.

This product contains small parts and is not suitable for children under 3 years of age. Adult supervision is recommended during assembly and play, especially for younger children within the recommended age range.

This product contains a button battery for the LED lighting. If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours. Keep batteries out of reach of children. If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.



3. SETUP AND ASSEMBLY

The HOGOKIDS Gingerbread House is designed as a 24-day Advent Calendar building experience. Each day from December 1st to 24th, you will open a designated window on the calendar box to reveal a surprise bag of building blocks.

Assembly Steps:

1. **Unpack the Calendar:** Place the Advent Calendar box in a suitable building area.
2. **Daily Unveiling:** Starting December 1st, locate and open the window corresponding to the current day.
3. **Retrieve Building Blocks:** Remove the sealed bag of building blocks from the opened window.
4. **Follow Instructions:** Refer to the clear, easy-to-follow instructions provided with the set for assembling the day's components. Each day's bag contains the necessary pieces for that specific part of the build.
5. **Connect Sections:** As you progress through the days, connect the newly built sections to form the complete gingerbread house structure.
6. **Complete the House:** By December 24th, all sections will be assembled, completing your gingerbread house.



Image 3.1: Visual guide for the 24-day countdown building process.

Video Guide:

For a visual demonstration of the Advent Calendar unboxing and assembly process, please refer to the video below.

Your browser does not support the video tag.

Video 3.1: Demonstration of the HOGOKIDS Gingerbread House Advent Calendar unboxing and assembly.

4. OPERATING INSTRUCTIONS (LED LIGHTING)

The HOGOKIDS Gingerbread House features integrated warm LED lighting to enhance its festive appearance. The lighting system is typically powered by a button battery (refer to safety information for battery type and handling).

Activating the Lights:

1. Ensure the battery is correctly installed in the designated compartment as per the assembly instructions.
2. Locate the power switch for the LED lights, usually a small button or switch integrated into the base or a specific section of the house.

3. Press or toggle the switch to turn the lights ON.
4. Press or toggle the switch again to turn the lights OFF.



Image 4.1: Gingerbread House with LED lights off.



Image 4.2: Gingerbread House with warm LED lights illuminated.

5. MAINTENANCE

To ensure the longevity and appearance of your HOGOKIDS Gingerbread House, follow these maintenance guidelines:

- **Cleaning:** Dust the model regularly with a soft, dry cloth or a soft brush. Avoid using water or chemical cleaners, as these can damage the plastic bricks or electronic components.
- **Storage:** When not on display, store the assembled model or disassembled bricks in a cool, dry place away from direct sunlight and extreme temperatures. Keep them in a sealed container to prevent dust accumulation and loss of small parts.
- **Battery Replacement:** If the LED lights dim or stop working, replace the button battery with a new one of the same type. Ensure correct polarity during installation. Dispose of used batteries responsibly.
- **Handling:** Handle the assembled model with care to prevent accidental disassembly or damage to

delicate parts.

6. TROUBLESHOOTING

If you encounter any issues with your HOGOKIDS Gingerbread House, consider the following troubleshooting steps:

Missing Pieces:

- Carefully check all packaging materials, including the Advent Calendar windows and plastic bags, to ensure no small pieces were overlooked.
- If pieces are still missing, contact HOGOKIDS customer support (see Section 8).

LED Lights Not Working:

- **Check Battery Installation:** Ensure the button battery is inserted correctly with the proper polarity.
- **Replace Battery:** The battery may be depleted. Replace it with a new one.
- **Inspect Connections:** Verify that all wiring for the LED lights is securely connected as per the assembly instructions.
- **Power Switch:** Ensure the power switch is in the 'ON' position.

Difficulty Assembling:

- **Review Instructions:** Double-check the instruction manual for the specific step you are on. Pay close attention to the orientation and placement of bricks.
- **Small Parts:** Remember this set uses 3.6mm mini bricks, which require precise placement.
- **Seek Assistance:** If you are still struggling, consider asking another person for assistance or referring to online building guides or videos.

7. SPECIFICATIONS


| Specification | Detail |
|--------------------|--|
| Product Name | HOGOKIDS 2025 Advent Calendar Gingerbread House Mini Building Set with Light |
| Model Number | HG1068 |
| Brand | HOGOKIDS |
| Number of Pieces | 1452 mini 3.6mm bricks |
| Recommended Age | 10 years and up |
| Product Dimensions | Approximately 2 x 2 x 2 inches (assembled) |
| Item Weight | 2 pounds |
| Material | Plastic |
| Lighting | Integrated LED (button battery powered) |
| Manufacturer | HOGOKIDS (Shenzhen C-tronics Co., Ltd) |



Image 7.1: Product dimensions and component sizes.



Contrast Block



Normal Block




Image 7.2: Comparison of block sizes (3.6mm mini blocks vs. standard blocks).

8. WARRANTY AND SUPPORT

HOGOKIDS is committed to providing high-quality products. For any questions, concerns, or issues regarding missing parts or product defects, please contact our customer support team.

Contact Information:

- Email: info@hogokidstoys.com
- Website: www.hogokidstoys.com

Please have your product model number (HG1068) and purchase details ready when contacting support.