

DUMOS PP10ABK

DUMOS Countertop Ice Maker

USER MANUAL

Introduction

Thank you for choosing the DUMOS Countertop Ice Maker. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your new ice maker. Please read this manual thoroughly before using the appliance and retain it for future reference. Proper use and care will ensure efficient performance and extend the lifespan of your ice maker.

Safety Instructions

To reduce the risk of fire, electric shock, or injury when using your ice maker, follow these basic precautions:

- Read all instructions before use.
- Do not touch the evaporator or ice cubes when the ice maker is operating to avoid frostbite.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the ice maker from the power outlet when not in use, before cleaning, or before performing any maintenance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Ensure the ice maker is placed on a stable, level surface to prevent tipping.
- Do not block any ventilation openings. Ensure adequate air circulation around the unit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

- Do not use water other than potable water in the ice maker.

Product Overview

The DUMOS Countertop Ice Maker is designed for convenience and efficiency, producing bullet-shaped ice cubes quickly. Below are the main components and key features of your ice maker.

Components

- Ice Maker Unit
- Ice Basket
- Ice Scoop

Key Features

- **Fast Ice Making:** Produces 9 bullet-shaped ice cubes in as little as 6 minutes.
- **High Daily Capacity:** Up to 26.5 pounds of ice in 24 hours.
- **Two Ice Cube Sizes:** Choose between small and large bullet ice cubes.
- **Self-Cleaning Function:** Automated cleaning for easy maintenance.
- **Portable Design:** Compact size (8.8"D x 11.6"W x 12.5"H) and convenient carry handle.
- **Quiet Operation:** Noise level below 40dB, similar to a working refrigerator.
- **Smart Indicators:** Lights for "Water Insufficient" and "Ice Basket Full".
- **Transparent Window:** Allows you to monitor ice production.



Figure 1: DUMOS Countertop Ice Maker with ice basket and scoop. This image displays the overall design of the ice maker, including its integrated handle and the removable ice basket. A glass with a drink and ice is also visible, demonstrating its use.



Figure 2: Illustration of the ice maker's low noise operation. This graphic compares the ice maker's sound level (40dB) to other common sounds like whispering (30dB) and normal chat (42dB), highlighting its quiet performance.

Setup

1. **Unpack the Ice Maker:** Carefully remove all packaging materials. Check for any damage during transit.
2. **Initial Cleaning:** Before first use, clean the interior of the ice maker, including the water tank and ice basket, with a soft cloth and mild detergent. Rinse thoroughly with clean water.
3. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure there is at least 4 inches (10 cm) of space around the unit for proper ventilation.
4. **Add Water:** Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
5. **Connect Power:** Plug the power cord into a grounded electrical outlet (115 Volts).

PRODUCT DIMENSION

LIGHTWEIGHT & COMPACT



Figure 3: Visual guide for adding water and initiating self-cleaning. This image illustrates the first step of adding water to the reservoir, which is crucial for initial setup and operation.

Operating Instructions

1. **Power On:** Press the ON/OFF button to turn on the ice maker. The indicator light will illuminate.
2. **Select Ice Size:** If your model supports it, press the "SELECT" button (or similar) to choose between small or large ice cube sizes. The corresponding indicator light will show your selection.
3. **Ice Production:** The ice maker will begin the ice-making cycle. The first batch of ice typically takes 6-8 minutes. Subsequent cycles may be faster.
4. **Ice Full Indicator:** When the ice basket is full, the "ICE FULL" indicator light will turn on, and the ice maker will automatically pause production. Remove ice from the basket to resume operation.
5. **Add Water Indicator:** If the water level in the reservoir is too low, the "ADD WATER" indicator light will turn on, and the ice maker will stop. Add more potable water to the reservoir to continue.
6. **Power Off:** Press the ON/OFF button again to turn off the ice maker.

Maintenance and Cleaning

Regular cleaning and maintenance are essential to ensure the longevity and hygienic operation of your DUMOS ice maker.

Self-Cleaning Function

The ice maker features a convenient self-cleaning function:

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the ON/OFF button for 5 seconds to activate the self-cleaning mode.
3. The cleaning cycle will run for approximately 15 minutes.
4. Once the cycle is complete, drain the water from the reservoir by removing the drain plug (usually located at the bottom or side of the unit).
5. Rinse the interior with fresh water and drain again.

PRODUCT DIMENSION

LIGHTWEIGHT & COMPACT



Figure 4: Illustration of the self-cleaning process. This image shows the internal water circulation during the self-cleaning cycle, which is activated by holding the power button for 5 seconds.

Regular Cleaning

- Always unplug the ice maker before cleaning.
- Remove the ice basket and wash it with warm, soapy water. Rinse and dry thoroughly.
- Wipe the exterior of the unit with a soft, damp cloth.
- For the interior, use a diluted solution of vinegar and water or a mild descaling agent to clean the water tank and ice-making components. Rinse thoroughly with clean water multiple times to remove any residue.
- Ensure all parts are completely dry before reassembling and storing the unit.

Troubleshooting

If you encounter issues with your DUMOS ice maker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Ice maker not working.	No power; "ADD WATER" light on.	Check power connection; Add water to the reservoir.
Ice cubes are too small or not forming.	Insufficient water; Water temperature too high; Ambient temperature too high.	Add water; Use colder water; Place ice maker in a cooler environment.
"ICE FULL" light is on, but basket is not full.	Ice sensor is dirty or blocked.	Clean the ice sensor (usually small infrared sensors near the ice basket).
Unusual noise during operation.	Unit not level; Internal components vibrating.	Ensure the unit is on a flat, stable surface; This may be normal during initial cycles.
Ice has an odd taste or smell.	Unit needs cleaning; Stale water.	Perform self-cleaning and thorough manual cleaning; Use fresh potable water.

Specifications

Technical specifications for the DUMOS Countertop Ice Maker:

Feature	Detail
Brand	DUMOS
Model Name	DUMOS Countertop Ice Maker
Model Number	PP10ABK
Product Dimensions (D x W x H)	11.5" x 8.9" x 12.4"
Capacity (Water Tank)	1.5 Liters
Daily Ice Output	Up to 26.5 lbs / 24 hours
Ice Cube Shape	Bullet
Ice Cube Sizes	Small, Large
Voltage	115 Volts
Refrigerant	R600a
Material	Alloy Steel, Plastic
Item Weight	17.96 pounds

LOW NOISE

HIGH-EFFICIENCY CONDENSING SYSTEM



Figure 5: Product dimensions of the DUMOS Countertop Ice Maker. This image provides a visual representation of the ice maker's height, width, and depth, indicating its compact size suitable for countertops.

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact DUMOS customer service. Keep your purchase receipt as proof of purchase for any warranty claims.

You can also find additional support and frequently asked questions on the official DUMOS website or through your retailer's support channels.

For a digital copy of the user manual, please visit: [DUMOS Countertop Ice Maker User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question