

[Manuals.plus](#) /

› [FEZIBO](#) /

› FEZIBO 55x24 Electric Standing Desk User Manual

FEZIBO 55x24 Rustic Brown

FEZIBO 55x24 Electric Standing Desk User Manual

Model: 55x24 Rustic Brown

1. INTRODUCTION

Thank you for choosing the FEZIBO Electric Standing Desk. This desk is designed to promote a healthier lifestyle by allowing seamless transitions between sitting and standing positions throughout your workday. Its electric height adjustable lifting system provides a quiet and stable operation, making it an ideal addition to any home or office environment. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your desk.



Image 1.1: The FEZIBO 55x24 Electric Standing Desk in a typical office setup.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Keep children and pets away from the desk during operation.
- Ensure no obstacles are in the desk's path during height adjustment.
- Do not overload the desk. Refer to the specifications for maximum weight capacity.
- Keep all electrical components dry and away from liquids.
- Only use the provided power adapter and cables.
- If the desk makes unusual noises or movements, discontinue use and contact support.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact FEZIBO customer support.

- Desktop (Splice Board, 2 pieces)
- Desk Frame (Legs, Crossbar, Feet)
- Electric Motor
- Control Panel with Memory Presets
- Power Adapter and Cable
- Desk Hooks (x2)
- Assembly Tools (Allen wrench, screws, etc.)
- User Manual



Always Keep Stable

Sturdy frame with lifting column connectors

Image 3.1: All components neatly packaged for assembly.

4. SETUP AND ASSEMBLY

Assembly of the FEZIBO Electric Standing Desk is straightforward. A detailed installation video is available for visual guidance. You will need a Phillips head screwdriver in addition to the included Allen wrench.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Check

against the package contents list.

2. **Assemble Desktop:** The desktop comes in two pieces. Align the two desktop pieces and secure them using the provided dowels and screws. The pre-drilled holes ensure a precise and smooth joint.
3. **Attach Legs to Crossbar:** Connect the two leg columns to the central crossbar using the designated screws. Ensure all connections are firm.
4. **Mount Frame to Desktop:** Carefully place the assembled frame onto the underside of the desktop. Align the pre-drilled holes on the desktop with the frame and secure using the provided screws.
5. **Install Motor and Control Panel:** Attach the electric motor and control panel to the underside of the desk. The pre-drilled holes allow for flexible placement, typically on the right or left side. Ensure the motor and control panel are on the same side due to cable length.
6. **Connect Cables:** Plug the motor cable into the control panel and the power cable into the control panel. Route cables neatly using the included cable management accessories.
7. **Attach Desk Hooks:** Secure the two desk hooks to the pre-drilled holes on either end of the desk. These are useful for hanging headphones or bags.
8. **Adjust Leveling Feet:** Once the desk is upright, adjust the leveling feet at the bottom of the legs to ensure the desk is stable and level on any surface.

x2

Desk Hooks

Hook your head phones and bags



Frame Base

Enhance the stability of the desk



Image 4.1: Detail of desk hooks and frame base for enhanced stability.

5. OPERATING INSTRUCTIONS

The FEZIBO Electric Standing Desk features an intuitive control panel for easy height adjustment and memory functions.

5.1. Height Adjustment

- **Up/Down Buttons:** Use the **^** (Up) and **v** (Down) buttons to manually adjust the desk height. The desk operates

smoothly and quietly, with noise levels under 50 dB.

- The desk can be adjusted between 27.3 inches (minimum) and 45.5 inches (maximum).

5.2. Memory Presets

The desk features 3 programmable memory height buttons to save your preferred sitting and standing positions.


1. **Set a Memory Position:** Adjust the desk to your desired height using the Up/Down buttons.
2. Press the **M** button (if available, or follow specific model instructions for setting memory).
3. Immediately press one of the numbered memory buttons (**1**, **2**, or **3**) until you hear a beep or see a confirmation on the display. The height is now saved.
4. **Recall a Memory Position:** Simply press the corresponding numbered memory button (**1**, **2**, or **3**) to automatically move the desk to the saved height.

5.3. Anti-Collision Technology

The desk is equipped with an anti-collision system for safety. If the desk encounters an obstacle during lifting or lowering, it will automatically stop and reverse approximately 2 cm to prevent damage or injury.

Setting Adjustment

Set and adjust custom height with ease



Reset: Press and hold the "UP" and "DOWN" button simultaneously for 5 seconds.

Image 5.1: Control panel for setting and adjusting custom heights.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your FEZIBO Standing Desk.

- **Cleaning:** Wipe the desktop surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the laminated finish.

- **Frame Care:** Clean the metal frame with a dry or slightly damp cloth.
- **Cable Management:** Periodically check that all cables are securely connected and neatly organized to prevent tangling or damage.
- **Motor Inspection:** Ensure the motor and lifting mechanisms are free from dust and debris. Do not attempt to lubricate or disassemble the motor.
- **Stability Check:** Routinely check that all screws and bolts are tight. Re-tighten if necessary to maintain desk stability.

7. TROUBLESHOOTING

If you encounter any issues with your FEZIBO Electric Standing Desk, please refer to the following common solutions before contacting support.

Problem	Possible Cause	Solution
Desk does not move	Power cable disconnected; Control panel not reset; Overload.	Check power connections. Perform a reset (press and hold UP and DOWN buttons for 5 seconds). Reduce weight on desk.
Desk moves unevenly or makes unusual noise	Loose connections; Obstruction; Uneven weight distribution.	Check all screws and bolts for tightness. Remove any obstructions. Distribute weight evenly on the desktop.
Anti-collision system is too sensitive	Sensitivity setting (if adjustable); Minor vibrations.	Refer to the control panel instructions for sensitivity adjustment (if available). Ensure stable environment.
Memory presets not working	Incorrect saving procedure.	Ensure you press the 'M' button (or equivalent) immediately followed by the numbered preset button to save.

8. SPECIFICATIONS

Feature	Detail
Brand	FEZIBO
Model	55x24 Rustic Brown
Product Dimensions (D x W x H)	24"D x 55"W x 27"H
Adjustable Height Range	27.3" to 45.5"
Color	Rustic Brown (Top), Black (Frame)
Style	Modern
Base Material	Alloy Steel
Top Material Type	Wood (Laminated)
Noise Level	Under 50 dB
Memory Presets	3 Programmable Buttons

Feature	Detail
Anti-Collision	Yes
Assembly Required	Yes (Includes all assembly tools)
Recommended Uses	Office, Computer Desk



9. WARRANTY & SUPPORT

Your FEZIBO Electric Standing Desk comes with a limited warranty. For specific warranty terms and conditions, please refer to the documentation included in your product packaging or contact FEZIBO customer support.

If you have any questions, concerns, or require technical assistance during assembly or use, please do not hesitate to contact our dedicated support team. We are committed to providing excellent customer service.

FEZIBO Customer Support:

Website: www.fezibo.com

Email: support@fezibo.com

Phone: (Please refer to website for current phone number)