

# **UWANT V500 Cordless Vacuum Cleaner Instruction Manual**

Model: V500 | Brand: UWANT

## **1. PRODUCT OVERVIEW**

The UWANT V500 Cordless Vacuum Cleaner is designed for efficient home cleaning, offering advanced features for various surfaces. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.

Key features include a self-emptying base, a 7-layer HEPA filtration system, and an anti-tangle brush suitable for pet hair and different floor types.

## **2. PACKAGE CONTENTS**

Please verify that all components listed below are included in your package:



Figure 2.1: Illustration of all items included in the UWANT V500 package.

- Base Station x 1
- Vacuum Cleaner x 1
- Metal Tube x 1
- Narrow Crevice Tool x 1
- 2-in-1 Brush Tool x 1

- Floor Brush x 1
- Battery x 1
- Adapter x 1
- Dust Bag x 2 (1 pre-installed, 1 spare)

### 3. SETUP GUIDE

#### 3.1 Assembly

1. Insert the metal tube into the main vacuum cleaner body until it clicks securely.
2. Attach the floor brush to the bottom end of the metal tube, ensuring it clicks into place.
3. Install the battery into the designated slot on the main vacuum cleaner body.
4. Assemble the Base Station by connecting its components as shown in the package contents diagram.

#### 3.2 Charging the Battery

Before first use, fully charge the vacuum cleaner battery. The vacuum automatically charges when docked in the Base Station.



Figure 3.1: The vacuum cleaner charging while docked in the Base Station.

- Place the assembled vacuum cleaner onto the Base Station.
- Connect the adapter to the Base Station and plug it into a power outlet.
- The battery indicator on the vacuum will show charging status. A full charge takes approximately 3 hours.

## 4. OPERATING INSTRUCTIONS

### 4.1 Power On/Off and Suction Modes

To power on the vacuum, press the power button located on the handle. The vacuum offers three suction modes: Eco, Standard, and Boost.



Figure 4.1: Vacuum display indicating battery level and selectable cleaning modes.

- **Eco Mode:** For light cleaning and extended battery life (up to 60 minutes).
- **Standard Mode:** For everyday cleaning tasks.
- **Boost Mode:** Provides maximum suction for stubborn dirt and deep cleaning.
- Press the mode selection button to cycle through the available suction modes.

### 4.2 Green Light Dust Detection

The integrated green light on the floor brush illuminates the cleaning path, making tiny dust particles and

pet hair visible for more effective cleaning.



Figure 4.2: Green light dust detection in action, revealing hidden debris.

### 4.3 Using Attachments

The vacuum can be converted into a handheld unit by detaching the metal tube and attaching the desired accessory directly to the main body. This is ideal for cleaning upholstery, car interiors, or hard-to-reach areas.

The UWANT logo, featuring the word "UWANT" in a bold, orange, sans-serif font.

The Clean UWANT is in the Details.

uwant cordless vacuum cleaner products through our technological innovation and meticulous design, can provide outstanding deep cleaning effects, achieving a dual upgrade in performance and experience. This series of products can clean to the details of the space, making cleaning itself a pleasant and effortless activity. We are not just a brand that can create comfortable and healthy spaces for you, but also your partner in a clean life.

Figure 4.3: Using the narrow crevice tool for detailed cleaning.

## 5. MAINTENANCE

### 5.1 Auto-Empty and Dust Bag Replacement

The UWANT V500 features an auto-empty system that transfers collected debris from the vacuum's dust cup into a sealed 1.8L dust bag within the Base Station. This process occurs automatically when the vacuum is docked.

## Experience the Power of Self-Emptying

Up to 60 days hands-free;  
Keeps cleaning simple & dust-free.



Figure 5.1: The auto-empty system transferring dust from the vacuum to the Base Station's dust bag.

- When the dust bag in the Base Station is full, replace it with a new one. Two dust bags are included in the package.
- To access the dust bag compartment, open the front panel of the Base Station.
- Carefully remove the full dust bag and dispose of it. Insert a new dust bag, ensuring it is properly seated.

### 5.2 Filter Cleaning and Replacement

The vacuum utilizes a 7-layer HEPA filtration system to trap 99.98% of dust and allergens. Regular cleaning of the filters is essential for maintaining suction power and air quality.

## Extended Runtime & Rapid Charging

Enjoy uninterrupted performance with a battery that lasts longer and recharges quickly

Runtime (Normal Mode):

**≈ 60 minutes**

Battery Capacity:

**7×2,500 mAh**

Charging Time:

**3 hours**



Figure 5.2: Exploded view of the 7-stage HEPA filtration system.

- Refer to the detailed instructions in the user manual for specific filter removal and cleaning procedures.
- Filters should be cleaned regularly (e.g., monthly) and replaced periodically (e.g., every 6-12 months, depending on usage) to ensure optimal performance.

## 6. TROUBLESHOOTING

If you encounter any issues with your UWANT V500, please refer to the following common troubleshooting steps:

- **No Power:** Ensure the battery is fully charged and correctly installed. Check if the Base Station is properly connected to a power outlet.
- **Reduced Suction:** Check if the dust cup or dust bag is full and needs emptying/replacement. Inspect filters for clogs and clean or replace them as necessary. Ensure there are no blockages in the floor brush or metal tube.
- **Unusual Noise:** Turn off the vacuum and check the floor brush for any tangled hair or debris. Remove any obstructions.
- For more detailed troubleshooting, consult the comprehensive user manual.

## 7. SPECIFICATIONS

| Feature                       | Detail   |
|-------------------------------|--|
| Brand                         | uwant  |
| Model Name                    | V500   |
| Color                         | Gray   |
| Special Feature               | Cordless, Auto Empty, 7-Layer HEPA Filtration, Anti-Tangle Brush |
| Battery Life                  | Up to 60 minutes (Eco Mode)                                      |
| Charging Time                 | Approximately 3 hours  |
| Vacuum Collection Technology  | Bagged with Brush Roll   |
| Dust Bag Capacity             | 1.8L (Base Station)  |
| Product Dimensions            | 10.8 x 11.3 x 43.3 inches  |
| Item Weight                   | 7.7 pounds   |
| Voltage                       | 25.2 Volts   |
| Number of Speeds/Power Levels | 3  |

## 8. WARRANTY AND SUPPORT

The UWANT V500 Cordless Vacuum Cleaner comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact UWANT customer service through their official website or the contact information provided in your user manual.