

[manuals.plus](#) /› [MYPIN](#) /› [MYPIN HA0362 Advertising Media Player Instruction Manual](#)**MYPIN HA0362**

MYPIN HA0362 Advertising Media Player Instruction Manual

Model: HA0362

1. INTRODUCTION

The MYPIN HA0362 Advertising Media Player is designed to transform any HD TV into a dynamic digital signage display. This device supports playing videos, music, and photo slideshows from USB drives or Micro SD cards, offering features like automatic playback, looping, and screen mirroring from various devices. It is suitable for diverse environments including retail, restaurants, conference rooms, and home entertainment.

2. WHAT'S IN THE Box

- Multimedia Player (HA0362) x1
- Remote Control x1
- Power Supply x1
- HDMI Cable x1
- AV Cable x1

Transferring Advertising Photos and Videos from Smartphones to TV, Makes Switching Ads More Convenient




Image: Contents of the MYPIN HA0362 package, including the media player, remote control, power supply, HDMI cable, and AV cable.

3. SETUP

3.1 Connecting the Device

1. Connect one end of the HDMI cable to the HDMI port on your TV or monitor.
2. Connect the other end of the HDMI cable to the HDMI port on the MYPIN HA0362 Media Player.
3. Connect the DC end of the power cable to the media player and the adapter end to a power socket.
4. Power on your TV and select the correct HDMI input source.

Multimedia Playback Function



Supports Automatic&Loop Play
Video/Music/Picture from
USB Driver(Up to 512G)



Image: A close-up view of the MYPIN HA0362 Media Player with HDMI and power cables connected, ready for use with a display.

3.2 Network Connection

For features requiring internet access, connect the device to your Wi-Fi network:

1. Using the remote control, navigate to 'Settings' on the device's home screen.
2. Select 'Wi-Fi' and choose your network from the available options.
3. Enter your Wi-Fi password to connect.

Alternatively, an Ethernet cable can be used for a wired internet connection if Wi-Fi is unavailable.

3.3 Setup Video Guide

Your browser does not support the video tag.

Video: A step-by-step guide demonstrating the physical installation and connection of the MYPIN HA0362 Media Player to a display and network setup.

4. OPERATING INSTRUCTIONS

4.1 Media Playback (USB/SD Card)

The MYPIN HA0362 supports playing media directly from USB drives or Micro SD cards. Insert your storage device into the corresponding port on the player. Use the remote control to navigate to the 'Files' or 'Video/Photo/Music' section on the home screen to browse and play your content.



Image: The MYPIN HA0362 Media Player displaying a menu with options for video, music, and photo playback, highlighting automatic and loop play features.

4.2 App Control and Transmission (AlbumLink)

The 'AlbumLink' mobile application allows for easy transfer of advertising images or videos from your phone to the TV. It also enables using your phone as a remote control.

1. Download the 'AlbumLink' app on your smartphone.
2. Open the app and scan the QR code displayed on the TV screen to connect.
3. Once connected, you can transfer content or use your phone to control the media player.

The app supports controlling multiple advertising machines with one phone or multiple phones controlling one machine.



Image: A visual guide showing the three steps to connect a mobile phone to the media player for picture and video transmission to a TV.

4.3 Wireless Display Adapter with Screen Mirroring

The device supports screen mirroring from smartphones, laptops, and tablets to your display. This allows you to project content such as movies, photos, or business reports onto a larger screen.

Your browser does not support the video tag.

Video: Demonstration of MAC computer screen projection using the MYPIN HA0362 Media Player.

Your browser does not support the video tag.

Video: Demonstration of Windows computer screen mirroring using the MYPIN HA0362 Media Player.

Your browser does not support the video tag.

Video: Demonstration of iPhone screen projection using the MYPIN HA0362 Media Player.

4.4 Horizontal and Vertical Display Modes

The screen display can be freely switched between horizontal and vertical modes to suit your content and display orientation.

Your browser does not support the video tag.

Video: Guide on how to set the screen display orientation (horizontal or vertical) on the MYPIN HA0362 Media Player.

4.5 Automatic Playback and Looping

Configure the device to automatically play content upon startup and loop media for continuous display.

Your browser does not support the video tag.

Video: Instructions on how to configure the auto play settings for media on the MYPIN HA0362 Media Player.

4.6 Timed Power On/Off

Set specific times for the device to automatically power on and off, optimizing energy consumption and operational convenience.

Your browser does not support the video tag.

Video: Guide on managing file uploads, downloads, deletions, and setting timed power on/off functions on the MYPIN HA0362 Media Player.

4.7 Supported Media Formats

- **Video:** MP4, MKV, AVI, MOV, VOB, M2TS (using H.264/AVC)
- **Photos:** JPG, JPEG, BMP, GIF, PNG
- **Music:** MP3, WMA, OGG, FLAC, APE, AAC

5. MAINTENANCE

5.1 General Care

- Keep the device in a dry, well-ventilated area.
- Avoid exposing the device to extreme temperatures or direct sunlight.
- Clean the exterior with a soft, dry cloth. Do not use liquid cleaners.

5.2 Firmware Upgrades

Periodically check for firmware updates to ensure optimal performance and access to new features.

Instructions for upgrading the device can be found in the following video:

Your browser does not support the video tag.

Video: A guide detailing the process of upgrading the firmware on the MYPIN HA0362 Media Player.

6. TROUBLESHOOTING

- **No Signal on TV:** Ensure all HDMI and power cables are securely connected. Verify the TV input source matches the HDMI port used.
- **AlbumLink App Not Found:** If the AlbumLink app is not found in Google Play, please contact customer support for the latest installation program.
- **Connectivity Issues:** Ensure the device is within 15ft of your Wi-Fi router for optimal 2.4/5GHz dual-band transmission.
- **Media Playback Errors:** Check if the media file format is supported (refer to Section 4.7). Ensure the USB drive or Micro SD card is properly inserted and not corrupted.

7. SPECIFICATIONS

- **Brand Name:** MYPIN
- **Item Model Number:** HA0362
- **Item Weight:** 12.3 ounces
- **Package Dimensions:** 6.77 x 5.12 x 1.93 inches
- **Connectivity:** 2.4/5GHz Dual-Band Wi-Fi, HDMI, USB, AV, Micro SD
- **Video Output:** 1080P HD

8. WARRANTY AND SUPPORT

For warranty information or technical assistance, please refer to the product packaging or contact MYPIN customer support directly. Support is available for any operational queries or issues encountered with your device.