



[Manuals.plus](#) /

> [ropelux](#) /

> ropelux 52-Inch Ceiling Fan with Light (Model RPKY01-B52) Instruction Manual

ropelux RPKY01-B52

ropelux 52-Inch Ceiling Fan with Light (Model RPKY01-B52) Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the safe and efficient installation, operation, and maintenance of your ropelux 52-inch Ceiling Fan with Light, Model RPKY01-B52. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Figure 1: Overall view of the ropelux 52-inch ceiling fan, illustrating its dimensions and suitability for various ceiling heights (high, low, and slanted up to 15 degrees).

SAFETY INFORMATION

- **Electrical Safety:** Always ensure the power supply is OFF at the circuit breaker before beginning any installation or maintenance. If you are unsure about wiring, consult a qualified electrician.
- **Mounting Requirements:** Do not install the ceiling fan on a sloped ceiling exceeding a 15-degree gradient. Use a fan-rated Junction box (supporting minimum 100 lbs / 45 kg), not a light-rated box.
- **Blade Installation:** For the screwless snap-on blades, you must hear a distinct "click" when inserting each blade. Then, firmly pull each blade to ensure it is securely and safely locked before beginning wiring. Failure to do so may result in blades detaching during operation.
- **General Safety:** Keep hands clear of fan blades during operation. Do not attempt to stop the fan by hand.

WHAT'S IN THE BOX

Carefully unpack all components and ensure you have received the following items:

- Light Kit
- Remote Control
- Controller
- Motor
- Hanger Bracket
- 5 Fan Blades
- Decorative Cover
- Downrod (short and long options)
- Accessory Bag (screws, wire nuts, etc.)
- Instruction Manual

Your browser does not support the video tag.

Video 1: Unboxing and overview of the ropelux ceiling fan components, including the snap-on blades and remote control.

SETUP AND INSTALLATION

1. Install Mounting Bracket

Secure the hanger bracket to a fan-rated ceiling box (minimum 100 lbs / 45 kg). Ensure the maximum ceiling angle does not exceed 15 degrees. Use appropriate screws and anchors for your ceiling type.


2. Assemble Motor & Downrod

Choose the short or long downrod as needed for your ceiling height. Pass the motor wires through the downrod. Secure the downrod to the motor and tighten the screws and locking pin to ensure stability.

3. Install the Fan Blades

The ropelux fan features a patented snap-on design for convenient, screw-free blade installation. Push each blade into the slot until you hear a distinct "click." After hearing the click, firmly pull each blade to confirm it is securely locked. This safety check must be performed for every blade before proceeding with wiring.

Easy-Snap Blade Assembly



The image is a comparison graphic. On the left, a blue-bordered box shows a person's hands in white gloves snapping a black blade into a fan motor. A blue speech bubble says "click", a green stamp says "3 seconds", and a blue arrow points to the blade. Below this is a white pill-shaped button with "OURS" in blue. On the right, a grey-bordered box shows a hand using a power drill to screw a blade into a fan motor. A red stamp says "5 minutes". Below this is a white pill-shaped button with "OTHERS" in black. A blue circle with "VS" in white is between the two boxes. Below the "OTHERS" button is the text "Screw Blades Installation" and a paragraph describing the process.

3 seconds

click

VS

5 minutes

OURS

Easy-Snap fan Blade

To ensure optimal safety and performance, please ensure you hear a distinct "click" when pushing each blade in. Afterward, firmly pull each blade to confirm it is securely locked. This simple safety check must be performed for every blade before wiring.

OTHERS

Screw Blades Installation

Each blade requests 5 screws, 5*5 blades=25 screws totally. Installation becomes slower and harder.

Figure 2: Easy-Snap Blade Assembly, highlighting the secure click-in mechanism for quick installation.

Your browser does not support the video tag.

Video 2: Demonstrates the proper installation of snap-on fan blades, emphasizing the audible "click" for secure attachment and how to remove them.

4. Hang the Fan Body and Connect the Power Controller

Hang the assembled fan onto the mounting bracket, ensuring the downrod ball is seated securely in the bracket's groove. Insert the controller (receiver) into the bracket and connect it to the motor wires.

5. Wire the Fan to the Ceiling Power Wires

Connect the fan's wires to the ceiling power wires using wire nuts. Match colors: Black (Live) to Black (Live), White (Neutral) to White (Neutral), and Green (Ground) to Green (Ground). **Ensure the power is OFF at the circuit breaker before wiring.**

6. Neatly Arrange Wires and Fasten the Cover

Carefully tuck all wires into the junction box. Before final tightening, slightly loosen the screws on the mounting

bracket to align the holes for the decorative cover more easily. Fasten the decorative cover securely to the mounting bracket.

Your browser does not support the video tag.

Video 3: Step-by-step guide on how to install the ropelux ceiling fan, covering mounting, assembly, wiring, and securing the cover.

OPERATING INSTRUCTIONS

Remote & App Dual Control

Your ropelux ceiling fan can be controlled using the included handheld remote or via the "Fanlamp Pro" app on your smartphone. Both methods allow you to adjust fan speed, light dimming, color temperature, seasonal motor reversal, and timer settings.

Your browser does not support the video tag.

Video 4: Demonstrates the remote and app control features of the ceiling fan, including fan speed, light dimming, and color temperature adjustments.

Fan Speeds

The fan features 6 selectable speeds, from a soft, natural breeze to powerful cooling. The optimized 30-watt DC motor and precision-tilt blades deliver enhanced airflow.

Strong Airflow, Ultra-Quiet DC Motor



Figure 3: Illustration of the fan's 6-speed powerful cooling, highlighting the DC motor and high airflow.

Light Customization

The integrated 12-inch 25W LED light offers high brightness, anti-glare, and eye-friendly illumination. It is dimmable (210-2100 LM) and allows for color temperature adjustment from Warm White (3000K) to Natural White (4500K) and Cool White (6500K).

Customizable Light

Light Source:LED, Lifespan:50000Hrs, Light board is replaceable




Figure 4: Customizable light settings, showing different color temperatures and dimmable range.

Seasonal Modes

The fan offers two directional modes: downward for summer cooling and upward for winter warm air circulation, ensuring comfort throughout the year.

Reversible Air Circulation and 6 Wind Speed

Suitable for all seasons

Summer Mode

Downward Airflow
Forward Cool Airflow



Other seasons Mode

Upward Airflow
Better airflow in
cooler seasons



Figure 5: Reversible air circulation feature for optimal comfort in all seasons.

MAINTENANCE

To ensure optimal performance and longevity of your ropelux ceiling fan, regular maintenance is recommended:

- **Cleaning:** Dust the fan blades and motor housing periodically with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Tightness Check:** Periodically check all screws and connections to ensure they are secure. Loose connections can cause noise or wobbling.
- **Blade Balance:** If the fan wobbles, check that all blades are securely attached and balanced.

TROUBLESHOOTING

If you experience issues with your fan, refer to the following common troubleshooting steps:

- **Fan does not turn on:** Check the circuit breaker and wall switch. Ensure all wiring connections are secure. Verify the remote control batteries are functional.

- **Light does not work:** Check the light switch on the remote or app. Ensure wiring connections to the light kit are secure.
- **Fan wobbles:** Ensure the mounting bracket is securely fastened to a fan-rated junction box. Check that all fan blades are properly installed and clicked into place.
- **Remote/App not responding:** Replace remote batteries. Ensure the fan's power is on. Re-pair the remote/app if necessary (refer to the full user manual for pairing instructions).

SPECIFICATIONS

Brand	ropelux
Model Name	RPKY01-B52
Size	52 inch
Product Dimensions	52"D x 52"W x 11"H
Electric Fan Design	Ceiling Fan
Power Source	AC/DC
Style	Modern
Room Type	Bedroom, Dining Room, Garage, Kitchen, Living Room
Special Feature	Remote Controlled, App Control
Noise Level	30 Decibels
Wattage	30 watts (motor)
Number of Blades	5
Speed	6 levels, 290 RPM (max)
Voltage	265 Volts (AC)
Indoor/Outdoor Usage	Indoor
Motor Type	DC
Installation Type	Snap-in

WARRANTY AND SUPPORT

Ropelux provides a 10-Year warranty on the motor and a 2-year warranty on the entire ceiling fan with light. For any questions or support, please contact our reliable service team. We are ready to ensure your satisfaction.