

[manuals.plus](#) /› [iJoy](#) /› [IJOY Arcade Bluetooth Speaker User Manual](#)

iJoy Arcade

IJOY Arcade Bluetooth Speaker User Manual

Model: Arcade

Brand: iJoy

1. INTRODUCTION

This manual provides essential information for the safe and effective operation of your IJOY Arcade Bluetooth Speaker. The IJOY Arcade Bluetooth speaker features an LED light show, FM radio, and a built-in handle for portability. It offers true wireless Bluetooth connectivity, FM radio functionality, and a microphone input. Please read this manual thoroughly before using the product and retain it for future reference.

2. WHAT'S IN THE Box

Carefully unpack your IJOY Arcade Bluetooth Speaker and ensure all items are present and in good condition. If any items are missing or damaged, please contact customer support.

- IJOY Arcade Bluetooth Speaker
- USB Charging Cable
- Owner's Manual



Image: The IJOY Arcade Bluetooth Speaker shown alongside its included USB charging cable.

3. PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your IJOY Arcade Bluetooth Speaker.



Image: Front view of the IJOY Arcade Bluetooth Speaker, highlighting the control panel and the multi-colored LED light strips along the sides.

Control Panel (Top View)

- **M/Light Button:** Press to switch modes (Bluetooth, FM Radio). Press and hold to change or turn off LED light show.
- **Previous Track/Volume Down Button:** Short press for previous track (Bluetooth mode). Long press to decrease volume.
- **Play/Pause Button:** Press to play or pause audio. In FM mode, press to auto-scan and save stations.
- **Next Track/Volume Up Button:** Short press for next track (Bluetooth mode). Long press to increase volume.
- **Power Button:** Press and hold to turn the speaker ON/OFF.

Ports (Rear/Side View)

- **USB Charging Port:** For charging the speaker's internal battery.
- **Microphone Input:** For connecting an external microphone.

4. SETUP

4.1 Charging the Speaker

1. Connect the small end of the included USB charging cable to the USB charging port on the speaker.
2. Connect the larger end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging and turn off once fully charged.
4. Allow approximately 3-4 hours for a full charge before first use.

4.2 Powering On/Off

- To turn ON the speaker, press and hold the Power button until you hear an audible prompt.
- To turn OFF the speaker, press and hold the Power button again until you hear an audible prompt.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Pairing

1. Ensure the speaker is powered ON and in Bluetooth mode. If not, press the M/Light button to cycle through modes until you hear the Bluetooth pairing prompt.
2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).
3. Search for available Bluetooth devices and select "IJOY Arcade" from the list.
4. Once paired, the speaker will indicate a successful connection, and you can begin playing audio from your device.
5. The speaker will automatically attempt to reconnect to the last paired device when powered on.

5.2 FM Radio

1. Press the M/Light button to switch the speaker to FM Radio mode.
2. To auto-scan and save available FM stations, press the Play/Pause button once. The speaker will scan and store stations automatically.
3. Use the Previous Track and Next Track buttons to navigate between saved FM stations.
4. Adjust the volume using the long press function on the Previous Track and Next Track buttons.

5.3 LED Light Show

- The speaker features multi-colored LED lights that activate automatically when powered on.
- To change the LED light pattern or turn the lights off, press and hold the M/Light button. Cycle through available light modes or disable them as desired.

5.4 Microphone Input

- Connect a compatible microphone (not included) to the microphone input port on the speaker.
- The microphone audio will be mixed with the speaker's output, allowing for karaoke or public address functions.

5.5 True Wireless Pairing (TWS)

The IJOY Arcade speaker supports True Wireless Stereo (TWS) pairing, allowing you to connect two IJOY Arcade speakers together for a stereo sound experience.

1. Ensure both IJOY Arcade speakers are powered ON and in Bluetooth mode, but not connected to any device.
2. On one of the speakers (this will be the primary speaker), press and hold the Play/Pause button for a few seconds until you hear a pairing tone.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation tone.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described in section 5.1.
5. Audio will now play in stereo across both speakers.

6. MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the speaker to extreme temperatures, direct sunlight, or high humidity.
- Do not immerse the speaker in water or any other liquids.
- Store the speaker in a cool, dry place when not in use for extended periods.

7. TROUBLESHOOTING

Problem	Possible Solution
Speaker does not turn on.	Ensure the speaker is fully charged. Connect to a power source using the USB charging cable.
Cannot pair with Bluetooth device.	Make sure the speaker is in Bluetooth pairing mode. Ensure Bluetooth is enabled on your device and it is within range (approx. 33 feet/10 meters). Try restarting both the speaker and your device.
No sound or low volume.	Check the volume levels on both the speaker and your connected device. Ensure the speaker is not muted.
FM radio reception is poor.	Try repositioning the speaker to improve signal reception. Ensure you have performed an auto-scan for stations.
LED lights are not working.	Press and hold the M/Light button to cycle through light modes or reactivate them.

8. SPECIFICATIONS

Feature	Detail
Model Number	Arcade
Product Dimensions	3 x 5 x 10 inches (approx.)
Item Weight	2.5 pounds
Connectivity Technology	Bluetooth, FM Radio
Special Features	Built-in Handle, FM Radio, LED Light Show, Microphone Input, True Wireless Pairing
Power Source	Battery Powered (1 Nonstandard Battery included)
Color	Black
Manufacturer	iJoy

© 2025 iJoy. All rights reserved.

Related Documents - Arcade

	<u>iJoy Mini+ Massage Chair: Use, Care, and Maintenance Manual</u> Comprehensive user manual for the iJoy Mini+ robotic massage chair, covering setup, operation, safety guidelines, maintenance, and warranty information for optimal relaxation and well-being.
	<u>iJoy 550 Massage Chair: Use & Care Manual</u> Comprehensive guide to operating, assembling, and maintaining your iJoy 550 massage chair by Interactive Health. Learn about safety features, massage modes, and warranty information.
	<u>iJoy-250 Turbo2 Use & Care Manual: Interactive Health Massage Chair</u> Comprehensive use and care manual for the Interactive Health iJoy-250 Turbo2 robotic massage chair. Learn about safety instructions, operation, features, maintenance, and warranty for your robotic massage experience.
	<u>IJOY Elite Mini Kit: Comprehensive User Manual and Guide</u> Detailed user manual for the IJOY Elite Mini Kit, covering specifications, operation, functions, troubleshooting, and safety warnings. Learn how to use your 60W vaping device.

	<p><u>iJoy 127 Massage Chair Use & Care Manual</u></p> <p>Discover the features, safety guidelines, and maintenance instructions for the iJoy 127 Robotic Massage Chair by Interactive Health. This comprehensive manual covers operation, massage modes, grounding, warranty, and specifications for optimal well-being.</p>
	<p><u>iJoy 300 Robotic Massage Chair Use and Care Manual</u></p> <p>Comprehensive use and care manual for the iJoy 300 Robotic Massage Chair, featuring Human Touch Technology. Learn about safety, assembly, operation, massage modes, and maintenance for optimal relaxation and well-being.</p>