

Hauslane WM-538SS

Hauslane Wall Mount Range Hood User Manual

Model: WM-538SS (30 Inch)

1. SAFETY INFORMATION

Please read all instructions carefully before installation and operation to prevent injury and property damage. Keep this manual for future reference.

- **Electrical Safety:** Ensure the power supply matches the voltage requirements (120 Volts, 1.8 Amps). Always disconnect power before servicing or cleaning.
- **Installation:** Installation must be performed by a qualified installer in accordance with all local codes and standards.
- **Fire Hazard:** Never leave surface cooking unattended. Clean grease filters regularly to prevent grease fires.
- **Ventilation:** Ensure proper ventilation for combustion gases from fuel-burning equipment to prevent back-drafting.
- **Moving Parts:** Keep hands and clothing away from moving parts during operation.

2. PRODUCT OVERVIEW

The Hauslane WM-538SS is a 30-inch wall-mount range hood designed to enhance your kitchen's ventilation and aesthetics. It features a sleek stainless steel European-style design with modern touch controls and efficient LED lighting.

Key Features:

- **Professional Wall-Mounted Design:** Crafted from premium stainless steel, maximizing wall space.
- **3-Speed Touch Controls:** Intuitive touch panel for fan speed and lighting adjustments.
- **Customizable LED Lighting:** Energy-saving GU10 base LED lamps, easily replaceable.
- **Dishwasher-Safe Baffle Filters:** Stainless steel filters effectively trap grease and odors for easy cleaning.
- **Ducted or Ductless Convertible:** Versatile installation options (requires optional recirculation kit for ductless, sold separately).

- **High Ceiling Compatibility:** Designed for kitchens with up to 10-foot ceilings, with an optional extension kit available.

Components Included:

- Range Hood Main Unit
- Dishwasher-Safe Baffle Filters (2 for 30" model)
- Lower Chimney Cover (1)
- Upper Chimney Cover (1)
- Chimney Bracket (1)
- Grease Cup (1)
- Top 6" Round Exhaust Adapter (1)
- Mounting Hardware
- Instruction Manual



Figure 2.1: Front view of the Hauslane Wall Mount Range Hood.

Designed for Heavy-Duty Cooking



Figure 2.2: Diagram highlighting key features including ceiling height compatibility, touch controls, baffle filters, and changeable lights.



Figure 2.3: All components included in the product package.

3. SETUP AND INSTALLATION

This section provides general guidelines for installing your range hood. For detailed, step-by-step instructions, please refer to the dedicated installation manual included with your product.

Pre-Installation Checklist:

- Verify all components are present and undamaged.
- Ensure adequate wall structure for mounting.
- Confirm electrical supply meets specifications.
- Determine if installation will be ducted (6" round duct system required) or ductless (requires optional recirculation kit).

General Installation Steps:

1. **Mounting:** Securely attach the mounting bracket to the wall studs at the appropriate height above your cooking surface.
2. **Ducting (Ducted Installation):** Connect the 6-inch round exhaust adapter to your existing ductwork. Ensure all connections are sealed to prevent air leaks.
3. **Electrical Connection:** Connect the range hood to a grounded electrical outlet or hardwire according to local electrical codes.
4. **Chimney Cover Installation:** Install the upper and lower chimney covers, adjusting for ceiling height. An optional extension kit is available for ceilings up to 10 feet.
5. **Filter Installation:** Insert the baffle filters into their designated slots.

WM-538

Size: 30"



* Adjustable
Chimney Cover

L: 26 - 44 1/2 inch | 66-113 cm

D: 19 inch | 48 cm

W: 29 3/8 inch | 75 cm

Figure 3.1: Product dimensions for the WM-538SS 30-inch model.

4. OPERATING INSTRUCTIONS

The Hauslane WM-538SS range hood features an intuitive touch control panel for easy operation of its functions.

Control Panel Functions:

- **Power Button ():** Press to turn the range hood on or off.
- **Fan Speed Control (+/-):** Adjusts the fan speed through three settings (Low, Medium, High). Press '+' to increase speed, '-' to decrease.
- **Light Button ():** Toggles the LED lights on or off.
- **Timer Function:** The display may show a timer or clock. Refer to the full installation manual for specific instructions on setting and using the timer.



Figure 4.1: Detailed view of the touch control panel.

5. MAINTENANCE



Regular maintenance ensures optimal performance and longevity of your Hauslane range hood.

Cleaning Baffle Filters:

The stainless steel baffle filters are designed to be dishwasher-safe for easy cleaning.

1. Turn off the range hood and disconnect power.
2. Locate the filter release latches and carefully remove the baffle filters.
3. Place the filters in a dishwasher for a thorough cleaning cycle. Alternatively, wash by hand with hot, soapy water.
4. Ensure filters are completely dry before re-installing.
5. Re-insert the filters, ensuring they click securely into place.

Say No to Grease Drips



Deep-Groove Baffle Filter
Capture grease drips before
they land in tonight's dinner

Dishwasher-Safe
Made with
stainless steel

Figure 5.1: Close-up view of the deep-groove baffle filters.



Figure 5.2: Demonstrating the ease of cleaning baffle filters in a dishwasher.

Cleaning Exterior Surfaces:

Wipe stainless steel and tempered glass surfaces with a soft cloth and a mild, non-abrasive cleaner. Avoid harsh

chemicals or abrasive pads that could scratch the finish.

Replacing LED Lights:

The range hood uses GU10 base LED bulbs, which are widely available at hardware stores.

1. Turn off the range hood and disconnect power.
2. Carefully twist and unlock the existing GU10 bulb from its socket.
3. Insert the new GU10 LED bulb and twist to lock it into place.
4. Reconnect power and test the lights.

Changeable GU10 LED Lights




Figure 5.3: Illustration of the changeable GU10 LED lights.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your range hood. For problems not listed here,

please contact customer support.

Problem	Possible Cause	Solution
Range hood does not turn on.	No power supply; circuit breaker tripped; loose wiring.	Check power connection; reset circuit breaker; ensure all wiring is secure (consult a qualified electrician if unsure).
Low suction power.	Clogged filters; improper ducting; external blockage.	Clean baffle filters; check ductwork for kinks or blockages; ensure external vent is clear.
Excessive noise during operation.	Loose components; motor issue; improper installation; ducting issues.	Ensure all parts are securely fastened; check for obstructions in the fan; verify ducting is properly sized and installed. Note: Higher fan speeds will naturally produce more noise.
Lights not working.	Bulb burnt out; loose connection; electrical issue.	Replace LED bulb; check light switch and connections; consult electrician if problem persists.

7. SPECIFICATIONS

Detailed technical specifications for the Hauslane WM-538SS 30-inch Wall Mount Range Hood.

Attribute	Value
Model Number	WM-538SS
Product Dimensions (WxDxH)	29-3/8" x 19" x 31" - 46" (Adjustable Height)
Material	Stainless Steel
Noise Level	7 Sones
Mounting Type	Wall Mount
Amperage	1.8 Amps
Voltage	120 Volts
Number of Speeds	3
Item Weight	24 Pounds
Wattage	216 Watts
Filter Type	Baffle (Dishwasher-Safe)
Airflow Displacement	860 Cubic Feet Per Minute (CFM)

Attribute	Value
Special Features	6" Round or Ductless, LED Lighting, Touch Screen

8. WARRANTY AND SUPPORT

Hauslane stands behind the quality of its products.



Warranty Information:





- **Lifetime Motor Warranty:** The range hood motor is covered by a lifetime warranty.
- **2-Year Limited Warranty:** The entire stove hood comes with a 2-year limited warranty covering defects in materials and workmanship.

For warranty claims, technical assistance, or to purchase optional accessories (e.g., extension kits, recirculation kits), please contact Hauslane customer support. Refer to the contact information provided in your product packaging or visit the official Hauslane website.

© 2025 Hauslane. All rights reserved.

Related Documents - WM-538SS

	<p>Hauslane IN-R100 Pro-Style 30-inch Built-In Range Hood Powerful Suction & Easy Cleaning</p> <p>Discover the Hauslane IN-R100 Pro-Style 30-inch built-in range hood. Featuring 600 CFM powerful suction, dishwasher-safe baffle filters, low-noise operation, and convertible ductless/ducted installation. Ideal for any kitchen style.</p>
	<p>Hauslane WM-730 Model Series User Manual</p> <p>Comprehensive user manual for the Hauslane WM-730 Model Series range hood, covering installation, operation, care, and troubleshooting.</p>

<div><div>USER MANUAL</div><div><p>WM-540 Model Series</p></div><div>HAUSLANE chefseries</div></div>	<p>Hauslane WM-540 Range Hood User Manual and Installation Guide</p> <p>Comprehensive user manual and installation guide for the Hauslane WM-540 model series range hood. Includes safety information, parts list, step-by-step installation instructions, usage guide, and warranty details.</p>
<div><div>USER MANUAL</div><div><p>WM-530 PRO Model Series</p></div><div>HAUSLANE</div></div>	<p>Hauslane WM-530 PRO Series Range Hood User Manual Installation and Operation Guide</p> <p>Comprehensive user manual for the Hauslane WM-530 PRO Series range hood, covering installation, operation, maintenance, and troubleshooting. Includes safety information and warranty details.</p>
<div><div><p>HAUSLANE</p></div></div>	<p>Hauslane IS-200 Contemporary Style Island Range Hood Technical Drawings and Specifications</p> <p>Detailed technical drawings, dimensions, and installation height guidelines for the Hauslane IS-200 Contemporary Style Island Range Hood, available in 30-inch and 36-inch models. Includes contact information and product specifications.</p>
<div><div>USER MANUAL</div><div><p>Model UC-PS38SS-30</p></div><div>HAUSLANE</div></div>	<p>Hauslane UC-PS38SS-30 User Manual: Installation, Operation, and Maintenance</p> <p>Comprehensive user manual for the Hauslane UC-PS38SS-30 range hood, covering installation, operation, safety precautions, maintenance, and troubleshooting. Learn how to properly install and use your kitchen ventilation system.</p>