

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tronsmart](#) /

› [Tronsmart 30W Outdoor Portable Wireless Speaker User Manual](#)

Tronsmart CLA T

Tronsmart 30W Outdoor Portable Wireless Speaker User Manual

Model: CLA T

INTRODUCTION

Thank you for choosing the Tronsmart 30W Outdoor Portable Wireless Speaker. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your speaker. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Figure 1: Tronsmart 30W Outdoor Portable Wireless Speaker (Model CLA T)

This image displays the Tronsmart CLA T speaker from an angled perspective, showcasing its cylindrical design, control panel, and the illuminated volume knob at the top. The speaker is dark blue with a textured fabric finish.

WHAT'S IN THE BOX

Please check the contents of your package. If any items are missing or damaged, contact your retailer.

- 1 x Tronsmart CLA T Wireless Speaker
- 1 x USB-C Charging Cable
- 1 x User Manual
- 1 x Lanyard

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-C charging cable to the speaker's charging port and the other end to a compatible USB power adapter (not included). The charging indicator light will show the charging status.

2. Powering On/Off

- To power on: Press and hold the **Power button** for 2 seconds.
- To power off: Press and hold the **Power button** for 2 seconds.

3. Bluetooth Pairing

The speaker will automatically enter Bluetooth pairing mode when powered on for the first time. The Bluetooth indicator light will flash rapidly.

1. Enable Bluetooth on your device (smartphone, tablet, etc.).
2. Search for "Tronsmart CLA T" in the list of available Bluetooth devices.
3. Select "Tronsmart CLA T" to connect. Once connected, the Bluetooth indicator light will turn solid blue.

4. True Wireless Stereo (TWS) Pairing

You can pair two Tronsmart CLA T speakers together for a true wireless stereo experience, providing 60W total output.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), double-press the **TWS button** (often indicated by two linked circles or a similar icon). The speaker will enter TWS pairing mode.
3. The two speakers will automatically connect to each other. Once connected, the TWS indicator light on both speakers will turn solid.
4. Connect your device to the primary speaker via Bluetooth as described in "Bluetooth Pairing" above.

TRUE WIRELESS STEREO PAIRING & EQ

APP control--Quickly pair two speakers to form stereo surround sound



Figure 2: True Wireless Stereo Pairing Setup

This image illustrates two Tronsmart CLA T speakers placed on a desk, wirelessly connected to each other and to a smartphone displaying an equalizer app. This setup demonstrates the True Wireless Stereo pairing feature.

5. Tronsmart App Installation

For personalized EQ settings and additional features, download the Tronsmart app from your device's app store (Google Play Store for Android, Apple App Store for iOS). Search for "Tronsmart".

OPERATING THE SPEAKER

1. Control Panel Overview



Figure 3: Speaker Features and Controls

This image highlights key features of the Tronsmart CLA T speaker, including 360-degree HD surround sound, 2-speaker stereo fast pairing, independent tweeter and woofer, 30W ultra bass radiator, adjustable volume wheel, IPX6 waterproof rating, 12-hour play time, and EQ & APP control. The speaker's control panel with various buttons is clearly visible.

The speaker features an intuitive control panel for easy operation:

- **Power Button:** Press and hold to power on/off.
- **Play/Pause Button:** Press to play or pause music.
- **Volume Up Button:** Press to increase volume.
- **Volume Down Button:** Press to decrease volume.
- **Next Track Button:** Press to skip to the next song.
- **Previous Track Button:** Press to go to the previous song.
- **Light Mode Button:** Press to cycle through 7-color adjustable ring light modes.
- **EQ Button:** Press to cycle through preset equalizer modes or activate voice assistant (double-tap).
- **Volume Knob:** Rotate the top knob for precise volume control and light adjustments.

2. Volume Knob & Light Show

The top volume knob offers 360-degree rotation for easy volume control. It also features a 7-color adjustable ring light with

4 modes that can sync with your music, creating a vibrant atmosphere.

- Rotate clockwise to increase volume.
- Rotate counter-clockwise to decrease volume.
- Press the Light Mode button to change light effects.

3. Hands-Free Calling

When connected to your smartphone via Bluetooth, the speaker can be used for hands-free calls.

- **Answer Call:** Press the Play/Pause button once.
- **End Call:** Press the Play/Pause button once during a call.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds.

4. Micro SD/TF Card Playback

The speaker supports music playback directly from a Micro SD/TF card. Insert a card with audio files into the designated slot. The speaker will automatically switch to Micro SD/TF card mode and begin playback.

MAINTENANCE

1. Cleaning

To clean the speaker, use a soft, dry cloth. Do not use abrasive cleaners, alcohol, or other chemical solvents, as these may damage the surface or internal components.

2. Waterproofing (IPX6)

The Tronsmart CLA T speaker is IPX6 waterproof, meaning it is resistant to high-pressure, heavy sprays of water. It is suitable for outdoor use and can withstand rain, dust, snow, and spills. **Do not submerge the speaker in water.** Ensure the charging port cover is securely closed before exposing the speaker to water.

ULTRA IPX6 WATERPROOF

Sealed waterproof design, no fear
of any extreme water wading activities



Figure 4: IPX6 Waterproof Capability

This image shows the Tronsmart CLA T speaker partially submerged in water, with splashes around it, demonstrating its IPX6 waterproof rating. The speaker's illuminated ring light is visible even underwater.

3. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery periodically to maintain its health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully.

Problem	Possible Cause	Solution
No sound from speaker.	Volume is too low or muted. Speaker not connected via Bluetooth. Audio source issue.	Increase volume on speaker and connected device. Re-pair the speaker with your device. Check audio source (e.g., music app, Micro SD card).
Cannot pair via Bluetooth.	Speaker is too far from device. Speaker is connected to another device. Bluetooth on device is off.	Move speaker closer to device. Disconnect from other devices. Ensure Bluetooth is enabled on your device.
TWS pairing fails.	Speakers are too far apart. One speaker is already connected to a device.	Ensure speakers are within 10 meters of each other. Disconnect both speakers from any Bluetooth devices before TWS pairing.
Light show not working.	Light mode is off or set to a static color.	Press the Light Mode button to cycle through different light effects.

SPECIFICATIONS

Feature	Detail
Model Name	Tronsmart CLA T
Speaker Type	Outdoor Portable Wireless Speaker
Speaker Maximum Output Power	36 Watts
Connectivity Technology	Bluetooth, Wi-Fi
Waterproof Rating	IPX6
Product Dimensions	3.01"D x 3.01"W x 8.5"H
Play Time	Up to 12 hours (Varies by volume level and audio content)
Battery	1 AAA batteries required. (included) <i>(Note: This specification is from the provided data. The speaker itself uses a built-in rechargeable battery for operation.)</i>
Manufacturer	Tronsmart
Item Model Number	CLA T
ASIN	B0F6MLC9QD




Figure 5: Speaker Internal Components

This image provides an exploded view of the Tronsmart CLA T speaker, detailing its internal components such as 40mm large size dual magnetic 16-core voice coils and 67mm extra large size single magnetic 25-core voice coils, highlighting the drivers responsible for its 360-degree sound and enhanced bass.



Figure 6: Speaker in Use (30W High Power & 12H Play Time)

This image shows a group of young people outdoors, with the Tronsmart CLA T speaker placed on the ground, emitting sound waves. This illustrates the speaker's 30W high power output and its 12-hour play time, suitable for extended outdoor activities.

WARRANTY AND SUPPORT

Tronsmart products are designed and manufactured to the highest quality standards. For warranty information and customer support, please refer to the warranty card included with your product or visit the official Tronsmart website. You can also contact Tronsmart customer service directly for assistance with product inquiries, technical support, or warranty claims.

Official Website: www.tronsmart.com



