

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Quicent](#) /

› [Quicent Heavy Duty 10x20 Pop Up Canopy S1 Instruction Manual](#)

Quicent S1

Quicent Heavy Duty 10x20 Pop Up Canopy S1 Instruction Manual

Model: S1

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective assembly, operation, maintenance, and troubleshooting of your Quicent Heavy Duty 10x20 Pop Up Canopy, Model S1. Please read all instructions carefully before setup and retain this manual for future reference.

IMPORTANT SAFETY INFORMATION

WARNING:

- Always secure the canopy with all 4 sandbags and guy lines, especially in windy conditions.
- Do not use in winds exceeding 30 mph.
- Keep away from heat sources to prevent fire hazards.
- Avoid prolonged exposure to UV rays.

COMPONENTS AND PARTS LIST

Your Quicent Heavy Duty 10x20 Pop Up Canopy includes the following:

- Heavy-duty alloy steel frame
- 500D Oxford fabric canopy top with silver coating (99.99% UV block, waterproof)
- 4 sandbags
- 8 stakes
- Guy lines
- 800D wheeled carry bag

Note: Sidewalls are not included with this specific model.

SETUP INSTRUCTIONS

The canopy is designed for quick and intuitive assembly, typically taking around 1 minute with two people. No complex locks or tools are required.

1. Step 1: Unpack the Frame

Remove the folded frame from the wheeled carry bag. Place the frame in the desired setup location.



Image: The folded canopy frame being removed from its bag, illustrating the initial unpacking step.

2. Step 2: Partially Expand the Frame

With a partner, grasp opposite legs of the frame and slowly pull outwards to partially expand the frame. Do not fully extend yet.



Image: The canopy frame partially expanded, showing the initial structure before the top cover is applied.

3. Step 3: Attach the Canopy Top

Drape the 500D Oxford fabric canopy top over the partially expanded frame. Ensure the corners of the canopy top align with the frame's corner legs. Secure the canopy top to the frame using the integrated Velcro straps.



Image: A close-up view demonstrating how to attach the canopy fabric to the frame using Velcro straps for a secure fit.

4. Step 4: Fully Expand and Lock the Frame

Continue pulling the frame outwards until it is fully expanded. Lift the truss bars at each corner until they click into place, locking the frame securely. The frame features anti-pinch pull rings for safety.



Image: The fully expanded canopy frame, highlighting the robust Q195 steel connectors and overall structure.

5. Step 5: Adjust Leg Height

Press the button on each leg and lift the outer leg until it locks into the desired height. The canopy offers three adjustable height levels.



Image: A person adjusting the height of a canopy leg, demonstrating the three-level adjustable feature.

6. Step 6: Secure the Canopy

Utilize the provided 4 sandbags and 8 stakes to firmly anchor the canopy to the ground. Attach guy lines to the canopy corners and stake them into the ground for additional stability, especially in windy conditions.



Image: A fully assembled canopy, showing the use of sandbags and stakes for secure anchoring.

7. Video: Quicent 10x20 Party Tent Setup

Video: A detailed demonstration of setting up a Quicent 10x20 Party Tent, including frame expansion, canopy attachment, and securing the structure.

OPERATING INSTRUCTIONS

Adjusting Height

The canopy legs feature a three-level height adjustment. To adjust, press the red button on the leg mechanism and slide the inner leg to the desired height. Ensure the button clicks securely into place at each adjustment point.

Weather Protection

The 500D silver-coated Oxford fabric provides 99.99% UV protection and is waterproof. The 60° angled roof design facilitates 50% faster rain shedding compared to flat canopies, preventing water accumulation.

All-Weather Coverage



Image: The canopy offering protection from both sun (UV) and rain (waterproof), highlighting its all-weather capabilities.

MAINTENANCE

- **Cleaning:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before storage.
- **Frame Care:** Inspect the alloy steel frame regularly for any signs of damage or rust. Clean any dirt or debris from the frame.
- **Storage:** Always collapse the canopy and store it in its 800D wheeled carry bag when not in use. Ensure the canopy is completely dry before storage to prevent mold and mildew. Store in a cool, dry place.

TROUBLESHOOTING

- **Canopy instability:** Ensure all 4 sandbags are filled and properly placed, and all 8 stakes and guy lines are securely fastened. Check that all frame locks are engaged.
- **Water pooling on top:** The 60° angled roof is designed to shed water. Ensure the canopy top is taut and properly attached to the frame. Adjust leg heights if necessary to maintain tension.

- **Difficulty expanding/collapsing:** Ensure no parts are obstructed or bent. Apply gentle, even pressure. If the frame is stiff, check for debris in the joints.

SPECIFICATIONS

Feature	Detail
Brand	Quictent
Model Number	S1
Size	10x20 Without Sidewall
Product Dimensions	240"L x 121"W x 127"H
Material	500D Oxford (Canopy), Alloy Steel (Frame/Poles)
Color	Gray
Ultraviolet Light Protection	YES (UPF 50+, 99.99% UV Block)
Water Resistance Level	Waterproof
Assembly Required	Yes
Item Weight	72.8 pounds
Recommended Uses	Camping, Beach, Picnics, Parties, Tailgate, Sports Games, Weddings, Anniversaries, Backyard, Vendor Booth, Family Activities

WARRANTY AND SUPPORT

Your Quictent Heavy Duty Pop Up Canopy Model S1 comes with a 1-year frame warranty and a half-year cover warranty. For any support needs, please refer to the contact information provided at the point of purchase or visit the official Quictent website.