



Manuals.plus /

- › OHY /
- › OHY K61 60% Wired Backlit Mini Membrane Gaming Keyboard User Manual

OHY K61

OHY K61 60% Wired Backlit Mini Membrane Gaming Keyboard User Manual

Model: K61 | Brand: OHY

1. INTRODUCTION

This manual provides detailed instructions for the OHY K61 60% Wired Backlit Mini Membrane Gaming Keyboard. Please read this manual thoroughly before using the product to ensure proper operation and to maximize your user experience. This keyboard is designed for both gaming and general office use, offering a compact design and responsive performance.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- OHY K61 60% Wired Backlit Mini Membrane Gaming Keyboard
- Detachable Type-C USB Cable

3. PRODUCT OVERVIEW

The OHY K61 keyboard features a compact 60% layout, designed to save desktop space while providing essential functionality. It incorporates membrane switches with a mechanical feel, RGB backlighting, and a stable wired connection.



Image 3.1: OHY K61 60% Wired Backlit Mini Membrane Gaming Keyboard. This image displays the compact layout of the keyboard with its vibrant RGB backlighting.

COMPACT SIZE LIGHTWEIGHT DESIGN

320G



Image 3.2: Dimensions of the OHY K61 keyboard. The keyboard measures 294mm (11.5 inches) in length, 100mm (3.9 inches) in width, and 23.7mm (0.9 inches) in height, weighing approximately 320g.

WIN & MAC COMPATIBLE QUIET WIRED KEYBOARD



Image 3.3: OHY K61 keyboard demonstrating compatibility with both Windows and Mac operating systems, emphasizing its quiet operation.

4. SETUP INSTRUCTIONS

1. **Connect the Cable:** Insert the Type-C end of the provided USB cable into the port on the back of the OHY K61 keyboard.
2. **Connect to Computer:** Plug the standard USB-A end of the cable into an available USB port on your computer (PC or Mac).
3. **Automatic Installation:** The keyboard is plug-and-play. Your operating system should automatically detect and install the necessary drivers. No additional software or drivers are required.
4. **Ready for Use:** Once detected, the keyboard is ready for immediate use.

5. OPERATING INSTRUCTIONS

5.1. RGB Backlight Control

The OHY K61 keyboard features dynamic RGB backlighting. Use the following key combinations to control the lighting effects:

- **FN + " (Sun icon) Key:** Toggle backlight ON/OFF.
- **FN + , (Sun icon) Key:** Switch between different backlight modes (e.g., always bright, breathing mode).
- **FN + [{" Key:** Decrease backlight brightness.
- **FN +]}] Key:** Increase backlight brightness.
- **FN + ,< Key:** Decrease breathing frequency (slow down effect).
- **FN + ,> Key:** Increase breathing frequency (speed up effect).



Image 5.1: Visual guide for RGB backlight control. This image illustrates the key combinations for changing backlight modes and turning the backlight on/off.

5.2. FN Key Functions

The Function (FN) key allows access to secondary functions printed on certain keys. Hold down the FN key and press the desired key to activate its secondary function.

- **FN + 1 through += (F1-F12):** Access F1 through F12 functions. Refer to the keycaps for specific assignments.
- **FN + Win Key:** Lock/Unlock the Windows key to prevent accidental presses during gaming.



Image 5.2: Diagram showing FN key combinations for F1-F12 functions. This visual aid helps users quickly identify and utilize the secondary functions of the keyboard.

5.3. Anti-Ghosting

The keyboard supports 24-key no-conflict (anti-ghosting), ensuring that multiple simultaneous key presses are registered accurately, which is beneficial for fast-paced gaming and typing.

6. MAINTENANCE

To ensure the longevity and optimal performance of your OHY K61 keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the keyboard. For dust and debris between keycaps, use compressed air. Avoid using harsh chemicals or abrasive materials.
- **Spill Prevention:** While the keyboard has some splash-proof features, it is not fully waterproof. Avoid exposing it to excessive liquids. In case of a spill, immediately disconnect the keyboard and allow it to dry completely before reconnecting.
- **Cable Care:** Handle the detachable Type-C cable with care. Avoid bending or twisting it excessively, which can damage the internal wires.
- **Storage:** When not in use for extended periods, store the keyboard in a clean, dry environment away from direct sunlight and extreme temperatures.

**SPLASH
PROOF**



**ERGONOMIC
DESIGN**



QUIET KEYS



Image 6.1: Key features of the OHY K61 keyboard, including splash-proof design, ergonomic profile, and quiet key operation.

7. TROUBLESHOOTING

If you encounter issues with your OHY K61 keyboard, refer to the following common problems and solutions:

- **Keyboard Not Responding:**

- Ensure the USB cable is securely connected to both the keyboard and your computer.
- Try plugging the keyboard into a different USB port on your computer.
- Test the keyboard on another computer to determine if the issue is with the keyboard or the computer's USB port.
- Restart your computer.

- **Backlight Not Working or Incorrect:**

- Press **FN + "** (Sun icon) to ensure the backlight is turned ON.
- Adjust brightness using **FN + [** and **FN +]**.
- Cycle through backlight modes using **FN + ,** (Sun icon).

- **Keys Not Registering or Ghosting:**

- Ensure no debris is lodged under the keycaps.
- The keyboard features 24-key anti-ghosting, but extreme simultaneous presses beyond this limit may not register.

- **Windows Key is Disabled:**

- Press **FN + Win Key** to toggle the Windows key lock.

8. SPECIFICATIONS

Feature	Specification
Product Dimensions	11.5 x 3.9 x 0.9 inches (294 x 100 x 23.7 mm)
Item Weight	14.7 ounces (approx. 320g)
Manufacturer	OHY
Model Number	K61 (WJD-K61-Black+White)
Connectivity Technology	USB-C (Wired)
Keyboard Description	Membrane (Mechanical Feel)
Recommended Uses	Business, Gaming
Special Features	Ergonomic, Lightweight, Portable, Quiet, Splash-proof
Backlighting	RGB
Material	Plastic
Compatible Devices	Laptop, PC (Windows XP/VISTA/7/8/10, Mac)

9. WARRANTY AND SUPPORT

OHY provides an 18-month after-sales service for this product. If you encounter any quality problems or have questions during use, please contact OHY customer support. Your inquiries will typically be addressed within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official OHY website.